

TigerSwitch 10/100/1000

Gigabit Ethernet Switch

- ◆ 24 auto-MDI/MDI-X 10/100/1000BASE-T ports
- ◆ 4 ports shared with 4 SFP transceiver slots
- ◆ Non-blocking switching architecture
- ◆ Support for a redundant power unit
- ◆ Spanning Tree Protocol
- ◆ Up to six LACP or static 4-port trunks
- ◆ Layer 2/3/4 CoS support through four priority queues
- ◆ Full support for VLANs with GVRP
- ◆ IGMP multicast filtering and snooping
- ◆ Support for jumbo frames up to 9 KB
- ◆ Manageable via console, Web, SNMP/RMON



TigerSwitch 10/100/1000 Management Guide

From SMC's Tiger line of feature-rich workgroup LAN solutions

SMC[®]

N e t w o r k s

38 Tesla

Irvine, CA 92618

Phone: (949) 679-8000

June 2002

Pub. # 150200016900A

Information furnished by SMC Networks, Inc. (SMC) is believed to be accurate and reliable. However, no responsibility is assumed by SMC for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of SMC. SMC reserves the right to change specifications at any time without notice.

Copyright © 2002 by
SMC Networks, Inc.

38 Tesla

Irvine, CA 92618

All rights reserved. Printed in Taiwan

Trademarks:

SMC is a registered trademark; and EZ Switch, TigerStack and TigerSwitch are trademarks of SMC Networks, Inc. Other product and company names are trademarks or registered trademarks of their respective holders.

LIMITED WARRANTY

Limited Warranty Statement: SMC Networks, Inc. (“SMC”) warrants its products to be free from defects in workmanship and materials, under normal use and service, for the applicable warranty term. All SMC products carry a standard 90-day limited warranty from the date of purchase from SMC or its Authorized Reseller. SMC may, at its own discretion, repair or replace any product not operating as warranted with a similar or functionally equivalent product, during the applicable warranty term. SMC will endeavor to repair or replace any product returned under warranty within 30 days of receipt of the product.

The standard limited warranty can be upgraded to a Limited Lifetime* warranty by registering new products within 30 days of purchase from SMC or its Authorized Reseller. Registration can be accomplished via the enclosed product registration card or online via the SMC web site. Failure to register will not affect the standard limited warranty. The Limited Lifetime warranty covers a product during the Life of that Product, which is defined as the period of time during which the product is an “Active” SMC product. A product is considered to be “Active” while it is listed on the current SMC price list. As new technologies emerge, older technologies become obsolete and SMC will, at its discretion, replace an older product in its product line with one that incorporates these newer technologies. At that point, the obsolete product is discontinued and is no longer an “Active” SMC product. A list of discontinued products with their respective dates of discontinuance can be found at:

http://www.smc.com/index.cfm?action=customer_service_warranty.

All products that are replaced become the property of SMC. Replacement products may be either new or reconditioned. Any replaced or repaired product carries either a 30-day limited warranty or the remainder of the initial warranty, whichever is longer. SMC is not responsible for any custom software or firmware, configuration information, or memory data of Customer contained in, stored on, or integrated with any products returned to SMC pursuant to any warranty. Products returned to SMC should have any customer-installed accessory or add-on components, such as expansion modules, removed prior to returning the product for replacement. SMC is not responsible for these items if they are returned with the product.

Customers must contact SMC for a Return Material Authorization number prior to returning any product to SMC. Proof of purchase may be required. Any product returned to SMC without a valid Return Material Authorization (RMA) number clearly marked on the outside of the package will be returned to customer at customer's expense. For warranty claims within North America, please call our toll-free customer support number at (800) 762-4968. Customers are responsible for all shipping charges from their facility to SMC. SMC is responsible for return shipping charges from SMC to customer.

WARRANTIES EXCLUSIVE: IF AN SMC PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT OF THE PRODUCT IN QUESTION, AT SMC'S OPTION. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER

LIMITED WARRANTY

LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. SMC SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: IN NO EVENT, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), SHALL SMC BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF SMC OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR THE LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE. NOTHING IN THIS WARRANTY SHALL BE TAKEN TO AFFECT YOUR STATUTORY RIGHTS.

* SMC will provide warranty service for one year following discontinuance from the active SMC price list. Under the limited lifetime warranty, internal and external power supplies, fans, and cables are covered by a standard one-year warranty from date of purchase.

SMC Networks, Inc.
38 Tesla
Irvine, CA 92618

CONTENTS

| | | |
|----------|--|------------|
| 1 | Switch Management | 1-1 |
| | Connecting to the Switch | 1-1 |
| | Configuration Options | 1-1 |
| | Required Connections | 1-3 |
| | Remote Connections | 1-4 |
| | Basic Configuration | 1-5 |
| | Console Connection | 1-5 |
| | Setting Passwords | 1-5 |
| | Setting an IP Address | 1-6 |
| | Enabling SNMP Management Access | 1-9 |
| | Saving Configuration Settings | 1-11 |
| | Managing System Files | 1-12 |
| | System Defaults | 1-13 |
| | | |
| 2 | Configuring the Switch | 2-1 |
| | Using the Web Interface | 2-1 |
| | Navigating the Web Browser Interface | 2-2 |
| | Home Page | 2-2 |
| | Configuration Options | 2-3 |
| | Panel Display | 2-4 |
| | Main Menu | 2-5 |
| | Basic Configuration | 2-8 |
| | Displaying System Information | 2-8 |
| | Setting the IP Address | 2-10 |
| | Security | 2-13 |
| | Configuring the Logon Password | 2-13 |
| | Configuring Radius Logon Authentication | 2-14 |
| | Managing Firmware | 2-16 |
| | Downloading System Software from a Server | 2-16 |
| | Saving or Restoring Configuration Settings | 2-18 |
| | Setting the Startup Configuration File | 2-19 |
| | Copying the Running Configuration to a File | 2-20 |
| | Displaying Bridge Extension Capabilities | 2-20 |
| | Displaying Switch Hardware/Software Versions | 2-22 |
| | Port Configuration | 2-24 |
| | Displaying Connection Status | 2-24 |

CONTENTS

| | |
|--|------|
| Configuring Interface Connections | 2-26 |
| Setting Broadcast Storm Thresholds | 2-28 |
| Configuring Port Mirroring | 2-29 |
| Address Table Settings | 2-30 |
| Setting Static Addresses | 2-30 |
| Displaying the Address Table | 2-31 |
| Changing the Aging Time | 2-32 |
| Spanning Tree Protocol Configuration | 2-33 |
| Managing Global Settings | 2-33 |
| Displaying the current global settings for STA | 2-35 |
| Configuring the global settings for STA | 2-37 |
| Managing STA Interface Settings | 2-37 |
| VLAN Configuration | 2-41 |
| Assigning Ports to VLANs | 2-42 |
| Forwarding Tagged/Untagged Frames | 2-44 |
| Displaying Basic VLAN Information | 2-44 |
| Displaying Current VLANs | 2-45 |
| Creating VLANs | 2-47 |
| Adding Interfaces Based on Membership Type | 2-48 |
| Adding Interfaces Based on Static Membership | 2-50 |
| Configuring VLAN Behavior for Interfaces | 2-51 |
| Class of Service Configuration | 2-53 |
| Setting the Default Priority for Interfaces | 2-54 |
| Mapping CoS Values to Egress Queues | 2-55 |
| Setting the Service Weight for Traffic Classes | 2-58 |
| Mapping Layer 3/4 Priorities to CoS Values | 2-59 |
| Selecting IP Precedence/DSCP Priority | 2-59 |
| Mapping IP Precedence | 2-60 |
| Mapping DSCP Priority | 2-62 |
| Port Trunk Configuration | 2-64 |
| Dynamically Configuring a Trunk with LACP | 2-65 |
| Statically Configuring a Trunk | 2-66 |
| Configuring SNMP | 2-67 |
| Setting Community Access Strings | 2-67 |
| Specifying Trap Managers | 2-68 |
| Multicast Configuration | 2-69 |
| Configuring IGMP Parameters | 2-70 |

| | |
|---|------------|
| Interfaces Attached to a Multicast Router | 2-72 |
| Displaying Port Members of Multicast Services | 2-75 |
| Adding Multicast Addresses to VLANs | 2-76 |
| Showing Device Statistics | 2-77 |
| 3 Command Line Interface | 3-1 |
| Using the Command Line Interface | 3-1 |
| Accessing the CLI | 3-1 |
| Console Connection | 3-1 |
| Telnet Connection | 3-2 |
| Entering Commands | 3-3 |
| Keywords and Arguments | 3-3 |
| Minimum Abbreviation | 3-4 |
| Command Completion | 3-4 |
| Getting Help on Commands | 3-4 |
| Partial Keyword Lookup | 3-5 |
| Negating the Effect of Commands | 3-6 |
| Using Command History | 3-6 |
| Understanding Command Modes | 3-6 |
| Exec Commands | 3-7 |
| Configuration Commands | 3-8 |
| Command Line Processing | 3-9 |
| Command Groups | 3-10 |
| General Commands | 3-12 |
| enable | 3-12 |
| disable | 3-13 |
| configure | 3-14 |
| show history | 3-15 |
| reload | 3-16 |
| end | 3-16 |
| exit | 3-17 |
| quit | 3-17 |
| Flash/File Commands | 3-18 |
| copy | 3-18 |
| delete | 3-20 |
| dir | 3-21 |
| whichboot | 3-22 |

CONTENTS

| | |
|----------------------------------|------|
| boot system | 3-23 |
| System Management Commands | 3-24 |
| hostname | 3-25 |
| username | 3-26 |
| enable password | 3-27 |
| jumbo frame | 3-28 |
| ip http port | 3-29 |
| ip http server | 3-30 |
| logging on | 3-30 |
| logging history | 3-31 |
| clear logging | 3-33 |
| show logging | 3-33 |
| show startup-config | 3-34 |
| show running-config | 3-36 |
| show system | 3-37 |
| show users | 3-37 |
| show version | 3-38 |
| RADIUS Client Commands | 3-39 |
| authentication login | 3-39 |
| radius-server host | 3-40 |
| radius-server port | 3-41 |
| radius-server key | 3-41 |
| radius-server retransmit | 3-42 |
| radius-server timeout | 3-43 |
| show radius-server | 3-43 |
| SNMP Commands | 3-44 |
| snmp-server community | 3-44 |
| snmp-server contact | 3-45 |
| snmp-server location | 3-46 |
| snmp-server host | 3-46 |
| snmp-server enable traps | 3-48 |
| show snmp | 3-49 |
| IP Commands | 3-50 |
| ip address | 3-51 |
| ip dhcp restart | 3-52 |
| ip default-gateway | 3-53 |
| show ip interface | 3-54 |

| | |
|--|------|
| show ip redirects | 3-55 |
| ping | 3-55 |
| Line Commands | 3-57 |
| line | 3-58 |
| login | 3-59 |
| password | 3-60 |
| exec-timeout | 3-61 |
| password-thresh | 3-62 |
| silent-time | 3-63 |
| databits | 3-64 |
| parity | 3-65 |
| speed | 3-65 |
| stopbits | 3-66 |
| show line | 3-67 |
| Interface Commands | 3-68 |
| interface | 3-69 |
| description | 3-69 |
| speed-duplex | 3-70 |
| negotiation | 3-71 |
| capabilities | 3-72 |
| flowcontrol | 3-73 |
| shutdown | 3-74 |
| switchport broadcast | 3-75 |
| show interfaces status | 3-76 |
| show interfaces counters | 3-77 |
| show interfaces switchport | 3-78 |
| Address Table Commands | 3-79 |
| bridge address | 3-80 |
| show bridge | 3-81 |
| clear bridge | 3-82 |
| bridge-group aging-time | 3-83 |
| show bridge group aging-time | 3-83 |
| Spanning Tree Commands | 3-84 |
| bridge spanning-tree | 3-85 |
| bridge forward-time | 3-86 |
| bridge hello-time | 3-87 |
| bridge max-age | 3-87 |

CONTENTS

| | |
|--|-------|
| bridge priority | 3-88 |
| bridge-group path-cost | 3-89 |
| bridge-group priority | 3-90 |
| bridge-group portfast | 3-91 |
| show bridge group | 3-92 |
| VLAN Commands | 3-94 |
| vlan database | 3-95 |
| vlan | 3-96 |
| interface vlan | 3-97 |
| switchport mode | 3-98 |
| switchport acceptable-frame-types | 3-99 |
| switchport ingress-filtering | 3-100 |
| switchport native vlan | 3-101 |
| switchport allowed vlan | 3-102 |
| switchport forbidden vlan | 3-103 |
| show vlan | 3-104 |
| GVRP and Bridge Extension Commands | 3-105 |
| switchport gvrp | 3-105 |
| show gvrp configuration | 3-106 |
| garp timer | 3-107 |
| show garp timer | 3-108 |
| bridge-ext gvrp | 3-109 |
| show bridge-ext | 3-109 |
| IGMP Snooping Commands | 3-110 |
| ip igmp snooping | 3-111 |
| ip igmp snooping vlan static | 3-112 |
| ip igmp snooping version | 3-113 |
| show ip igmp snooping | 3-113 |
| show bridge multicast | 3-114 |
| ip igmp snooping querier | 3-115 |
| ip igmp snooping query-count | 3-116 |
| ip igmp snooping query-interval | 3-116 |
| ip igmp snooping query-max-response-time | 3-117 |
| ip igmp snooping query-time-out | 3-118 |
| ip igmp snooping vlan mrouter | 3-119 |
| show ip igmp snooping mrouter | 3-120 |
| Priority Commands | 3-121 |

| | |
|---|-------|
| switchport priority default | 3-122 |
| queue bandwidth | 3-123 |
| queue cos-map | 3-124 |
| show queue bandwidth | 3-125 |
| show queue cos-map | 3-126 |
| map ip precedence (Global Configuration) | 3-127 |
| map ip precedence (Interface Configuration) | 3-127 |
| map ip dscp (Global Configuration) | 3-129 |
| map ip dscp (Interface Configuration) | 3-129 |
| show map ip precedence | 3-131 |
| show map ip dscp | 3-132 |
| Mirror Port Commands | 3-133 |
| port monitor | 3-133 |
| show port monitor | 3-134 |
| Port Trunking Commands | 3-135 |
| channel-group | 3-136 |
| lacp | 3-137 |

APPENDICES:

| | | |
|----------|--|------------|
| A | Troubleshooting | A-1 |
| | Troubleshooting Chart | A-1 |
| | Upgrading Firmware via the Serial Port | A-2 |
| B | Pin Assignments | B-1 |
| | Console Port Pin Assignments | B-1 |
| | DB-9 Port Pin Assignments | B-1 |
| | Console Port to 9-Pin DTE Port on PC | B-2 |
| | Console Port to 25-Pin DTE Port on PC | B-2 |

Glossary

Index

CHAPTER 1

SWITCH MANAGEMENT

Connecting to the Switch

Configuration Options

The TigerSwitch 10/100/1000 SMC8624T includes a built-in network management agent. The agent offers a variety of management options, including SNMP, RMON and a Web-based interface. A PC may also be connected directly to the switch for configuration and monitoring via a command line interface (CLI).

Note: The IP address for this switch is assigned via DHCP by default. To change this address, see “Setting an IP Address” on page 1-6.

The switch’s HTTP Web agent allows you to configure switch parameters, monitor port connections, and display statistics graphically using a standard Web browser such as Netscape Navigator version 6.2 and higher or Microsoft IE version 5.0 and higher. The switch’s Web management interface can be accessed from any computer attached to the network.

The switch’s management agent is based on SNMP (Simple Network Management Protocol). This SNMP agent permits the switch to be managed from any system in the network using management software, such as SMC’s free EliteView software.

The CLI program can be accessed by a direct connection to the RS-232 serial console port on the switch, or remotely by a Telnet connection over the network.

The switch's CLI configuration program, Web interface, and SNMP agent allow you to perform the following management functions:

- Set user names and passwords for up to 16 users
- Set an IP interface for a management VLAN
- Configure SNMP parameters
- Enable/disable any port
- Set the speed/duplex mode for any port
- Configure up to 255 IEEE 802.1Q VLANs
- Enable GVRP automatic VLAN registration
- Configure IGMP multicast filtering
- TFTP upload and download of system firmware
- TFTP upload and download of switch configuration files
- Configure Spanning Tree parameters
- Configure Class of Service (CoS) priority queuing
- Configure up to six static or LACP trunks
- Enable jumbo frame support
- Enable port mirroring
- Set broadcast storm control on any port
- Display system information and statistics

Required Connections

The switch provides an RS-232 serial port that enables a connection to a PC or terminal for monitoring and configuring the switch. A null-modem console cable is provided with the switch.

Attach a VT100-compatible terminal, or a PC running a terminal emulation program to the switch. You can use the console cable provided with this package, or use a null-modem cable that complies with the wiring assignments shown in Appendix B.

To connect a terminal to the console port, complete the following steps:

1. Connect the console cable to the serial port on a terminal, or a PC running terminal emulation software, and tighten the captive retaining screws on the DB-9 connector.
2. Connect the other end of the cable to the RS-232 serial port on the switch.
3. Make sure the terminal emulation software is set as follows:
 - Select the appropriate serial port (COM port 1 or COM port 2).
 - Set the data rate to 9600 baud.
 - Set the data format to 8 data bits, 1 stop bit, and no parity.
 - Set flow control to none.
 - Set the emulation mode to VT100.
 - When using HyperTerminal, select Terminal keys, not Windows keys.

Note: When using HyperTerminal with Microsoft® Windows® 2000, make sure that you have Windows 2000 Service Pack 2 or later installed. Windows 2000 Service Pack 2 fixes the problem of arrow keys not functioning in HyperTerminal's VT100 emulation. See www.microsoft.com for information on Windows 2000 service packs.

4. Once you have set up the terminal correctly, the console login screen will be displayed.

Note: Refer to “Line Commands” on page 3-57 for a complete description of console configuration options.

For a description of how to use the CLI, see “Using the Command Line Interface” on page 3-1. For a list of all the CLI commands and detailed information on using the CLI, refer to “Command Groups” on page 3-10.

Remote Connections

Prior to accessing the switch’s onboard agent via a network connection, you must first configure it with a valid IP address, subnet mask, and default gateway using a console connection, DHCP or BOOTP protocol.

The IP address for this switch is assigned via DHCP by default. To manually configure this address or enable dynamic address assignment via DHCP or BOOTP, see “Setting an IP Address” on page 1-6.

Note: This switch supports four concurrent Telnet sessions.

After configuring the switch’s IP parameters, you can access the onboard configuration program from anywhere within the attached network. The onboard configuration program can be accessed using Telnet from any computer attached to the network. The switch can also be managed by any computer using a Web browser (Internet Explorer 5.0 or above, or Netscape Navigator 6.2 or above), or from a network computer using network management software such as EliteView.

Note: The onboard program only provides access to basic configuration functions. To access the full range of SNMP management functions, you must use SNMP-based network management software, such as EliteView.

Basic Configuration

Console Connection

The CLI program provides two different command levels — normal access level (Normal Exec) and privileged access level (Privileged Exec). The commands available at the Normal Exec level are a limited subset of those available at the Privileged Exec level and allow you to only display information and use basic utilities. To fully configure switch parameters, you must access the CLI at the Privileged Exec level.

Access to both CLI levels are controlled by user names and passwords. The switch has a default user name and password for each level. To log into the CLI at the Privileged Exec level using the default user name and password, perform these steps:

1. To initiate your console connection, press <Enter>. The “User Access Verification” procedure starts.
2. At the Username prompt, enter “admin.”
3. At the Password prompt, also enter “admin.” (The password characters are not displayed on the console screen.)
4. The session is opened and the CLI displays the “Console#” prompt indicating you have access at the Privileged Exec level.

Setting Passwords

Note: If this is your first time to log into the CLI program, you should define new passwords for both default user names using the “username” command, record them and put them in a safe place.

Passwords can consist of up to eight alphanumeric characters and are case sensitive. To prevent unauthorized access to the switch, set the passwords as follows:

1. Open the console interface with the default user name and password “admin” to access the Privileged Exec level.
2. Type “configure” and press <Enter>.
3. Type “username guest password 0 *password*,” for the Normal Exec level, where *password* is your new password. Press <Enter>.
4. Type “username admin password 0 *password*,” for the Privileged Exec level, where *password* is your new password. Press <Enter>.

```
Username: admin
Password:
CLI session with the host is opened.
To end the CLI session, enter [Exit].
Console#configure
Console(config)#username guest password 0 [password]
Console(config)#username admin password 0 [password]
Console(config)#
```

Setting an IP Address

You must establish IP address information for the switch to obtain management access through the network. This can be done in either of the following ways:

Manual — You have to input the information, including IP address and subnet mask. If your management station is not in the same IP subnet as the switch, you will also need to specify the default gateway router.

Dynamic — The switch sends IP configuration requests to BOOTP or DHCP address allocation servers on the network.

Note: Only one VLAN interface can be assigned an IP address (the default is VLAN 1). This defines the management VLAN, the only VLAN through which you can gain management access to the switch. If you assign an IP address to any other VLAN, the new IP address overrides the original IP address and this becomes the new management VLAN.

Manual Configuration

You can manually assign an IP address to the switch. You may also need to specify a default gateway that resides between this device and management stations that exist on another network segment. Valid IP addresses consist of four decimal numbers, 0 to 255, separated by periods. Anything outside this format will not be accepted by the CLI program.

Note: The IP address for this switch is assigned via DHCP by default.

Before you can assign an IP address to the switch, you must obtain the following information from your network administrator:

- IP address for the switch
- Default gateway for the network
- Network mask for this network

To assign an IP address to the switch, complete the following steps:

1. From the Privileged Exec level global configuration mode prompt, type “interface vlan 1” to access the interface-configuration mode. Press <Enter>.
2. Type “ip address *ip-address netmask*,” where “ip-address” is the switch IP address and “netmask” is the network mask for the network. Press <Enter>.
3. Type “exit” to return to the global configuration mode prompt. Press <Enter>.

4. To set the IP address of the default gateway for the network to which the switch belongs, type “ip default-gateway *gateway*,” where “gateway” is the IP address of the default gateway. Press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ip address 192.168.1.5 255.255.255.0
Console(config-if)#exit
Console(config)#ip default-gateway 192.168.1.254
Console(config)#
```

Dynamic Configuration

If you select the “bootp” or “dhcp” option, IP will be enabled but will not function until a BOOTP or DHCP reply has been received. You therefore need to use the “ip dhcp restart” command to start broadcasting service requests. Requests will be sent periodically in an effort to obtain IP configuration information. (BOOTP and DHCP values can include the IP address, subnet mask, and default gateway.)

If the “bootp” or “dhcp” option is saved to the startup-config file, then the switch will start broadcasting service requests as soon as it is powered on.

To automatically configure the switch by communicating with BOOTP or DHCP address allocation servers on the network, complete the following steps:

1. From the Privileged Exec level global configuration mode prompt, type “interface vlan 1” to access the interface-configuration mode. Press <Enter>.
2. At the interface-configuration mode prompt, use one of the following commands:
 - To obtain IP settings through DHCP, type “ip address dhcp” and press <Enter>.
 - To obtain IP settings through BOOTP, type “ip address bootp” and press <Enter>.

3. Type “exit” to return to the global configuration mode. Press <Enter>.
4. Type “ip dhcp restart” to begin broadcasting service requests. Press <Enter>.
5. Wait a few minutes, and then check the IP configuration settings, by typing the “show ip interface” command. Press <Enter>.
6. Then save your configuration changes by typing “copy running-config startup-config.” Enter the startup file name and press <Enter>.

```
Console(config)#interface vlan 1
Console(config-if)#ip address dhcp
Console(config-if)#exit
Console#ip dhcp restart
Console#show ip interface
IP interface vlan
  IP address and netmask: 10.1.0.54 255.255.255.0 on VLAN 1,
  and address mode: User specified.
Console#copy running-config startup-config
Startup configuration file name []: startup
Console#
```

Enabling SNMP Management Access

The switch can be configured to accept management commands from Simple Network Management Protocol (SNMP) applications such as EliteView. You can configure the switch to (1) respond to SNMP requests or (2) generate SNMP traps.

When SNMP management stations send requests to the switch (either to return information or to set a parameter), the switch provides the requested data or sets the specified parameter. The switch can also be configured to send information to SNMP managers (without being requested by the managers) through trap messages, which inform the manager that certain events have occurred.

Community Strings

Community strings are used to control management access to SNMP stations, as well as to authorize SNMP stations to receive trap messages from the switch. You therefore need to assign community strings to specified users or user groups, and set the access level.

The default strings are:

- **public** - with read-only access. Authorized management stations are only able to retrieve MIB objects.
- **private** - with read-write access. Authorized management stations are able to both retrieve and modify MIB objects.

Note: If you do not intend to utilize SNMP, it is recommended that you delete both of the default community strings. If there are no community strings, then SNMP management access to the switch is disabled.

To prevent unauthorized access to the switch via SNMP, it is recommended that you change the default community strings.

To configure a community string, complete the following steps:

1. From the Privileged Exec level global configuration mode prompt, type “snmp-server community *string mode*,” where “string” is the community access string and “mode” is **rw** (read/write) or **ro** (read only). Press <Enter>.
2. To remove an existing string, simply type “no snmp-server community *string*,” where “string” is the community access string to remove. Press <Enter>.

```
Console(config)#snmp-server community smc rw
Console(config)#snmp-server community private
Console(config)#
```


Trap Receivers

You can also specify SNMP stations that are to receive traps from the switch.

To configure a trap receiver, complete the following steps:

1. From the Privileged Exec level global configuration mode prompt, type “snmp-server host *host-address community-string*,” where “host-address” is the IP address for the trap receiver and “community-string” is the string associated with that host. Press <Enter>.
2. In order to configure the switch to send SNMP notifications, you must enter at least one snmp-server enable traps command. Type “snmp-server enable traps *type*,” where “type” is either **authentication** or **link-up-down**. Press <Enter>.

```
Console(config)#snmp-server enable traps link-up-down
Console(config)#
```

Saving Configuration Settings

Configuration commands only modify the running configuration file and are not saved when the switch is rebooted. To save all your configuration changes in nonvolatile storage, you must copy the running configuration file to the start-up configuration file using the “copy” command.

To save the current configuration settings, enter the following command:

1. From the Privileged Exec mode prompt, type “copy running-config startup-config” and press <Enter>.
2. Enter the name of the start-up file. Press <Enter>.

```
Console#copy running-config startup-config
Startup configuration file name []: startup
Console#
```

Managing System Files

The switch's flash memory supports three types of system files that can be managed by the CLI program, Web interface, or SNMP. The switch's file system allows files to be uploaded and downloaded, copied, deleted, and set as a start-up file.

The three types of files are:

- **Configuration** — These files store system configuration information and are created when configuration settings are saved. Saved configuration files can be selected as a system start-up file or can be uploaded via TFTP to a server for backup. A file named “Factory_Default_Config.cfg” contains all the system default settings and cannot be deleted from the system. See “Saving or Restoring Configuration Settings” on page 2-18 for more information.
- **Operation Code** — System software that is executed after boot-up, also known as run-time code. This code runs the switch operation and provides the CLI, Web and SNMP management interfaces. See “Managing Firmware” on page 2-16 for more information.
- **Diagnostic Code** — Software that is run during system boot-up, also known as POST (Power On Self-Test). This code also provides a facility to upload firmware files to the system directly through the console port. See “Upgrading Firmware via the Serial Port” on page A-2.

Due to the size limit of the flash memory, the switch supports only two operation code files. However, you can have as many diagnostic code files and configuration files as available flash memory space allows.

In the system flash memory, one file of each type must be set as the start-up file. During a system boot, the diagnostic and operation code files set as the start-up file are run, and then the start-up configuration file is loaded. Configuration files can also be loaded while the system is running, without rebooting the system.

System Defaults

The switch's system defaults are provided in the configuration file "Factory_Default_Config.cfg." To reset the switch defaults, this file should be set as the startup configuration file. See "Setting the Startup Configuration File" on page 2-19.

The following table lists some of the basic system defaults.

| Function | Parameter | Default |
|----------------|---|--|
| IP Settings | Management VLAN | 1 |
| | DHCP | Enabled |
| | BOOTP | Disabled |
| | User Specified | Disabled |
| | IP Address | 0.0.0.0 |
| | Subnet Mask | 255.0.0.0 |
| | Default Gateway | 0.0.0.0 |
| Web Management | HTTP Server | Enabled |
| | HTTP Port Number | 80 |
| SNMP | Community Strings | "public" (read only) "private" (read/write) |
| | Authentication Failure Traps | Enabled |
| | Link-up-Down Traps | Enabled |
| Security | Privileged Exec Level | Username "admin" Password "admin" |
| | Normal Exec Level | Username "guest" Password "guest" |
| | Enable Privileged Exec from Normal Exec Level | Password "super" |
| | RADIUS Authentication | Disabled |

| Function | Parameter | Default |
|-------------------------|----------------------------------|---|
| Console Port Connection | Baud Rate | 9600 |
| | Data bits | 8 |
| | Stop bits | 1 |
| | Parity | none |
| | Local Console Timeout | 0 (disabled) |
| Port Status | Admin Status | Enabled |
| | Auto-negotiation | Enabled |
| | Flow Control | Disabled |
| | 10/100/1000 Mbps Port Capability | 10 Mbps half duplex 10 Mbps full duplex 100 Mbps half duplex 100 Mbps full duplex 1000 Mbps full duplex Full-duplex flow control disabled Symmetric flow control disabled |
| Link Aggregation | Static Trunks | none |
| | LACP (all ports) | Disabled |
| Spanning Tree Protocol | Status | Enabled (Defaults: All parameters based on IEEE 802.1D) |
| | Fast Forwarding | Disabled |
| Address Table | Aging Time | 300 seconds |
| Virtual LANs | Default VLAN | 1 |
| | PVID | 1 |
| | Acceptable Frame Type | All |
| | Ingress Filtering | Disabled |
| | GVRP (global) | Disabled |
| | GVRP (port interface) | Disabled |

| Function | Parameter | Default |
|----------------------------|--------------------------|--|
| Class of Service | Ingress Port Priority | 0 |
| | Weighted Round Robin | Class 0: 16 Class 1: 64 Class 2: 128 Class 3: 240 |
| | IP Precedence Priority | Disabled |
| | IP DSCP Priority | Disabled |
| Multicast Filtering | IGMP Snooping | Enabled |
| | Act as Querier | Enabled |
| Broadcast Storm Protection | Status | Enabled (all ports) |
| | Broadcast Limit Rate | 256 packets per second |
| System Log | Status | Enabled |
| | Messages Logged | Levels 0-7 (all) |
| | Messages Logged to Flash | Levels 0-3 |
| Jumbo Frames | Status | Disabled |

CHAPTER 2

CONFIGURING THE SWITCH

Using the Web Interface

This switch provides an embedded HTTP Web agent. Using a Web browser you can configure the switch and view statistics to monitor network activity. The Web agent can be accessed by any computer on the network using a standard Web browser (Internet Explorer 5.0 or above, or Netscape Navigator 6.2 or above).

Note: You can also use the Command Line Interface (CLI) to manage the switch over a serial connection to the console port or via Telnet. For more information on using the CLI, refer to Chapter 3 “Command Line Interface.”

Prior to accessing the switch from a Web browser, be sure you have first performed the following tasks:

1. Configure the switch with a valid IP address, subnet mask, and default gateway using an out-of-band serial connection, BOOTP or DHCP protocol (see “Setting the IP Address” on page 2-10).
2. Set user names and passwords using an out-of-band serial connection. Access to the Web agent is controlled by the same user names and passwords as the onboard configuration program. (See “Configuring the Logon Password” on page 2-13.)

Note: If you log into the Web interface as guest (Normal Exec level), you can view page information but only change the guest password. If you log in as “admin” (Privileged Exec level), you can apply changes on all pages.

3. After you enter a user name and password, you will have access to the system configuration program.


- Notes:**
1. You are allowed three attempts to enter the correct password; on the third failed attempt the current connection is terminated.
 2. If the path between your management station and this switch does not pass through any device that uses the Spanning Tree Algorithm, then you can set the switch port attached to your management station to fast forwarding to improve the switch's response time to management commands issued through the Web interface. See "Managing STA Interface Settings" on page 2-37.

Navigating the Web Browser Interface

To access the Web-browser interface you must first enter a user name and password. The administrator has Read/Write access to all configuration parameters and statistics. The default user name and password for the administrator is "admin."

Home Page

When your Web browser connects with the switch's Web agent, the home page is displayed as shown below. The home page displays the Main Menu on the left side of the screen and System Information on the right side. The Main Menu links are used to navigate to other menus, and display configuration parameters and statistics.



Configuration Options


Configurable parameters have a dialog box or a drop-down list. Once a configuration change has been made on a page, be sure to click on the “Apply” or “Apply Changes” button to confirm the new setting. The following table summarizes the Web page configuration buttons.

| Button | Action |
|---------------|--|
| Revert | Cancels specified values and restores current values prior to pressing “Apply” or “Apply Changes.” |
| Refresh | Immediately updates values for the current page. |
| Apply | Sets specified values to the system. |
| Apply Changes | Sets specified values to the system. |

- Notes:**
1. To ensure proper screen refresh, be sure that Internet Explorer 5.x is configured as follows: Under the menu “Tools / Internet Options / General / Temporary Internet Files / Settings,” the setting for item “Check for newer versions of stored pages” should be “Every visit to the page.”
 2. When using Internet Explorer 5.0, you may have to manually refresh the screen after making configuration changes by pressing the browser’s refresh button.

Panel Display

The Web agent displays an image of the switch’s ports, indicating whether each link is up or down. Clicking on the image of a port opens the Port Configuration page as described on page 2-26.



Main Menu

Using the onboard Web agent, you can define system parameters, manage and control the switch, and all its ports, or monitor network conditions. The following table briefly describes the selections available from this program.

| Menu | Description | Page |
|---------------------------------------|--|------|
| <i>System</i> | | |
| System Information | Provides basic system description, including contact information | 2-8 |
| IP | Sets the IP address for management access | 2-10 |
| Passwords | Assigns a new password for the logon user name | 2-13 |
| Radius | Configures RADIUS authentication parameters | 2-14 |
| Firmware | Manages code image files | 2-16 |
| Configuration | Manages switch configuration files | 2-18 |
| Reset | Restarts the switch | |
| Bridge Extension | Shows the configuration for bridge extension commands; enables GVRP multicast protocol | 2-20 |
| Switch Information | Shows the number of ports, hardware/firmware version numbers, and power status | 2-22 |
| <i>Port</i> | | |
| Port Information | Displays port connection status | 2-24 |
| Trunk Information | Displays trunk connection status | 2-24 |
| Port Configuration | Configures port connection settings | 2-26 |
| Trunk Configuration | Configures trunk connection settings | 2-26 |
| Broadcast Storm Protect Configuration | Sets the broadcast storm threshold for each port | 2-28 |
| Mirror | Sets the source and target ports for mirroring | 2-29 |

| Menu | Description | Page |
|--------------------------------|---|------|
| <i>Address Table</i> | | |
| Static Addresses | Displays entries for interface, address or VLAN | 2-30 |
| Dynamic Addresses | Displays or edits static entries in the Address Table | 2-31 |
| Address Aging | Sets timeout for dynamically learned entries | 2-32 |
| <i>Spanning Tree</i> | | |
| STA Information | Displays STA values used for the bridge | 2-35 |
| STA Configuration | Configures global bridge settings for STA | 2-37 |
| STA Port Information | Configures individual port settings for STA | 2-37 |
| STA Trunk Information | Configures individual trunk settings for STA | 2-37 |
| STA Port Configuration | Configures individual port settings for STA | 2-37 |
| STA Trunk Configuration | Configures individual trunk settings for STA | 2-37 |
| <i>VLAN</i> | | |
| VLAN Basic Information | Displays basic information on the VLAN type supported by this switch | 2-44 |
| VLAN Current Table | Shows the current port members of each VLAN and whether or not the port supports VLAN tagging | 2-45 |
| VLAN Static List | Used to create or remove VLAN groups | 2-47 |
| VLAN Static Table | Modifies the settings for an existing VLAN | 2-48 |
| VLAN Static Membership by Port | Configures membership type for interfaces, including tagged, untagged or forbidden | 2-50 |
| VLAN Port Configuration | Specifies default PVID and VLAN attributes | 2-51 |
| VLAN Trunk Configuration | Specifies default trunk VID and VLAN attributes | 2-51 |

| Menu | Description | Page |
|--|---|------|
| <i>Priority</i> | | |
| Default Port Priority | Sets the default priority for each port | 2-54 |
| Default Trunk Priority | Sets the default priority for each trunk | 2-54 |
| Traffic Class | Maps IEEE 802.1p priority tags to output queues | 2-55 |
| Queue Scheduling | Configures Weighted Round Robin queueing | 2-58 |
| IP Precedence/DSCP Priority Status | Globally selects IP Precedence or DSCP Priority, or disables both. | 2-59 |
| IP Precedence Priority | Sets IP Type of Service priority, mapping the precedence tag to a class-of-service value | 2-60 |
| IP DSCP Priority | Sets IP Differentiated Services Code Point priority, mapping a DSCP tag to a class-of-service value | 2-62 |
| <i>Trunk</i> | | |
| LACP Configuration | Allows ports to dynamically join trunks | 2-65 |
| Trunk Configuration | Specifies ports to group into static trunks | 2-66 |
| SNMP | Configures community strings and related trap functions. | 2-67 |
| <i>IGMP</i> | | |
| IGMP Configuration | Enables multicast filtering; configures parameters for multicast query | 2-70 |
| Multicast Router Port Information | Displays the ports that are attached to a neighboring multicast router/switch for each VLAN ID | 2-73 |
| Static Multicast Router Port Configuration | Assigns ports that are attached to a neighboring multicast router/switch | 2-73 |
| IP Multicast Registration Table | Displays all multicast groups active on this switch, including multicast IP addresses and VLAN ID | 2-76 |

| Menu | Description | Page |
|------------------------|---|------|
| IGMP Member Port Table | Indicates multicast addresses associated with the selected VLAN | 2-75 |
| Statistics | Lists Ethernet and RMON port statistics | 2-77 |

Basic Configuration

Displaying System Information

You can easily identify the system by providing a descriptive name, location and contact information.

Command Attributes

- **System Name** – Name assigned to the switch system.
- **Object ID** – MIB II object ID for switch's network management subsystem.
- **Location** – Specifies the system location.
- **Contact** – Administrator responsible for the system.

System Up Time – Length of time the management agent has been up.

Web – Click System/System Information. Specify the system name, location, and contact information for the system administrator, then click Apply. (This page also includes a Telnet button that allows you to access the Command Line Interface via Telnet.)

| | |
|-----------------------|--|
| System Name | SMC8624T Test Switch |
| Object ID | 1.3.6.1.4.1.202.20.25 |
| Location | TPS - 3rd Floor |
| Contact | Chris |
| System Up Time | 0 days, 0 hours, 28 minutes, and 30.16 seconds |

Telnet - Connect to textual user interface

Support - Send mail to technical support

Contact - Connect to SMC Web Page

CLI – Specify the hostname, location and contact information.

```

Console(config)#hostname SMC8624T Test Switch          3-25
Console(config)#snmp-server location TPS - 3rd Floor   3-46
Console(config)#snmp-server contact Chris              3-45
Console#show system                                    3-37
System description: SMC TigerSwitch - SMC8624T
System OID string: 1.3.6.1.4.1.202.20.24
System information
  System Up time: 0 days, 2 hours, 4 minutes, and 7.13 seconds
  System Name      : SMC8624T Test Switch
  System Location   : TPS - 3rd Floor
  System Contact    : Chris
  MAC address       : 00-30-f1-47-58-3a
  Web server        : enable
  Web server port   : 80
  POST result       :
UART Loopback Test.....PASS
Timer Test.....PASS
DRAM Test .....PASS
I2C Initialization.....PASS
Runtime Image Check .....PASS
PCI Device Check .....PASS
Switch Driver Initialization.....PASS
Switch Internal Loopback Test.....PASS
----- DONE -----
Console#
  
```

Setting the IP Address

An IP address may be used for management access to the switch over your network. By default, the switch uses DHCP to assign IP settings to VLAN 1 on the switch. If you wish to manually configure IP settings, you need to change the switch's user-specified defaults (IP address 0.0.0.0 and netmask 255.0.0.0) to values that are compatible with your network. You may also need to establish a default gateway between the switch and management stations that exist on another network segment.

You can manually configure a specific IP address, or direct the device to obtain an address from a BOOTP or DHCP server when it is powered on. Valid IP addresses consist of four decimal numbers, 0 to 255, separated by periods. Anything outside this format will not be accepted by the CLI program.

- **Management VLAN** – This is the only VLAN through which you can gain management access to the switch. By default, all ports on the switch are members of VLAN 1, so a management station can be connected to any port on the switch. However, if other VLANs are configured and you change the Management VLAN, you may lose management access to the switch. In this case, you should reconnect the management station to a port that is a member of the Management VLAN.
- **IP Address Mode** – Specifies whether IP functionality is enabled via manual configuration (Static), Dynamic Host Configuration Protocol (DHCP), or Boot Protocol (BOOTP). If DHCP/BOOTP is enabled, IP will not function until a reply has been received from the server. Requests will be broadcast periodically by the switch for an IP address. (DHCP/BOOTP values can include the IP address, subnet mask, and default gateway.)
- **IP Address** – Address of the VLAN interface that is allowed management access. Valid IP addresses consist of four numbers, 0 to 255, separated by periods.

- **Subnet Mask** – This mask identifies the host address bits used for routing to specific subnets.
- **Gateway IP Address** – IP address of the gateway router between this device and management stations that exist on other network segments.
- **MAC Address** – The MAC address of this switch.

Manual Configuration

Web – Click System/IP. Specify the management interface, IP address and default gateway, then click Apply.

| | |
|--------------------|-------------------|
| Management VLAN | 1 |
| IP Address Mode | Static |
| IP Address | 10.1.0.1 |
| Subnet Mask | 255.255.255.0 |
| Gateway IP Address | 0.0.0.0 |
| MAC Address | 00-30-F1-47-58-3A |

Restart DHCP

CLI – Specify the management interface, IP address and default gateway.

```

Console#config
Console(config)#interface vlan 1
Console(config-if)#ip address 10.2.13.30 255.255.255.0
Console(config-if)#exit
Console(config)#ip default-gateway 192.168.1.254
Console(config)#
  
```

Using DHCP/BOOTP

If your network provides DHCP/BOOTP services, you can configure the switch to be dynamically configured by these services.

Web – Click System/IP. Specify the Management VLAN, set the IP Address Mode to DHCP or BOOTP. Then click “Apply” to save your changes. The switch will broadcast a request for IP configuration settings on the next power reset. Otherwise, you can click “Restart DHCP” to immediately request a new address.

If you lose your management connection, use a console connection and enter “show ip interface” to determine the new switch address.

CLI – Specify the management interface, and set the IP Address Mode to DHCP or BOOTP.

```
Console#config
Console(config)#interface vlan 1 3-69
Console(config-if)#ip address dhcp 3-51
Console(config-if)#end
Console#ip dhcp restart 3-52
Console#show ip interface 3-54
IP address and netmask: 10.1.0.54 255.255.255.0 on VLAN 1,
and address mode: User specified.
Console#
```

Renewing DHCP – DHCP may lease addresses to clients indefinitely or for a specific period of time. If the address expires or the switch is moved to another network segment, you will lose management access to the switch. In this case, you can reboot the switch or submit a client request to restart DHCP service.

Web – If the address assigned by DHCP is no longer functioning, you will not be able to renew the IP settings via the Web interface. You can only restart DHCP service via the Web interface if the current address is still available.

CLI – Enter the following command to restart DHCP service.

```
Console#ip dhcp restart 3-52
```

Security

Configuring the Logon Password

The guest only has read access for most configuration parameters. However, the administrator has write access for parameters governing the onboard agent. You should therefore assign a new administrator password as soon as possible, and store it in a safe place.

- Notes:**
1. If you log into the Web interface as guest (Normal Exec level), you can view page information but only change the guest password. If you log in as admin (Privileged Exec level), you can apply changes on all pages.
 2. If for some reason your password is lost, you can reload the factory defaults file or reinstall runtime code to restore the default passwords. See “Upgrading Firmware via the Serial Port” on page A-2 for more information.

The default guest name is “guest” with the password “guest.” The default administrator name is “admin” with the password “admin.” Note that user names can only be assigned via the CLI.

Web – Click System/Passwords. Enter the old password, enter the new password, confirm it by entering it again, then click “Apply.”

| | |
|------------------|----------------------|
| Old Password | <input type="text"/> |
| New Password | <input type="text"/> |
| Confirm Password | <input type="text"/> |

CLI – Assign a user name to access-level 15 (i.e., administrator), then specify the password.

```
Console(config)#username bob access-level 15
Console(config)#username bob password 0 smith
Console(config)#
```

3-26

Configuring Radius Logon Authentication

Remote Authentication Dial-in User Service (RADIUS) is an authentication protocol that uses a central server to control access to RADIUS-compliant devices on the network. A RADIUS server can be programmed with a database of multiple user name/password pairs and associated privilege levels for each user or group that requires management access to this switch using the console port, Telnet or the Web.

When setting up privilege levels on the RADIUS server, level 0 allows guest (CLI - Normal Exec) access to the switch. Only level 15 allows administrator (CLI - Privileged Exec) access.

Command Attributes

- **Authentication** – Select the authentication, or authentication sequence required:
 - **Radius** – User authentication is performed using a RADIUS server only.
 - **Local** – User authentication is performed only locally by the switch.
 - **Radius, Local** – User authentication is attempted first using a RADIUS server, then locally by the switch.
 - **Local, Radius** – User authentication is first attempted locally by the switch, then using a RADIUS server.
- **Server IP Address** – The IP address of the RADIUS server.
- **Server Port Number** – The UDP port number used by the RADIUS server.
- **Secret Text String** – The text string that is shared between the switch and the RADIUS server.
- **Number of Server Transmits** – The number of request transmits to the RADIUS server before failure.

- **Timeout for a reply** – The number of seconds the switch waits for a reply from the RADIUS server before it resends the request.

Note: The local switch user database has to be set up by manually entering user names and passwords using the CLI.

Web – Click System/Radius. Specify the authentication sequence, server address, port number and other parameters, then click “Apply.”

| | |
|----------------------------|----------|
| Authentication | Local ▾ |
| Server IP Address | 10.1.0.1 |
| Server Port Number | 1812 |
| Secret Text String | |
| Number of Server Transmits | 2 |
| Timeout for a reply (sec) | 5 |

CLI Commands

CLI – Specify all the required parameters to enable logon authentication.

```

Console(config)#authentication login radius          3-39
Console(config)#radius-server host 192.168.1.25      3-40
Console(config)#radius-server port 181              3-41
Console(config)#radius-server key green             3-41
Console(config)#radius-server retransmit 5          3-42
Console(config)#radius-server timeout 10            3-43
Console#show radius-server                          3-43
Server IP address: 192.168.1.25
Communication key with radius server:
Server port number: 181
Retransmit times: 5
Request timeout: 10
Console(config)#

```

Managing Firmware

You can upload/download firmware to or from a TFTP server. By saving runtime code to a file on a TFTP server, that file can later be downloaded to the switch to restore operation. You can also set the switch to use new firmware without overwriting the previous version.

Command Attributes

- **TFTP Server IP Address** – The IP address of a TFTP server.
- **Destination File Name** — The destination file name should not contain slashes (\ or /), the leading letter of the file name should not be a period (.), and the length of file name should be 1 to 31 characters. (Valid characters: A-Z, a-z, 0-9, “.”, “-”, “_”)
- The maximum number of runtime code files is 2.

Downloading System Software from a Server

When downloading runtime code, you can specify the Destination File Name to replace the current image, or first download the file using a different name from the current runtime code file, and then set the new file as the startup file.

Web – Click System/Firmware. Enter the IP address of the TFTP server, enter the file name of the software to download, select a file on the switch to overwrite or specify a new file name, then click “Transfer from Server.”

Transfer Operation Code Image File from Server

| | | |
|--------------------------------|--|--|
| Current Operation Code Version | 1.0.1.1 | |
| TFTP Server IP Address | <input type="text" value="0.0.0.0"/> | |
| Source File Name | <input type="text"/> | |
| Destination File Name | <input type="radio"/> <input type="text" value="run_v1011"/> | <input type="radio"/> <input type="text"/> |

Transfer from Server

If you download specifying a new destination file name, be sure to select the new file from the drop-down box, and then click “Apply Changes.”

Start-Up Operation Code Image File

File Name

Apply Changes

To start the new firmware, reboot the system.

CLI – Enter the IP address of the TFTP server, select “config” or “opcode” file type, then enter the source and destination file names, set the new file to start up the system, and then restart the switch.

| | |
|--|------|
| Console#copy tftp file | 3-18 |
| TFTP server ip address: 10.1.0.99 | |
| Choose file type: | |
| 1. config: 2. opcode: <1-2>: 2 | |
| Source file name: v10.bix | |
| Destination file name: V10000 | |
| / | |
| Console#config | |
| Console(config)#boot system opcode: V10000 | 3-23 |
| Console(config)#exit | |
| Console#reload | 3-16 |

To start the new firmware, enter the “reload” command or reboot the system.

Saving or Restoring Configuration Settings

You can upload/download configuration settings to/from a TFTP server. The configuration file can be later downloaded to restore the switch's settings.

Command Attributes

- **Destination File Name** — The destination configuration file name should not contain slashes (\ or /), the leading letter of the file name should not be a period (.), and the length of file name should be 1 to 31 characters. (Valid characters: A-Z, a-z, 0-9, ".", "-", "_")
- The maximum number of user-defined configuration files is limited only by available Flash memory space.

You can save the configuration file under a new file name and then set it as the startup file, or you can specify the current startup configuration file as the destination file to directly replace it. Note that the file "Factory_Default_Config.cfg" can be copied to the TFTP server, but cannot be used as a destination file name on the switch.

Web – Click System/Configuration. Enter the IP address of the TFTP server, enter the name of the file to download, select a file on the switch to overwrite or specify a new file name, and then click "Transfer from Server."

Transfer Configuration File from Server

| | | |
|------------------------|--|--|
| TFTP Server IP Address | <input type="text" value="0.0.0.0"/> | |
| Source File Name | <input type="text"/> | |
| Destination File Name | <input checked="" type="radio"/> startup-set-ip.cfg <input type="radio"/> <input type="text"/> | |

CLI – Enter the IP address of the TFTP server, specify the source file on the server, set the startup file name on the switch, and then restart the switch.

```

Console#copy tftp startup-config
TFTP server ip address: 192.168.1.19
Source configuration file name: startup2.0
Startup configuration file name [startup] : startup2.0
/
Console#

```

3-18

Setting the Startup Configuration File

If you download to a new file name, then select the new file from the drop-down box, and click “Apply Changes.”

Start-Up Configuration File

| | |
|-----------|--------------------|
| File Name | startup-set-ip.cfg |
|-----------|--------------------|

Apply Changes

To use the new settings, reboot the system.

CLI – Enter the IP address of the TFTP server, specify the source file on the server, set the startup file name on the switch, and then restart the switch.

```

Console#copy tftp startup-config
TFTP server ip address: 192.168.1.19
Source configuration file name: startup2.0
Startup configuration file name [startup] : startup2.0
/
Console#
Console#config
Console(config)#boot system config: startup2.0
Console(config)#exit
Console#reload

```

3-18

3-23

Note: The CLI allows you replace a running configuration file without performing a reset.

Copying the Running Configuration to a File

CLI – If you copy the running configuration to a file, you can set this file as the startup file at a later time, and then restart the switch.

| | |
|--|------|
| Console#copy running-config file | 3-18 |
| destination file name : 051902.cfg | |
| / | |
| Console# | |
| Console#config | |
| Console(config)#boot system config: 051902.cfg | 3-23 |
| Console(config)#exit | |
| Console#reload | 3-16 |

Displaying Bridge Extension Capabilities

The Bridge MIB includes extensions for managed devices that support Multicast Filtering, Traffic Classes, and Virtual LANs. You can access these extensions to display default settings for the key variables, or to configure the global setting for GARP VLAN Registration Protocol (GVRP).

Command Attributes

- **Extended Multicast Filtering Services** – This switch does not support the filtering of individual multicast addresses based on GMRP (GARP Multicast Registration Protocol).
- **Traffic Classes** – This switch provides mapping of user priorities to multiple traffic classes. (Refer to “Class of Service Configuration” on page 2-53.)
- **Static Entry Individual Port** – This switch allows static filtering for unicast and multicast addresses. (Refer to “Setting Static Addresses” on page 2-30.)
- **VLAN Learning** – This switch uses Independent VLAN Learning (IVL), where each port maintains its own filtering database.

- **Configurable PVID Tagging** – This switch allows you to override the default Port VLAN ID (PVID used in frame tags) and egress status (VLAN-Tagged or Untagged) on each port. (Refer to “VLAN Configuration” on page 2-41.)
- **Local VLAN Capable** – This switch does not support multiple local bridges (i.e., multiple Spanning Trees).
- **GMRP** – GARP Multicast Registration Protocol (GMRP) allows network devices to register endstations with multicast groups. This switch does not support GMRP; it uses the Internet Group Management Protocol (IGMP) to provide automatic multicast filtering.
- **GVRP** – GARP VLAN Registration Protocol (GVRP) defines a way for switches to exchange VLAN information in order to register necessary VLAN members on ports across the network. This function should be enabled to permit VLANs groups which extend beyond the local switch.

Web – Click System/Bridge Extension.

Bridge Capability

| | |
|---------------------------------------|---------|
| Extended Multicast Filtering Services | No |
| Traffic Classes | Enabled |
| Static Entry Individual Port | Yes |
| VLAN Learning | IVL |
| Configurable PVID Tagging | Yes |
| Local VLAN Capable | No |

| | |
|-----------------|--|
| Traffic Classes | <input checked="" type="checkbox"/> Enable |
| GMRP | <input type="checkbox"/> Enable |
| GVRP | <input type="checkbox"/> Enable |

CLI – Enter the following command.

```
Console#show bridge-ext                                     3-109
Max support vlan numbers: 255
Max support vlan ID: 4094
Extended multicast filtering services: No
Static entry individual port: Yes
VLAN learning: IVL
Configurable PVID tagging: Yes
Local VLAN capable: No
Traffic classes: Enabled
Global GVRP status: Enabled
GMRP: Disabled
Console#
```

Displaying Switch Hardware/Software Versions

Command Attributes

Main Board

- **Serial Number** – The serial number of the switch
- **Number of Ports** – Number of ports on this switch
- **Hardware Version** – Hardware version of the main board.
- **Internal Power Status** – Displays the status of the internal power supply
- **Loader Version** – Version number of loader code.
- **Boot-ROM Version** – Version number of boot code.
- **Operation Code Version** – Version number of runtime code.
- **Role** – Shows that this switch is Master (i.e., operating stand-alone).

Web – Click System/Switch Information.

Main Board:

| | |
|-----------------------|------------|
| Serial Number | A217056372 |
| Number of Ports | 24 |
| Hardware Version | R0C |
| Internal Power Status | Active |

Management Software:

| | |
|------------------------|---------|
| Loader Version | 1.0.0.0 |
| Boot-ROM Version | 1.0.0.0 |
| Operation Code Version | 1.0.1.4 |
| Role | Master |

CLI – Use the following command to display version information.

```

Console#show version
Unit1
  Serial number      :A217056372
  Service tag       :[NONE]
  Hardware version   :R0C
  Number of ports    :24
  Main power status  :up
  Redundant power status :not present
Agent(master)
  Unit id           :1
  Loader version    :1.0.0.0
  Boot rom version  :1.0.0.0
  Operation code version :1.0.1.4
Console#
  
```

Port Configuration

Displaying Connection Status

You can use the Port Information or Trunk Information pages to display the current connection status, including link state, speed/duplex mode, flow control, and auto-negotiation.

Command Attributes

- **Name** – Interface label.
- **Type** – Indicates the of port type (1000Base-TX or 1000Base-SFP).
- **Admin Status** – Shows if the interface is enabled or disabled.
- **Oper Status** – Indicates if the link is Up or Down.
- **Speed/Duplex Status** – Shows the current speed and duplex mode.
- **Flow Control Status** – Indicates the type of flow control currently in use.
- **Autonegotiation** – Shows if auto-negotiation is enabled or disabled.
- **Trunk Member** – Shows if port is a trunk member. (Port Information only)
- **Creation** – Shows if a trunk is manually configured. (Trunk Information only)

Web – Click Port/Port Information or Trunk Information. Modify the required interface settings, and click “Apply.”

| Port | Name | Type | Admin Status | Oper Status | Speed Duplex Status | Flow Control Status | Autonegotiation | Trunk Member |
|------|------|-------------|--------------|-------------|---------------------|---------------------|-----------------|--------------|
| 1 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |
| 2 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |
| 3 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |
| 4 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |
| 5 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |
| 6 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |
| 7 | | 1000Base-TX | Enabled | Up | 100full | None | Enabled | |
| 8 | | 1000Base-TX | Enabled | Down | 1000full | None | Enabled | |

CLI – This example shows the connection status for Port 13.

```

Console#show interfaces status ethernet 1/13
Information of Eth 1/13
Basic information:
  Port type: 1000t
  Mac address: 00-00-11-11-22-2F
Configuration:
  Name:
  Port admin: Up
  Speed-duplex: Auto
  Capabilities: 10half, 10full, 100half, 100full, 1000full,
  Broadcast storm: Enabled
  Broadcast storm limit: 256 packets/second
  Flow control: Disabled
  Lacp: Disabled
Current status:
  Link status: Down
  Operation speed-duplex: 1000full
  Flow control type: None
Console#

```

Configuring Interface Connections

You can use the Trunk Configuration or Port Configuration page to enable/disable an interface, manually fix the speed and duplex mode, set flow control, set auto-negotiation, and set the interface capabilities to advertise.

Command Attributes

- **Name** – Allows you to label an interface. (Range: 1-64 characters)
- **Admin** – Allows you to manually disable an interface. You can disable an interface due to abnormal behavior (e.g., excessive collisions), and then reenable it after the problem has been resolved. You may also disable an interface for security reasons.
- **Speed/Duplex** – Allows manual selection of port speed and duplex mode (i.e., with auto-negotiation disabled).
- **Flow Control** – Allows automatic or manual selection of flow control.
 - Flow control can eliminate frame loss by “blocking” traffic from end stations or segments connected directly to the switch when its buffers fill. When enabled, back pressure is used for half-duplex operation and IEEE 802.3x for full-duplex operation.
 - Flow control should not be used if a port is connected to a hub. Otherwise flow control signals will be propagated throughout the segment.
- **Autonegotiation/Port Capabilities** – Allows auto-negotiation to be enabled/disabled. Specifies the capabilities to be advertised for a port during auto-negotiation. The following capabilities are supported.
 - **10half** - Supports 10 Mbps half-duplex operation
 - **10full** - Supports 10 Mbps full-duplex operation
 - **100half** - Supports 100 Mbps half-duplex operation
 - **100full** - Supports 100 Mbps full-duplex operation
 - **1000full** - Supports 1000 Mbps full-duplex operation
 - **Sym** - Transmits and receives pause frames for flow control

- **FC** - Supports flow control

- **Trunk** – Indicates if a port is a member of a trunk. To create trunks and select port members, see “Port Trunk Configuration” on page 2-64.

Note: Autonegotiation must be disabled before you can configure or force the interface to use the Speed/Duplex Mode or Flow Control options.

Web – Click Port/Port Configuration or Trunk Configuration. Modify the required interface settings, and click “Apply.”

| Port | Name | Admin | Speed Duplex | Flow Control | Autonegotiation | Trunk |
|------|----------------------|--|-----------------------------|-------------------------------|---|--------------------------|
| 1 | <input type="text"/> | <input checked="" type="checkbox"/> Enable | 10half <input type="text"/> | Disabled <input type="text"/> | Enabled <input type="text"/> <input checked="" type="checkbox"/> 10h <input checked="" type="checkbox"/> 100h <input type="checkbox"/> 1000h <input type="checkbox"/> Sym <input checked="" type="checkbox"/> 10f <input checked="" type="checkbox"/> 100f <input checked="" type="checkbox"/> 1000f <input type="checkbox"/> FC | <input type="checkbox"/> |
| 2 | <input type="text"/> | <input checked="" type="checkbox"/> Enable | 10half <input type="text"/> | Disabled <input type="text"/> | Enabled <input type="text"/> <input checked="" type="checkbox"/> 10h <input checked="" type="checkbox"/> 100h <input type="checkbox"/> 1000h <input type="checkbox"/> Sym <input checked="" type="checkbox"/> 10f <input checked="" type="checkbox"/> 100f <input checked="" type="checkbox"/> 1000f <input type="checkbox"/> FC | <input type="checkbox"/> |
| 3 | <input type="text"/> | <input checked="" type="checkbox"/> Enable | 10half <input type="text"/> | Disabled <input type="text"/> | Enabled <input type="text"/> <input checked="" type="checkbox"/> 10h <input checked="" type="checkbox"/> 100h <input type="checkbox"/> 1000h <input type="checkbox"/> Sym <input checked="" type="checkbox"/> 10f <input checked="" type="checkbox"/> 100f <input checked="" type="checkbox"/> 1000f <input type="checkbox"/> FC | <input type="checkbox"/> |
| 4 | <input type="text"/> | <input checked="" type="checkbox"/> Enable | 10half <input type="text"/> | Disabled <input type="text"/> | Enabled <input type="text"/> <input checked="" type="checkbox"/> 10h <input checked="" type="checkbox"/> 100h <input type="checkbox"/> 1000h <input type="checkbox"/> Sym <input checked="" type="checkbox"/> 10f <input checked="" type="checkbox"/> 100f <input checked="" type="checkbox"/> 1000f <input type="checkbox"/> FC | <input type="checkbox"/> |
| 5 | <input type="text"/> | <input checked="" type="checkbox"/> Enable | 10half <input type="text"/> | Disabled <input type="text"/> | Enabled <input type="text"/> <input checked="" type="checkbox"/> 10h <input checked="" type="checkbox"/> 100h <input type="checkbox"/> 1000h <input type="checkbox"/> Sym <input checked="" type="checkbox"/> 10f <input checked="" type="checkbox"/> 100f <input checked="" type="checkbox"/> 1000f <input type="checkbox"/> FC | <input type="checkbox"/> |

CLI – Select the interface, and then enter the required settings.

```

Console(config)#interface ethernet 1/13                               3-69
Console(config-if)#description RD SW#13                             3-69
Console(config-if)#shutdown                                          3-74
.
Console(config-if)#no shutdown
Console(config-if)#no negotiation                                   3-71
Console(config-if)#speed-duplex 100half                             3-70
Console(config-if)#flowcontrol                                       3-73
.
Console(config-if)#negotiation
Console(config-if)#capabilities 100half                             3-72
Console(config-if)#capabilities 100full
Console(config-if)#capabilities flowcontrol

```

Setting Broadcast Storm Thresholds

Broadcast storms may occur when a device on your network is malfunctioning, or if application programs are not well designed or properly configured. If there is too much broadcast traffic on your network, performance can be severely degraded or everything can come to complete halt.

You can protect your network from broadcast storms by setting a threshold for broadcast traffic for each port. Any broadcast packets exceeding the specified threshold will then be dropped.

Command Usage

- Default is enabled for all ports. Threshold: 256 packets per second
- Broadcast control does not effect IP multicast traffic.

Web – Click Port/Port Broadcast Control. Set the threshold for all ports (16, 64, 128, or 256 pps), and then click “Apply.”

| | |
|-------------------------|-----|
| Threshold (packets/sec) | 256 |
|-------------------------|-----|

| Port | Type | Protect Status |
|------|-------------|--|
| 1 | 1000Base-TX | <input checked="" type="checkbox"/> Enable |
| 2 | 1000Base-TX | <input checked="" type="checkbox"/> Enable |
| 3 | 1000Base-TX | <input checked="" type="checkbox"/> Enable |
| 4 | 1000Base-TX | <input checked="" type="checkbox"/> Enable |
| 5 | 1000Base-TX | <input checked="" type="checkbox"/> Enable |
| 6 | 1000Base-TX | <input checked="" type="checkbox"/> Enable |

CLI – Specify the required interface, and then enter the threshold. The following sets broadcast suppression at 128 packets per second on port 1.

| | |
|---|------|
| Console(config)#interface ethernet 1/1 | 3-69 |
| Console(config-if)#switchport broadcast packet-rate 128 | 3-75 |
| Console(config-if)# | |

Configuring Port Mirroring

You can mirror traffic from any source port to a target port for real-time analysis. You can then attach a logic analyzer or RMON probe to the target port and study the traffic crossing the source port in a completely unobtrusive manner.

Command Usage

- The mirror port and monitor port speeds must match, otherwise traffic may be dropped from the monitor port.
- The switch supports only one port mirror session.
- The source and target port have to be either both in the port group of 1 to 12 or both in the port group of 13 to 24.

Web – Click Port/Mirror. Specify the source port, the traffic type to be mirrored, and the target port, then click “Add.”

Mirror Sessions:

Source: 1/10 Both Destination: 1/11

New:

| | |
|-------------|------|
| Source Port | 1 ▾ |
| Type | Rx ▾ |
| Target Port | 1 ▾ |

<<Add

Remove

CLI – Use the interface command to select the target port, then use the port monitor command to specify the source port. Note that default mirroring under the CLI is for both received and transmitted packets.

```
Console(config)#interface ethernet 1/10
Console(config-if)#port monitor ethernet 1/11
Console(config-if)#
```

3-69

3-133

Address Table Settings

Switches store the addresses for all known devices. This information is used to route traffic directly between the inbound and outbound ports. All the addresses learned by monitoring traffic are stored in the dynamic address table. You can also manually configure static addresses that are bound to a specific port.

Setting Static Addresses

A static address can be assigned to a specific interface on this switch. Static addresses are bound to the assigned interface and will not be moved. When a static address is seen on another interface, the address will be ignored and will not be written to the address table.

Command Usage

Entries specified via the Web interface are permanent. Entries specified via the CLI can be made permanent or can be set to be deleted on reset.

Web – Click Address Table/Static Addresses. Specify the interface, the MAC address and VLAN, then click “Add Static Address.”

| | | |
|------------------------------|--|--|
| Static Address Counts | <input type="text" value="1"/> | |
| Current Static Address Table | <div>00-E8-49-7D-08-01, VLAN 1, Unit 1, Port 1, Permanent</div> | |
| Interface | <input checked="" type="radio"/> Port <input type="text" value="1"/> | <input type="radio"/> Trunk <input type="text" value="1"/> |
| MAC Address | <input type="text"/> | <input type="text"/> |
| VLAN | <input type="text" value="1"/> | <input type="text"/> |

Add Static Address

Remove Static Address

CLI – This example adds an address to the static address table, but sets it to be deleted when the switch is reset.

```
Console(config)#bridge 1 address 00-e0-29-94-34-de vlan 1 forward
ethernet 1/1 delete-on-reset
Console(config)#
```

Displaying the Address Table

The Dynamic Address Table contains the MAC addresses learned by monitoring the source address for traffic entering the switch. When the destination address for inbound traffic is found in the database, the packets intended for that address is forwarded directly to the associated port. Otherwise, the traffic is broadcast to all ports.

Command Usage

- You can display entries in the dynamic address table by selecting an interface (either port or trunk), MAC address, or VLAN.
- You can sort the information displayed based on interface (port or trunk), MAC address, or VLAN.

Web – Click Address Table/Dynamic Addresses. Specify the search type (i.e., Interface, MAC Address, or VLAN), the method of sorting the displayed addresses, then click Query.

| | |
|---|--|
| Query by: | |
| <input checked="" type="checkbox"/> Interface | <input checked="" type="radio"/> Port <input type="text" value="7"/> <input type="button" value="v"/> <input type="radio"/> Trunk <input type="button" value="v"/> |
| <input type="checkbox"/> MAC Address | <input type="text"/> |
| <input type="checkbox"/> VLAN | <input type="text" value="1"/> <input type="button" value="v"/> |
| Address Table Sort Key | <input type="text" value="Address"/> <input type="button" value="v"/> |

For example, the following screen shows the dynamic addresses for port 7.

| Dynamic Address Table | |
|-------------------------------|--|
| Dynamic Address Counts | 1 |
| Current Dynamic Address Table | 00-30-F1-2F-BE-30, VLAN 1, Unit 1, Port 7, Dynamic |

CLI – This example also displays the address table entries for port 11.

| | |
|--------------------------------------|------|
| Console#show bridge 1 ethernet 1/11 | 3-81 |
| Interface Mac Address Vlan Type | |
| ----- | |
| Eth 1/11 00-10-b5-62-03-74 1 Learned | |
| Console# | |

Changing the Aging Time

You can set the aging time for entries in the dynamic address table.

Command Usage

The range for the aging time is 17 - 2184 seconds. (The default is 300 seconds.)

Web – Click Address Table/Address Aging. Specify the new aging time, then click “Apply.”

Aging Time (17-2184): seconds

CLI – This example sets the aging time to 400 seconds.

| | |
|---|------|
| Console(config)#bridge-group 1 aging-time 400 | 3-83 |
| Console(config)# | |

Spanning Tree Protocol Configuration

The Spanning Tree Algorithm can be used to detect and disable network loops, and to provide backup links between switches, bridges or routers. This allows the switch to interact with other bridging devices (that is, an STA-compliant switch, bridge or router) in your network to ensure that only one route exists between any two stations on the network, and provide backup links which automatically take over when a primary link goes down.

Managing Global Settings

Global settings apply to the entire switch.

Command Attributes

The following global attributes are fixed and cannot be changed:

- **Bridge ID** – The priority and MAC address of this device.
- **Designated Root** – The priority and MAC address of the device in the Spanning Tree that this switch has accepted as the root device.
- **Root Port** – The number of the port on this switch that is closest to the root. This switch communicates with the root device through this port. If there is no root port, then this switch has been accepted as the root device of the Spanning Tree network.
- **Root Path Cost** – The path cost from the root port on this switch to the root device.
- **Configuration Changes** – The number of times the Spanning Tree has been reconfigured.
- **Last Topology Change** – The time since the Spanning Tree was last reconfigured.

The following global attributes can be configured:

- **Spanning Tree State** – Enable/disabled this switch to participate in a STA-compliant network.
- **Priority** – Bridge priority is used in selecting the root device, root port, and designated port. The device with the highest priority becomes the STA root device. However, if all devices have the same priority, the device with the lowest MAC address will then become the root device. (CLI only)
 - Default: 32768
 - Range: 0 - 65535
- **Hello Time** – Interval (in seconds) at which the root device transmits a configuration message.
 - Default: 2
 - Minimum: 1
 - Maximum: The lower of 10 or $[(\text{Max. Message Age} / 2) - 1]$
- **Maximum Age** – The maximum time (in seconds) a device can wait without receiving a configuration message before attempting to reconfigure. All device ports (except for designated ports) should receive configuration messages at regular intervals. Any port that ages out STA information (provided in the last configuration message) becomes the designated port for the attached LAN. If it is a root port, a new root port is selected from among the device ports attached to the network. (References to “ports” in this section means “interfaces,” which includes both ports and trunks.)
 - Default: 20
 - Minimum: The higher of 6 or $[2 \times (\text{Hello Time} + 1)]$.
 - Maximum: The lower of 40 or $[2 \times (\text{Forward Delay} - 1)]$

- **Forward Delay** – The maximum time (in seconds) the root device will wait before changing states (i.e., listening to learning to forwarding). This delay is required because every device must receive information about topology changes before it starts to forward frames. In addition, each port needs time to listen for conflicting information that would make it return to a blocking state; otherwise, temporary data loops might result.
 - Default: 15
 - Minimum: The higher of 4 or $[(\text{Max. Message Age} / 2) + 1]$
 - Maximum: 30

Displaying the current global settings for STA

Web – Click STA/STA Information.

| | | | |
|---------------------|--------------------|-----------------------|---------------------|
| Spanning Tree State | Enabled | Designated Root | 32768.0030F147583A |
| Bridge ID | 32768.0030F147583A | Root Port | 0 |
| Max Age | 20 | Root Path Cost | 0 |
| Hello Time | 2 | Configuration Changes | 1 |
| Forward Delay | 15 | Last Topology Change | 0 d 4 h 49 min 19 s |

CLI – This command displays global STA settings, followed by the settings for each port.

```

Console#show bridge group 1                                     3-92
Bridge-group information
-----
Spanning tree protocol           :ieee8021d
Spanning tree enable/disable    :enable
Priority                         :32768
Hello Time (sec.)               :2
Max Age (sec.)                  :20
Forward Delay (sec.)            :15
Designated Root                 :32768.000011112222
Current root port                :0
Current root cost                :0
Number of topology changes      :1
Last topology changes time (sec.):4576
Hold times (sec.)               :1
-----
Eth 1/ 1 information
-----
Admin status      : enable
STA state         : broken
Path cost         : 4
Priority          : 128
Designated cost   : 0
Designated port   : 128.1
Designated root   : 32768.000011112222
Designated bridge : 32768.000011112222
Fast forwarding   : disable
Forward transitions : 0
.
.
.

```

Note: The current root port and current root cost display as zero when this device is not connected to the network.

Configuring the global settings for STA

Web – Click STA/STA Configuration. Modify the required attributes, click “Apply.”

Switch:

| | |
|---------------------|-----------|
| Spanning Tree State | Enabled ▾ |
| Priority | 32768 |

When the Switch Becomes Root:

| | | |
|---------------|----|---------|
| Hello Time | 2 | seconds |
| Maximum Age | 20 | seconds |
| Forward Delay | 15 | seconds |

CLI – This example enables Spanning Tree Protocol, and then sets the indicated attributes.

| | |
|--|------|
| Console(config)#bridge 1 spanning-tree | 3-85 |
| Console(config)#bridge 1 priority 40000 | 3-88 |
| Console(config)#bridge 1 hello-time 5 | 3-87 |
| Console(config)#bridge 1 max-age 40 | 3-87 |
| Console(config)#bridge 1 forward-time 20 | 3-86 |

Managing STA Interface Settings

You can configure STA attributes for specific interfaces, including port priority, path cost, and fast forwarding. You may use a different priority or path cost for ports of same media type to indicate the preferred path.

Command Attributes

The following global attributes are read-only and cannot be changed:

- **Port Status** – Displays current state of this port within the Spanning Tree:

- **Disabled** - The port has been disabled by the user or has failed diagnostics.
- **Blocking** - Port receives STA configuration messages, but does not forward packets.
- **Listening** - Port will leave blocking state due to a topology change, start transmitting configuration messages, but does not yet forward packets.
- **Learning** - Port has transmitted configuration messages for an interval set by the Forward Delay parameter without receiving contradictory information. Port address table is cleared, and the port begins learning addresses.
- **Forwarding** - Port forwards packets, and continues learning addresses.
- **Broken** - Port is malfunctioning or no link has been established.
- **Forward Transitions** – The number of times this port has transitioned from the Learning state to the Forwarding state.
- **Designated Cost** – The cost for a packet to travel from this port to the root in the current Spanning Tree configuration. The slower the media, the higher the cost.
- **Designated Bridge** – The priority and MAC address of the device through which this port must communicate to reach the root of the Spanning Tree.
- **Designated Port** – The priority and number of the port on the designated bridging device through which this switch must communicate with the root of the Spanning Tree.
- **Trunk Member** – Indicates if a port is a member of a trunk.

The following interface attributes can be configured:

- **Priority** – Defines the priority used for this port in the Spanning Tree Protocol. If the path cost for all ports on a switch are the same, the port with the highest priority (i.e., lowest value) will be configured as an active link in the Spanning Tree. This makes a port with higher priority less likely to be blocked if the Spanning Tree Protocol is detecting network loops. Where more than one port is assigned the highest priority, the port with lowest numeric identifier will be enabled.
 - Default: 128
 - Range: 0 - 255
- **Path Cost** – This parameter is used by the STP to determine the best path between devices. Therefore, lower values should be assigned to ports attached to faster media, and higher values assigned to ports with slower media. (Path cost takes precedence over port priority.)
 - Full Range: 1-65535
 - Recommended Range –
 - Ethernet: 50-600
 - Fast Ethernet: 10-60
 - Gigabit Ethernet: 3-10
 - Defaults –
 - Ethernet – half duplex: 100; full duplex: 95; trunk: 90
 - Fast Ethernet – half duplex: 19; full duplex: 18; trunk: 15
 - Gigabit Ethernet – full duplex: 4; trunk: 3
- **Fast Forwarding** – Since end-nodes cannot cause forwarding loops, they can be pass directly through to the forwarding state. Fast Forwarding can achieve quicker convergence for end-node workstations and servers, and also overcome other STA related timeout problems. (Remember that Fast Forwarding should only be enabled for ports connected to an end-node device.)
 - Default is disabled

Web – Click STA/STA Port Information or STA Trunk Information.

| Port | Port Status | Forward Transitions | Designated Cost | Designated Bridge | Designated Port | Trunk Member |
|------|-------------|---------------------|-----------------|--------------------|-----------------|--------------|
| 1 | Broken | 0 | 0 | 32768.000011112222 | 128.1 | |
| 2 | Broken | 0 | 0 | 32768.000011112222 | 128.2 | |
| 3 | Broken | 0 | 0 | 32768.000011112222 | 128.3 | |
| 4 | Broken | 0 | 0 | 32768.000011112222 | 128.4 | |
| 5 | Broken | 0 | 0 | 32768.000011112222 | 128.5 | |
| 6 | Broken | 0 | 0 | 32768.000011112222 | 128.6 | |
| 7 | Forwarding | 1 | 0 | 32768.000011112222 | 128.7 | |
| 8 | Broken | 0 | 0 | 32768.000011112222 | 128.8 | |

CLI – This example shows the STA attributes for port 5.

| | |
|--|----------------------|
| Console#show bridge group 1 ethernet 1/5 | 3-92 |
| Bridge-group information | |
| ----- | |
| Spanning tree protocol | :ieee8021d |
| Spanning tree enable/disable | :enable |
| Priority | :32768 |
| Hello Time (sec.) | :2 |
| Max Age (sec.) | :20 |
| Forward Delay (sec.) | :15 |
| Designated Root | :32768.0000e8000001 |
| Current root port | :13 |
| Current root cost | :4 |
| Number of topology changes | :325 |
| Last topology changes time (sec.): | 18 |
| Hold times (sec.) | :1 |
| ----- | |
| Eth 1/ 5 information | |
| ----- | |
| Admin status | : enable |
| STA state | : blocking |
| Path cost | : 4 |
| Priority | : 128 |
| Designated cost | : 4 |
| Designated port | : 128.5 |
| Designated root | : 32768.0000e8000001 |
| Designated bridge | : 32768.222222222222 |
| Fast forwarding | : enable |
| Forward transitions | : 18 |
| Console# | |

Web – Click STA/STA Port Configuration or STA Trunk Configuration. Modify the required attributes, then click “Apply.”

| Port | Type | STA State | Priority | Path Cost | Fast Forwarding | Trunk |
|------|-------------|------------|----------|-----------|----------------------------------|-------|
| 1 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |
| 2 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |
| 3 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |
| 4 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |
| 5 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |
| 6 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |
| 7 | 1000Base-TX | Forwarding | 128 | 18 | <input type="checkbox"/> Enabled | |
| 8 | 1000Base-TX | Broken | 128 | 4 | <input type="checkbox"/> Enabled | |

CLI – This example sets STA attributes for port 5.

| | |
|--|------|
| Console(config)#interface ethernet 1/5 | 3-69 |
| Console(config-if)#bridge-group 1 priority 0 | 3-90 |
| Console(config-if)#bridge-group 1 path-cost 50 | 3-89 |
| Console(config-if)#bridge-group 1 portfast | 3-91 |

VLAN Configuration

In conventional networks with routers, broadcast traffic is split up into separate domains. Switches do not inherently support broadcast domains. This can lead to broadcast storms in large networks that handle traffic such as IPX or NetBeui. By using IEEE 802.1Q-compliant VLANs, you can organize any group of network nodes into separate broadcast domains, thus confining broadcast traffic to the originating group. This also provides a more secure and cleaner network environment.

An IEEE 802.1Q VLAN is a group of ports that can be located anywhere in the network, but communicate as though they belong to the same physical segment.

VLANs help to simplify network management by allowing you to move devices to a new VLAN without having to change any physical connections. VLANs can be easily organized to reflect departmental groups (such as Marketing or R&D), usage groups (such as e-mail), or multicast groups (used for multimedia applications such as videoconferencing).

VLANs provide greater network efficiency by reducing broadcast traffic, and allow you to make network changes without having to update IP addresses or IP subnets. VLANs inherently provide a high level of network security since traffic must pass through a configured Layer 3 link to reach a different VLAN.

- Up to 255 VLANs based on the IEEE 802.1Q standard
- Distributed VLAN learning across multiple switches using explicit or implicit tagging
- Port overlapping, allowing a port to participate in multiple VLANs
- End stations can belong to multiple VLANs
- Passing traffic between VLAN-aware and VLAN-unaware devices
- Priority tagging

Assigning Ports to VLANs

Before enabling VLANs for the switch, you must first assign each port to the VLAN group(s) in which it will participate. By default all ports are assigned to VLAN 1 as untagged ports. Add a port as a tagged port (that is, a port attached to a VLAN-aware device) if you want it to carry traffic for one or more VLANs and if the device at the other end of the link also supports VLANs. Then assign the port at the other end of the link to the same VLAN(s). However, if you want a port on this switch to participate

in one or more VLANs, but the device at the other end of the link does not support VLANs, then you must add this port as an untagged port (that is, a port attached to a VLAN-unaware device).

VLAN Classification – When the switch receives a frame, it classifies the frame in one of two ways. If the frame is untagged, the switch assigns the frame to an associated VLAN (based on the PVID of the receiving port). But if the frame is tagged, the switch uses the tagged VLAN ID to identify the port broadcast domain of the frame.

Port Overlapping – Port overlapping can be used to allow access to commonly shared network resources among different VLAN groups, such as file servers or printers. Note that if you implement VLANs which do not overlap, but still need to communicate, you can connect them by using a Layer-3 router or switch.

Port-based VLANs – Port-based (or static) VLANs are manually tied to specific ports. The switch's forwarding decision is based on the destination MAC address and its associated port. Therefore, to make valid forwarding or flooding decisions, the switch must learn the relationship of the MAC address to its related port—and thus to the VLAN—at run-time. However, when GVRP is enabled, this process can be fully automatic.

Automatic VLAN Registration – GVRP (GARP VLAN Registration Protocol) defines a system whereby the switch can automatically learn the VLANs to which each endstation should be assigned. If an endstation (or its network adapter) supports the IEEE 802.1Q VLAN protocol, it can be configured to broadcast a message to your network indicating the VLAN groups it wants to join. When this switch receives these messages, it will automatically place the receiving port in the specified VLANs, and then forward the message to all other ports. When the message arrives at another switch that supports GVRP, it will also place the receiving port in the specified VLANs, and pass the message on to all other ports. VLAN requirements are propagated in this way throughout the network. This allows GVRP-compliant devices to be automatically configured for VLAN groups based solely on endstation requests.

To implement GVRP in a network, you must first configure the static VLANs required on switches that are connected to PCs, servers, and other devices, so that these VLANs can be propagated across the network (Web - VLAN / VLAN Membership). For other core switches in the network, enable GVRP on the links between these devices (Web - VLAN / Port Settings or Trunk Settings). You should also determine security boundaries in the network and disable GVRP on ports to prevent advertisements being propagated, or forbid ports from joining restricted VLANs.

Forwarding Tagged/Untagged Frames

If you want to create a small port-based VLAN for devices attached directly to a single switch, you can assign ports to the same untagged VLAN. However, to participate in a VLAN group that crosses several switches, you need to create a VLAN for that group and enable tagging on all ports.

Ports can be assigned to multiple tagged or untagged VLANs. Each port on the switch is therefore capable of passing tagged or untagged frames. To forward a frame from a VLAN-aware device to a VLAN-unaware device, the switch first decides where to forward the frame, and then strips off the VLAN tag. However, to forward a frame from a VLAN-unaware device to a VLAN-aware device, the switch first decides where to forward the frame, and then inserts a VLAN tag reflecting this port's default VID.

Displaying Basic VLAN Information

Command Attributes

- **VLAN Version Number** – The VLAN version used by this switch as specified in the IEEE 802.1Q standard. (Web interface only.)
- **Maximum VLAN ID** – Maximum VLAN ID recognized by this switch.

- **Maximum Number of Supported VLANs** – Maximum number of VLANs that can be configured on this switch.

Web – Click VLAN/VLAN Basic Information.

| | |
|-----------------------------------|------|
| VLAN Version Number | 1 |
| Maximum VLAN ID | 4094 |
| Maximum Number of Supported VLANs | 255 |

CLI – Enter the following command.

```

Console#show bridge-ext
Max support vlan numbers: 255
Max support vlan ID: 4094
Extended multicast filtering services: No
Static entry individual port: Yes
VLAN learning: IVL
Configurable PVID tagging: Yes
Local VLAN capable: No
Traffic classes: Enabled
Global GVRP status: Enabled
GMRP: Disabled
Console#
  
```

3-109

Displaying Current VLANs

Command Attributes for Web Interface

- **VLAN ID** – ID of configured VLAN (1-4094, no leading zeroes).
- **Up Time at Creation** – Time this VLAN was created; i.e., System Up Time.
- **Status** – Shows how this VLAN was added to the switch.
 - **Dynamic GVRP**: Automatically learned via GVRP.
 - **Permanent**: Added as a static entry.
- **Tagged Ports** – Shows the tagged VLAN port members.
- **Untagged Ports** – Shows the untagged VLAN port members

Web – Click VLAN/VLAN Current Table. Select any ID from the scroll-down list.

VLAN ID:

| | |
|---------------------|-------------------|
| Up Time at Creation | 0 d 0 h 0 min 8 s |
| Status | Permanent |

Egress Ports

| | |
|-------------|---|
| Unit1 Port1 | ▲ |
| Unit1 Port2 | |
| Unit1 Port3 | |
| Unit1 Port4 | |
| Unit1 Port5 | |
| Unit1 Port6 | |
| Unit1 Port7 | |
| Unit1 Port8 | ▼ |

Untagged Ports

| | |
|-------------|---|
| Unit1 Port1 | ▲ |
| Unit1 Port2 | |
| Unit1 Port3 | |
| Unit1 Port4 | |
| Unit1 Port5 | |
| Unit1 Port6 | |
| Unit1 Port7 | |
| Unit1 Port8 | ▼ |

Command Attributes for CLI Interface

- **VLAN** – ID of configured VLAN (1-4094, no leading zeroes).
- **Type** – Shows how this VLAN was added to the switch.
 - **Dynamic:** Automatically learned via GVRP.
 - **Static:** Added as a static entry.
- **Name** – Name of the VLAN (1 to 32 characters).
- **Status** – Shows if this VLAN is enabled or disabled.
 - **Active:** VLAN is operational.
 - **Suspend:** VLAN is suspended; i.e., does not pass packets.
- **Ports / Channel groups** – Shows the VLAN interface members.

CLI – Current VLAN information can be displayed with the following command.

| | | | | | | | | | |
|------------------------|--------|-------------|--------|----------------------|---------|---------|---------|---------|--|
| Console#show vlan id 1 | | | | | | | | 3-104 | |
| VLAN | Type | Name | Status | Ports/Channel groups | | | | | |
| 1 | Static | DefaultVlan | Active | Eth1/ 1 | Eth1/ 2 | Eth1/ 3 | Eth1/ 4 | Eth1/ 5 | |
| | | | | Eth1/ 6 | Eth1/ 7 | Eth1/ 8 | Eth1/ 9 | Eth1/10 | |
| | | | | Eth1/11 | Eth1/12 | Eth1/13 | Eth1/14 | Eth1/15 | |
| | | | | Eth1/16 | Eth1/17 | Eth1/18 | Eth1/19 | Eth1/20 | |
| | | | | Eth1/21 | Eth1/22 | Eth1/23 | Eth1/24 | | |
| Console# | | | | | | | | | |

Creating VLANs

Command Attributes

- **VLAN ID** – ID of configured VLAN (1-4094, no leading zeroes).
- **Name** – Name of the VLAN (1 to 32 characters).
- **Status** – Shows if this VLAN is enabled or disabled (Web).
 - **Enable:** VLAN is operational.
 - **Disable:** VLAN is suspended; i.e., does not pass packets.
- **State** – Shows if this VLAN is enabled or disabled (CLI).
 - **Active:** VLAN is operational.
 - **Suspend:** VLAN is suspended; i.e., does not pass packets.

Web – Click VLAN/VLAN Static List. Enter the VLAN ID and VLAN name, mark the Enable checkbox to activate the VLAN, and then click Add.

Current:

| |
|-------------------------|
| 1, DefaultVlan, Enabled |
|-------------------------|

New:

| | |
|------------------|---------------------------------|
| VLAN ID (1-4094) | <input type="text"/> |
| VLAN Name | <input type="text"/> |
| Status | <input type="checkbox"/> Enable |

CLI – This example creates a new VLAN.

| | |
|---|------|
| Console(config)#vlan database | 3-95 |
| Console(config-vlan)#vlan 5 name R&D media ethernet state active | 3-96 |
| Console(config-vlan)# | |

Adding Interfaces Based on Membership Type

Command Attributes

- **Port** – Port identifier.
- **Trunk** – Trunk identifier.
- **VLAN** – ID of configured VLAN (1-4094, no leading zeroes).
- **Name** – Name of the VLAN (1 to 32 characters).
- **Status** – Shows if this VLAN is enabled or disabled.
 - **Enable:** VLAN is operational.
 - **Disable:** VLAN is suspended; i.e., does not pass packets.
- **Membership Type** – Select VLAN membership for each interface by marking the appropriate radio button for a port or trunk:
 - **Tagged:** Interface is a member of the VLAN. All packets transmitted by the port will be tagged, that is, carry a tag and therefore carry VLAN or CoS information.
 - **Untagged:** Interface is a member of the VLAN. All packets transmitted by the port will be untagged, that is, not carry a tag and therefore not carry VLAN or CoS information. Note that an interface must be assigned to at least one group as an untagged port.
 - **Forbidden:** Interface is forbidden from automatically joining the VLAN via GVRP. For more information, see “GVRP” on page 81.
 - **None:** Interface is not a member of the VLAN. Packets associated with this VLAN will not be transmitted by the interface.

- **Trunk Member** – Indicates if a port is a member of a trunk. To add a trunk to the selected VLAN, use the last table on the VLAN Static Table page.

Web – Click VLAN/VLAN Static Table. Select a VLAN ID from the scroll-down list. Modify the VLAN name and status if required. Select the membership type by marking the appropriate radio button in the list of ports or trunks. Click “Apply.”

VLAN:

| | |
|--------|--|
| Name | <input type="text" value="DefaultVlan"/> |
| Status | <input checked="" type="checkbox"/> Enable |

| Port | Tagged | Untagged | Forbidden | None | Trunk Member |
|------|-----------------------|----------------------------------|-----------------------|-----------------------|--------------|
| 1 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 2 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 3 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 4 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 5 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 6 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 7 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 8 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |
| 9 | <input type="radio"/> | <input checked="" type="radio"/> | <input type="radio"/> | <input type="radio"/> | |

CLI – The following example shows how to add tagged and untagged ports to VLAN 2.

```

Console(config)#interface ethernet 1/1                               3-69
Console(config-if)#switchport allowed vlan add 2 tagged           3-102
Console(config-if)#exit
Console(config)#interface ethernet 1/2
Console(config-if)#switchport allowed vlan add 2 untagged
Console(config-if)#exit
Console(config)#interface ethernet 1/13
Console(config-if)#switchport allowed vlan add 2 tagged

```

Adding Interfaces Based on Static Membership

Command Attributes

- **Interface** – Port or trunk identifier.
- **Member** – VLANs for which the selected interface is a tagged member.
- **Non-Member** – VLANs for which the selected interface is not a tagged member.

Web – Open VLAN/VLAN Static Membership. Select an interface from the scroll-down box (Port or Trunk). Click “Query” to display VLAN membership information for the interface. Select a VLAN ID, and then click “Add” to add the interface as a tagged member, or click “Remove” to remove the interface. After configuring VLAN membership for each interface, click “Apply.”

Interface

☒ Port

1

☐ Trunk

Query

Member:

Vlan 1

<< Add

Remove >>

Non-Member:

(none)

CLI – This example adds Port 3 to VLAN 1 as a tagged port, and removes Port 3 from VLAN 2.

| | |
|---|-------|
| Console(config)#interface ethernet 1/3 | 3-69 |
| Console(config-if)#switchport allowed vlan add 1 tagged | 3-102 |
| Console(config-if)#switchport allowed vlan remove 2 | |

Configuring VLAN Behavior for Interfaces

You can configure VLAN behavior for specific interfaces, including the default VLAN identifier (PVID), accepted frame types, ingress filtering, GVRP status, and GARP timers.

Command Usage

- **GVRP** – GARP VLAN Registration Protocol defines a way for switches to exchange VLAN information in order to automatically register VLAN members on interfaces across the network.
- **GARP** – Group Address Registration Protocol is used by GVRP to register or deregister client attributes for client services within a bridged LAN. The default values for the GARP timers are independent of the media access method or data rate. These values should not be changed unless you are experiencing difficulties with GVRP registration/deregistration.

Command Attributes

- **PVID** – The VLAN ID assigned to untagged frames received on the interface. If the (CLI) switchport mode is set to **trunk** (see page 3-98), the PVID will be inserted into all untagged frames sent from a tagged port. (Default: 1)
- **Acceptable Frame Type** – Sets the interface to accept all frame types, including tagged or untagged frames, or only tagged frames. If only tagged frames are accepted, the switch will only accept frames if the frame tag matches a VLAN to which this interface has been assigned. (Default: All)
- **Ingress Filtering** – If ingress filtering is enabled, incoming frames for VLANs which do not include this ingress port in their member set will be discarded at the ingress port. This will not affect VLAN independent BPDU frames, such as GVRP or STP. (Default: Disabled)

- **GVRP Status** – Enables/disables GVRP for the interface. GVRP must be globally enabled for the switch before this setting can take effect. (See “Displaying Bridge Extension Capabilities” on page 2-20.) When disabled, any GVRP packets received on this port will be discarded and no GVRP registrations will be propagated from other ports. (Default: Enabled)
- **GARP Join Timer** – The interval between transmitting requests/queries to participate in a VLAN group. (Default: 20 centiseconds)
- **GARP Leave Timer** – The interval a port waits before leaving a VLAN group. This time should be set to more than twice the join time. This ensures that after a Leave or LeaveAll message has been issued, the applicants can rejoin before the port actually leaves the group. (Default: 60 centiseconds)
- **GARP LeaveAll Timer** – The interval between sending out a LeaveAll query message for VLAN group participants and the port leaving the group. This interval should be considerably larger than the Leave Time to minimize the amount of traffic generated by nodes rejoining the group. (Default: 1000 centiseconds)
- **Trunk Member** – Indicates if a port is a member of a trunk. To add a trunk to the selected VLAN, use the last table on the VLAN Static Table page.
- **Mode** – Indicates VLAN membership mode for a port. (Configure via CLI, see page 3-98.)
 - **1Q Trunk** – Specifies a port as an end-point for a VLAN trunk. A trunk is a direct link between two switches, so the port transmits and receives tagged frames that identify the source VLAN.
 - **Hybrid** – Specifies a hybrid VLAN interface. The port may receive or transmit tagged or untagged frames. Any frames that are not tagged will be assigned to the default VLAN.

Note: Mode and the Acceptable Frame Type are comparable parameters.

Web – Click VLAN/VLAN Port Configuration or VLAN Trunk Configuration. Fill in the required settings for each interface, click “Apply.”

| Port | PVID | Acceptable Frame Type | Ingress Filtering | GVRP Status | GARP Join Timer | GARP Leave Timer | GARP LeaveAll Timer | Trunk Member | Mode |
|------|------|-----------------------|----------------------------------|----------------------------------|-----------------|------------------|---------------------|--------------|--------|
| 1 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 2 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 3 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 4 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 5 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 6 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 7 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |
| 8 | 1 | ALL | <input type="checkbox"/> Enabled | <input type="checkbox"/> Enabled | 20 | 60 | 1000 | | Hybrid |

CLI – This example sets port 1 to accept only tagged frames, assigns PVID 3 as the native VLAN ID, enables GVRP, sets the GARP timers, and then sets the switchport mode to hybrid.

```

Console(config)#interface ethernet 1/1 3-69
Console(config-if)#switchport acceptable-frame-types tagged 3-99
Console(config-if)#switchport ingress-filtering 3-100
Console(config-if)#switchport native vlan 3 3-101
Console(config-if)#switchport gvrp 3-105
Console(config-if)#garp timer join 10 3-107
Console(config-if)#garp timer leave 90 3-107
Console(config-if)#garp timer leaveall 2000 3-107
Console(config-if)#switchport mode hybrid 3-98
Console(config-if)#

```

Class of Service Configuration

Class of Service (CoS) allows you to specify which data packets have greater precedence when traffic is buffered in the switch due to congestion. This switch supports CoS with four priority queues for each port. Data packets in a port's high-priority queue will be transmitted before those in the lower-priority queues. You can set the default priority for each interface, and configure the mapping of frame priority tags to the switch's priority queues.

Setting the Default Priority for Interfaces

You can specify the default port priority for each interface on the switch. All untagged packets entering the switch are tagged with the specified default port priority, and then sorted into the appropriate priority queue at the output port.

Command Usage

- This switch provides four priority queues for each port. It uses Weighted Round Robin to prevent head-of-queue blockage.
- The default priority applies if the incoming frame is an untagged frame received from a VLAN trunk or a static-access port. This priority does not apply to IEEE 802.1Q VLAN tagged frames. If the incoming frame is an IEEE 802.1Q VLAN tagged frame, the IEEE 802.1p User Priority bits will be used.
- If the output port is an untagged member of the associated VLAN, these frames are stripped of all VLAN tags prior to transmission.

Command Attributes

- **Default Priority** – The priority that is assigned to untagged frames received on the specified port. (Range: 0 - 7, Default: 0)
- **Number of Egress Traffic Classes** – The number of queue buffers provided for each port.

Web – Click Priority/Default Port Priority or Default Trunk Priority. Modify the default priority for any interface, then click “Apply.”

| Port | Default Priority | Number of Egress Traffic Classes | Trunk |
|------|--------------------------------------|----------------------------------|-------|
| 1 | <input type="text" value="0"/> (0-7) | 4 | |
| 2 | <input type="text" value="0"/> (0-7) | 4 | |
| 3 | <input type="text" value="0"/> (0-7) | 4 | |
| 4 | <input type="text" value="0"/> (0-7) | 4 | |
| 5 | <input type="text" value="0"/> (0-7) | 4 | |
| 6 | <input type="text" value="0"/> (0-7) | 4 | |
| 7 | <input type="text" value="0"/> (0-7) | 4 | |
| 8 | <input type="text" value="0"/> (0-7) | 4 | |

CLI – This example assigns a default priority of 5 to port 3.

| | |
|--|-------|
| Console(config)#interface ethernet 1/3 | 3-69 |
| Console(config-if)#switchport priority default 5 | 3-122 |

Mapping CoS Values to Egress Queues

This switch processes Class of Service (CoS) priority tagged traffic by using four priority queues for each port, with service schedules based on Weighted Round Robin (WRR). Up to eight separate traffic priorities are defined in IEEE 802.1p. The default priority levels are assigned according

to recommendations in the IEEE 802.1p standard as shown in the following table.

| | Queue | | | |
|----------|-------|---|---|---|
| | 0 | 1 | 2 | 3 |
| Priority | | 0 | | |
| | 1 | | | |
| | 2 | | | |
| | | 3 | | |
| | | | 4 | |
| | | | 5 | |
| | | | | 6 |
| | | | | 7 |

The priority levels recommended in the IEEE 802.1p standard for various network applications are shown in the following table. However, you can map the priority levels to the switch’s output queues in any way that benefits application traffic for your own network.

| Priority Level | Traffic Type |
|----------------|--|
| 1 | Background |
| 2 | (Spare) |
| 0 (default) | Best Effort |
| 3 | Excellent Effort |
| 4 | Controlled Load |
| 5 | Video, less than 100 milliseconds latency and jitter |
| 6 | Voice, less than 10 milliseconds latency and jitter |
| 7 | Network Control |

- **Priority** – CoS value. (Range: 0 to 7, where 7 is the highest priority)
- **Traffic Class** – Output queue buffer. (Range: 0 - 3, where 3 is the highest CoS priority queue)

Web – Click Priority/Traffic Classes. Assign priorities to the output queues, then click “Apply.”

| Priority | Traffic Class |
|----------|--------------------------------------|
| 0 | <input type="text" value="1"/> (0-3) |
| 1 | <input type="text" value="0"/> (0-3) |
| 2 | <input type="text" value="0"/> (0-3) |
| 3 | <input type="text" value="1"/> (0-3) |
| 4 | <input type="text" value="2"/> (0-3) |
| 5 | <input type="text" value="2"/> (0-3) |
| 6 | <input type="text" value="3"/> (0-3) |
| 7 | <input type="text" value="3"/> (0-3) |

CLI – The following example shows how to map CoS values 0, 1 and 2 to CoS priority queue 0, value 3 to CoS priority queue 1, values 4 and 5 to CoS priority queue 2, and values 6 and 7 to CoS priority queue 3.

```

Console(config)#interface ethernet 1/1                               3-69
Console(config)#queue cos-map 0 0 1 2                               3-124
Console(config)#queue cos-map 1 3
Console(config)#queue cos-map 2 4 5
Console(config)#queue cos-map 3 6 7
Console(config)#exit
Console#show queue cos-map ethernet 1/1                             3-126
Information of Eth 1/1
Queue ID Traffic class
-----
0      0 1 2
1      3
2      4 5
3      6 7
Console#

```

Setting the Service Weight for Traffic Classes

This switch uses the Weighted Round Robin (WRR) algorithm to determine the frequency at which it services each priority queue. As described in “Mapping CoS Values to Egress Queues” on page 2-55, the traffic classes are mapped to one of the four egress queues provided for each port. You can assign a weight to each of these queues (and thereby to the corresponding traffic priorities). This weight sets the frequency at which each queue will be polled for service, and subsequently affects the response time for software applications assigned a specific priority value.

Command Attributes

- **WRR Setting Table** – Displays a list of weights for each traffic class (i.e., queue).
- **Weight Value** – Set a new weight for the selected traffic class.

Web – Open Priority/Queue Scheduling. Select a traffic class by clicking on it with your cursor, enter a weight value, and then click “Apply.”

| | |
|-------------------|------------------------------|
| WRR Setting Table | Traffic Class 0 - weight 16 |
| | Traffic Class 1 - weight 64 |
| | Traffic Class 2 - weight 128 |
| | Traffic Class 3 - weight 240 |
| Weight Value | <input type="text"/> (1-255) |

CLI – The following example shows how to assign WRR weights of 1, 4, 16 and 64 to the CoS priority queues 0, 1, 2 and 3.

```
Console(config)#queue bandwidth 1 4 16 64 3-123
Console(config)#exit
Console#show queue bandwidth 3-125
Queue ID Weight
-----
0          1
1          4
2         16
3         64
Console#
```


Mapping Layer 3/4 Priorities to CoS Values

This switch supports a common method of prioritizing layer 3/4 traffic to meet application requirements. Traffic priorities can be specified in the IP header of a frame, using the priority bits in the Type of Service (ToS) octet. The ToS octet may contain three bits for IP Precedence or six bits for Differentiated Services Code Point (DSCP) service. When these services are enabled, the priorities are mapped to a Class of Service value by the switch, and the traffic then sent to the corresponding output queue.

Because different priority information may be contained in the traffic, this switch maps priority values to the output queues in the following manner:

- The precedence for priority mapping is IP Precedence or DSCP Priority and then Default Port Priority.
- IP Precedence and DSCP Priority cannot both be enabled. Enabling one of these priority types will automatically disable the other.
- IP Precedence and DSCP Priority settings are global and apply to all ports on the switch.

Selecting IP Precedence/DSCP Priority

The switch allows you to choose between using IP Precedence or DSCP priority. Select one of the methods or disable this feature.

Command Attributes

- **IP Precedence/DSCP Priority Status** – Selects IP Precedence, DSCP, or disables both priority services.

Web – Click Priority/IP Precedence Priority. Select “IP Precedence” or “IP DSCP” from the IP Precedence/DSCP Priority Status menu.

| | |
|------------------------------------|------------|
| IP Precedence/DSCP Priority Status | Disabled ▼ |
|------------------------------------|------------|

CLI – The following example globally enables IP Precedence service on the switch.

Console(config)#map ip precedence

Console#

3-127

Mapping IP Precedence

The Type of Service (ToS) octet in the IPv4 header includes three precedence bits defining eight different priority levels ranging from highest priority for network control packets to lowest priority for routine traffic. The default IP Precedence values are mapped one-to-one to Class of Service values (i.e., Precedence value 0 maps to CoS value 0, and so forth). Bits 6 and 7 are used for network control, and the other bits for various application types. ToS bits are defined in the following table.

| Priority Level | Traffic Type |
|----------------|----------------------|
| 7 | Network Control |
| 6 | Internetwork Control |
| 5 | Critical |
| 4 | Flash Override |
| 3 | Flash |
| 2 | Immediate |
| 1 | Priority |
| 0 | Routine |

Command Attributes

- **IP Precedence Priority Table** – Shows the IP Precedence to CoS map.
- **Class of Service Value** – Maps a CoS value to the selected IP Precedence value. Note that “0” represents low priority and “7” represent high priority.

Web – Click Priority/IP Precedence Priority. Select an IP Precedence value from the IP Precedence Priority Table by clicking on it with your cursor, enter a value in the Class of Service Value field, and then click “Apply.” Be sure to also select “IP Precedence” from the IP Precedence/DSCP Priority Status menu.

| | |
|-------------------------------------|----------------------------|
| IP Precedence Priority Table | IP Precedence 0 - CoS 0 |
| | IP Precedence 1 - CoS 1 |
| | IP Precedence 2 - CoS 2 |
| | IP Precedence 3 - CoS 3 |
| | IP Precedence 4 - CoS 4 |
| | IP Precedence 5 - CoS 5 |
| | IP Precedence 6 - CoS 6 |
| | IP Precedence 7 - CoS 7 |
| Class of Service Value | <input type="text"/> (0-7) |

CLI – The following example globally enables IP Precedence service on the switch, maps IP Precedence value 1 to CoS value 0 on port 5, and then displays all the IP Precedence settings for that port. (Note that the setting is global and applies to all ports on the switch.)

```

Console(config)#map ip precedence                               3-127
Console(config)#interface ethernet 1/5                         3-69
Console(config-if)#map ip precedence 1 cos 0                  3-127
Console(config-if)#end
Console#show map ip precedence ethernet 1/5                   3-131
Precedence mapping status: disabled

  Port      Precedence  COS
  -----
  Eth 1/ 5      0      0
  Eth 1/ 5      1      0
  Eth 1/ 5      2      2
  Eth 1/ 5      3      3
  Eth 1/ 5      4      4
  Eth 1/ 5      5      5
  Eth 1/ 5      6      6
  Eth 1/ 5      7      7
Console#

```

Mapping DSCP Priority

The DSCP is six bits wide, allowing coding for up to 64 different forwarding behaviors. The DSCP replaces the ToS bits, and it retains backward compatibility with the three precedence bits so that non-DSCP compliant, ToS-enabled devices, will not conflict with the DSCP mapping. Based on network policies, different kinds of traffic can be marked for different kinds of forwarding. The DSCP default values are defined in the following table. Note that all the DSCP values that are not specified are mapped to CoS value 0.

| IP DSCP Value | CoS Value |
|------------------------|-----------|
| 0 | 0 |
| 8 | 1 |
| 10, 12, 14, 16 | 2 |
| 18, 20, 22, 24 | 3 |
| 26, 28, 30, 32, 34, 36 | 4 |
| 38, 40, 42 | 5 |
| 48 | 6 |
| 46, 56 | 7 |

Command Attributes

- **DSCP Priority Table** – Shows the DSCP Priority to CoS map.
- **Class of Service Value** – Maps a CoS value to the selected DSCP Priority value. Note that “0” represents low priority and “7” represent high priority.

Web – Click Priority/IP DSCP Priority. Select a DSCP priority value from the DSCP Priority Table by clicking on it with your cursor, enter a value in the Class of Service Value field, and then click “Apply.” Be sure to also select “IP DSCP” from the IP Precedence/DSCP Priority Status menu.

| | |
|------------------------|----------------------------|
| DSCP Priority Table | DSCP 0 - CoS 0 |
| | DSCP 1 - CoS 0 |
| | DSCP 2 - CoS 0 |
| | DSCP 3 - CoS 0 |
| | DSCP 4 - CoS 0 |
| | DSCP 5 - CoS 0 |
| | DSCP 6 - CoS 0 |
| Class of Service Value | <input type="text"/> (0-7) |

Restore Default

CLI – The following example globally enables DSCP Priority service on the switch, maps DSCP value 1 to CoS value 0 on port 5, and then displays all the DSCP Priority settings for that port. (Note that the setting is global and applies to all ports on the switch.)

```

Console(config)#map ip dscp                               3-129
Console(config)#interface ethernet 1/5                    3-69
Console(config-if)#map ip dscp 1 cos 0                    3-129
Console(config-if)#end
Console#show map ip dscp ethernet 1/5                     3-132
DSCP mapping status: disabled

  Port          DSCP  COS
  -----
  Eth 1/ 5      0    0
  Eth 1/ 5      1    0
  Eth 1/ 5      2    0
  Eth 1/ 5      3    0
.
.
.
  Eth 1/ 5     61    0
  Eth 1/ 5     62    0
  Eth 1/ 5     63    0
Console#

```

Port Trunk Configuration

Ports can be combined into an aggregate link to increase the bandwidth of a network connection where bottlenecks exist or to ensure fault recovery. You can create up to six trunks at a time, with any single trunk containing up to four ports.

The switch supports both static trunking and dynamic LACP (Link Aggregation Control Protocol). LACP configured ports can automatically negotiate a trunked link with LACP-configured ports on another device. You can enable LACP on any port that is not already a member of a static trunk. If LACP is also enabled for the connected ports on another device, the switch and the other device will automatically create a trunked link.

Besides balancing the load across each port in the trunk, the other ports provide redundancy by taking over the load if a port in the trunk fails. However, before making any physical connections between devices, use the Web interface or CLI to specify the trunk on the devices at both ends. When using a port trunk, take note of the following points:

- Finish configuring port trunks before you connect the corresponding network cables between switches to avoid creating a loop.
- The ports at both ends of a connection must be configured as trunk ports.
- The ports at both ends of a trunk must be configured in an identical manner, including communication mode (i.e., speed, duplex mode and flow control), VLAN assignments, and CoS settings.
- All ports on both ends of an LACP trunk must be configured for full duplex, either by forced mode or auto-negotiation.
- All the ports in a trunk have to be treated as a whole when moved from/to, added or deleted from a VLAN.
- STP, VLAN, and IGMP settings can only be made for the entire trunk.

Dynamically Configuring a Trunk with LACP

Web – Click Trunk/LACP Configuration. Select any of the switch ports from the scroll-down port list and click “Add.” After you have completed adding ports to the member list, click “Apply.”

Member List:

Current:

New:

The interface shows a 'Current:' list with '(none)' and a 'New:' section with a '<<Add' button, a 'Remove' button, and a 'Port' dropdown menu currently set to '1'.

CLI – The following example enables LACP for ports 17 and 18. Just connect these ports to two LACP-enabled trunk ports on another switch to form a trunk.

```

Console(config)#interface ethernet 1/17                               3-69
Console(config-if)#lacp                                              3-137
Console(config-if)#exit
Console(config)#interface ethernet 1/18
Console(config-if)#lacp
Console(config-if)#end
Console#show interfaces status port-channel 1                        3-76
Information of Trunk 1
Basic information:
  Port type: 1000t
  Mac address: 22-22-22-22-22-2d
Configuration:
  Name:
  Port admin status: Up
  Speed-duplex: Auto
  Capabilities: 10half, 10full, 100half, 100full, 1000full,
  Flow control status: Disabled
Current status:
  Created by: Lacp
  Link status: Up
  Port operation status: Up
  Operation speed-duplex: 1000full
  Flow control type: None
  Member Ports: Eth1/17, Eth1/18,
Console#
  
```

Statically Configuring a Trunk

Web – Click Trunk/Trunk Configuration. Enter a trunk ID of 1-6 in the Trunk field, select any of the switch ports from the scroll-down port list, and click “Add.” After you have completed adding ports to the member list, click “Apply.”

Member List:

Current:

```
Trunk1, Unit1 Port17
Trunk1, Unit1 Port18
Trunk1, Unit1 Port19
Trunk1, Unit1 Port20
```

New:

| | |
|--------|-------------------------------------|
| <<Add | Trunk (1-6) <input type="text"/> |
| Remove | Port <input type="text" value="1"/> |

CLI – This example creates trunk 1 with ports 11 and 12. Just connect these ports to two static trunk ports on another switch to form a trunk.

```
Console(config)#interface port-channel 1 3-69
Console(config-if)#exit
Console(config)#interface ethernet 1/11 3-69
Console(config-if)#channel-group 1 3-136
Console(config-if)#exit
Console(config)#interface ethernet 1/12
Console(config-if)#channel-group 1
Console(config-if)#end
Console#show interfaces status port-channel 1 3-76
Information of Trunk 1
Basic information:
  Port type: 1000t
  Mac address: 22-22-22-22-22-2c
Configuration:
  Name:
  Port admin status: Up
  Speed-duplex: Auto
  Capabilities: 10half, 10full, 100half, 100full, 1000full,
  Flow control status: Disabled
Current status:
  Created by: User
  Link status: Up
  Port operation status: Up
  Operation speed-duplex: 1000full
  Flow control type: None
  Member Ports: Eth1/11, Eth1/12,
Console#
```


Configuring SNMP

The switch includes an onboard agent that continuously monitors the status of its hardware, as well as the traffic passing through its ports, based on the Simple Network Management Protocol (SNMP). A network management station can access this information using software such as EliteView. Access rights to the onboard agent are controlled by community strings. To communicate with the switch, the management station must first submit a valid community string for authentication. The options for configuring community strings and related trap functions are described in the following sections.

Setting Community Access Strings

You may configure up to five community strings authorized for management access. For security reasons, you should consider removing the default strings.

Command Attributes

Community String – A community string that acts like a password and permits access to the SNMP protocol.

Access Mode

- **Read-Only** – Specifies read-only access. Authorized management stations are only able to retrieve MIB objects.
- **Read/Write** – Specifies read-write access. Authorized management stations are able to both retrieve and modify MIB objects.

Web – Click SNMP/SNMP Configuration. Enter a new string in the Community String box and select the access rights from the Access Mode drop-down list, then click “Add.”

SNMP Community Capability: 5

| | | | | | |
|-------------------------|--|------------------|--|-------------|---|
| Current: | New: | | | | |
| private RW public RO | <table border="1" style="border-collapse: collapse;"> <tr> <td style="padding: 2px 5px;">Community String</td> <td style="width: 150px; height: 20px;"></td> </tr> <tr> <td style="padding: 2px 5px;">Access Mode</td> <td style="width: 100px;"> <div style="border: 1px solid black; padding: 2px;">Read-Only ▾</div> </td> </tr> </table> | Community String | | Access Mode | <div style="border: 1px solid black; padding: 2px;">Read-Only ▾</div> |
| Community String | | | | | |
| Access Mode | <div style="border: 1px solid black; padding: 2px;">Read-Only ▾</div> | | | | |
| | <div style="display: inline-block; border: 1px solid black; padding: 2px 10px; margin: 2px;"><< Add</div> <div style="display: inline-block; border: 1px solid black; padding: 2px 10px; margin: 2px;">Remove</div> | | | | |

CLI – The following example adds the string “spiderman” with read/write access.

```
Console(config)#snmp-server community spiderman rw
Console(config)#
```

3-44

Specifying Trap Managers

You can specify up to five management stations that will receive authentication failure messages and other trap messages from the switch.

Command Usage

- You can enable or disable authentication messages via the Web interface.
- You can enable or disable authentication messages, link-up-down messages, or all notification types via the CLI.

Web – Click SNMP/SNMP Configuration. Fill in the Trap Manager IP Address box and the Trap Manager Community String box, mark Enable Authentication Traps if required, and then click “Add.”

Trap Manager Capability: 5

| | | | |
|----------|--|-------------------------------|----------------------|
| Current: | | New: | |
| (none) | | Trap Manager IP address | <input type="text"/> |
| | <input type="button" value="Add"/> <input type="button" value="Remove"/> | Trap Manager Community String | <input type="text"/> |

Enable Authentication Traps: ☒

CLI – This example adds a trap manager and enables authentication traps.

| | |
|---|------|
| Console(config)#snmp-server host 10.1.19.23 batman | 3-46 |
| Console(config)#snmp-server enable traps authentication | 3-48 |

Multicast Configuration

Multicasting is used to support real-time applications such as video conferencing or streaming audio. A multicast server does not have to establish a separate connection with each client. It merely broadcasts its service to the network, and any hosts that want to receive the multicast register with their local multicast switch/router. Although this approach reduces the network overhead required by a multicast server, the broadcast traffic must be carefully pruned at every multicast switch/router it passes through to ensure that traffic is only passed on the hosts which subscribed to this service.

This switch uses IGMP (Internet Group Management Protocol) to query for any attached hosts that want to receive a specific multicast service. It identifies the ports containing hosts requesting to join the service and sends data out to those ports only. It then propagates the service request up to any neighboring multicast switch/router to ensure that it will continue to receive the multicast service. This procedure is called multicast filtering.

The purpose of IP multicast filtering is to optimize a switched network's performance, so multicast packets will only be forwarded to those ports containing multicast group hosts or multicast routers/switches, instead of flooding traffic to all ports in the subnet (VLAN).

Configuring IGMP Parameters

You can configure the switch to forward multicast traffic intelligently. Based on the IGMP query and report messages, the switch forwards traffic only to the ports that request multicast traffic. This prevents the switch from broadcasting the traffic to all ports and possibly disrupting network performance.

Command Usage

- **IGMP Snooping** – This switch can passively snoop on IGMP Query and Report packets transferred between IP multicast routers/switches and IP multicast host groups to identify the IP multicast group members. It simply monitors the IGMP packets passing through it, picks out the group registration information, and configures multicast filters accordingly.
- **IGMP Query** – A router, or multicast-enabled switch, can periodically ask their hosts if they want to receive multicast traffic. If there is more than one router/switch on the LAN performing IP multicasting, one of these devices is elected “querier” and assumes the role of querying the LAN for group members. It then propagates the service requests on to any adjacent multicast switch/router to ensure that it will continue to receive the multicast service.

Note: Multicast routers use this information, along with a multicast routing protocol such as DVMRP, to support IP multicasting across the Internet.

Command Attributes

- **IGMP Status** — When enabled, the switch will monitor network traffic to determine which hosts want to receive multicast traffic. This is also referred to as IGMP Snooping. (Default: Disabled)
- **Act as IGMP Querier** — When enabled, the switch can serve as the Querier, which is responsible for asking hosts if they want to receive multicast traffic. (Default: Disabled)
- **IGMP Query Count** — Sets the maximum number of queries issued for which there has been no response before the switch takes action to solicit reports. (Default: 2, Range: 2 - 10)
- **IGMP Query Interval** — Sets the frequency (in seconds) at which the switch sends IGMP host-query messages. (Default: 125, Range: 60 - 125)
- **IGMP Report Delay** — Sets the time (in seconds) between receiving an IGMP Report for an IP multicast address on a port before the switch sends an IGMP Query out of that port and removes the entry from its list. (Default: 10, Range: 5 - 30)
- **Query Timeout** — Sets the time (in seconds) the switch waits after the previous querier has stopped querying before it takes over as the querier. (Default: 300 seconds, Range: 300 - 500)
- **IGMP Version** — Sets the protocol version for compatibility with other devices on the network. (Default: 2, Range: 1 - 2)

Notes: 1. All systems on the subnet must support the same version.

2. Some attributes are only enabled for IGMPv2, including IGMP Report Delay and IGMP Query Timeout.

Web – Click IGMP/IGMP Configuration. Adjust the IGMP settings as required, and then click “Apply.” (The default settings are shown below.)

| | |
|------------------------------|--|
| IGMP Status | <input checked="" type="checkbox"/> Enable |
| Act as IGMP Querier | <input checked="" type="checkbox"/> Enable |
| IGMP Query Count (2-10) | 2 |
| IGMP Query Interval (60-125) | 125 seconds |
| IGMP Report Delay (5-30) | 10 seconds |
| IGMP Query Timeout (300-500) | 300 seconds |
| IGMP Version | 2 |

CLI – This example modifies the settings for multicast filtering, and then displays the current status.

```

Console(config)#ip igmp snooping                               3-111
Console(config)#ip igmp snooping querier                      3-115
Console(config)#ip igmp snooping query-count 10               3-116
Console(config)#ip igmp snooping query-interval 100           3-116
Console(config)#ip igmp snooping query-max-response-time 20   3-117
Console(config)#ip igmp snooping query-time-out 300           3-118
Console(config)#ip igmp snooping version 2                     3-113
Console(config)#exit
Console#show ip igmp snooping                                  3-113
  Igmp Snooping Configuration
  -----
  Service status      : Enabled
  Querier status      : Enabled
  Query count         : 10
  Query interval      : 100 sec
  Query max response time : 20 sec
  Query time-out      : 300 sec
  IGMP snooping version : Version 2
Console#

```

Interfaces Attached to a Multicast Router

Multicast routers use the information obtained from IGMP Query, along with a multicast routing protocol such as DVMRP, to support IP multicasting across the Internet. These routers may be dynamically discovered by the switch or statically assigned to an interface on the switch.

Displaying Interfaces Attached to a Multicast Router

Command Attributes

- **VLAN ID** – ID of configured VLAN (1-4094).
- **Multicast Router List** – Multicast routers dynamically discovered by this switch or those that are statically assigned to an interface on this switch.

Web – Click IGMP/Multicast Router Port Information. Select the required VLAN ID from the scroll-down list to display the associated multicast routers.

VLAN ID: 1

Multicast Router List:

Unit1 Port3, Static

CLI – This example shows that Port 11 has been statically configured as a port attached to a multicast router.

```

Console#show ip igmp snooping mrouter vlan 1
VLAN M'cast Router Port Type
-----
1          Eth 1/11 Static

```

Specifying Interfaces Attached to a Multicast Router

Depending on your network connections, IGMP snooping may not always be able to locate the IGMP querier. Therefore, if the IGMP querier is a known multicast router/switch connected over the network to an interface

(port or trunk) on your switch, you can manually configure that interface to join all the current multicast groups. This can ensure that multicast traffic is passed to all the appropriate interfaces within the switch.

Command Attributes

- **Interface** – Activates the Port or Trunk scroll down list.
- **VLAN ID** – Selects the VLAN to propagate all multicast traffic coming from the attached multicast router/switch.
- **Port or Trunk** – Specifies the interface attached to a multicast router.

Web – Click IGMP/Static Multicast Router Port Configuration. Specify the interfaces attached to a multicast router, indicate the VLAN which will forward all the corresponding multicast traffic, and then click “Add.” After you have completed adding interfaces to the list, click “Apply.”

Current:

| |
|--------------------|
| Vlan1, Unit1 Port3 |
|--------------------|

<<Add

Remove

New:

| | |
|-----------|--------------------------|
| Interface | Port |
| VLAN ID | 1 |
| Port | 1 |
| Trunk | <input type="checkbox"/> |

CLI – This example configures port 11 as a multicast router port within VLAN 1.

```

Console(config)#ip igmp snooping vlan 1 mrouter ethernet 1/11 3-119
Console(config)#exit
Console#show ip igmp snooping mrouter vlan 1 3-120
VLAN M'cast Router Port Type
-----
1           Eth 1/11  Static
    
```


Displaying Port Members of Multicast Services

You can display the port members associated with a specified VLAN and multicast IP address.

Command Attribute

- **VLAN ID** – Selects the VLAN in which to display port members.
- **Multicast IP Address** – The IP address for a specific multicast service
- **Multicast Group Port List** – Ports propagating a multicast service; i.e., ports that belong to the indicated VLAN group.

Web – Click IGMP/IP Multicast Registration Table. Select the VLAN ID and multicast IP address. The switch will display all the ports that are propagating this multicast service.

VLAN ID:

Multicast IP Address:

Multicast Group Port List:

Unit1 Port5, User

CLI – This example displays all the known multicast services supported on VLAN 1, along with the ports propagating the corresponding services. The type field shows if this entry was learned dynamically or was statically configured.

```

Console#show bridge 1 multicast vlan 1
VLAN M'cast IP addr. Member ports Type
-----
  1      224.0.0.12      Eth1/12    USER
  1      224.1.2.3       Eth1/12    IGMP
Console#
  
```

Adding Multicast Addresses to VLANs

Multicast filtering can be dynamically configured using IGMP Snooping and IGMP Query messages as described in “Configuring IGMP Parameters” on page 2-70. For certain application that require tighter control, you may need to statically configure a multicast service on the switch. First add all the ports attached to participating hosts to a common VLAN, and then assign the multicast service to that VLAN group.

Command Usage

- Static multicast addresses are never aged out.
- When a multicast address is assigned to specific VLAN, the corresponding traffic can only be forwarded to ports within that VLAN.

Command Attribute

- **Interface** – Activates the Port or Trunk scroll down list.
- **VLAN ID** – Selects the VLAN to propagate all multicast traffic coming from the attached multicast router/switch.
- **Multicast IP** – The IP address for a specific multicast service
- **Port or Trunk** – Specifies the interface attached to a multicast router.

Web – Click IGMP/IGMP Member Port Table. Specify the interface attached to a multicast service (via an IGMP-enabled switch or multicast router), indicate the VLAN that will propagate the multicast service, specify the multicast IP address, and then click “Add.” After you have completed adding ports to the member list, click “Apply.”

IGMP Member Port List:

| |
|-----------------------------------|
| VLAN 1, 225.0.0.9, Unit 1, Port 7 |
| |
| |
| |
| |
| |
| |
| |
| |
| |

<<Add

Remove

New Static IGMP Member Port:

| | |
|--------------|--------------------------|
| Interface | Port |
| VLAN ID | 1 |
| Multicast IP | |
| Port | 1 |
| Trunk | <input type="checkbox"/> |

CLI – This example assigns a multicast address to VLAN 1, and then displays all the known multicast services supported on VLAN 1.

```

Console(config)#ip igmp snooping vlan 1 static 224.0.0.12
ethernet 1/12
Console(config)#exit
Console#show bridge 1 multicast vlan 1
VLAN M'cast IP addr. Member ports Type
-----
1      224.0.0.12      Eth1/12      USER
1      224.1.2.3       Eth1/12      IGMP
Console#
  
```

Showing Device Statistics

You can display standard statistics on network traffic from the Interfaces Group and Ethernet-like MIBs, as well as a detailed breakdown of traffic based on the RMOM MIB. Interfaces and Ethernet-like statistics display errors on the traffic passing through each port. This information can be used to identify potential problems with the switch (such as a faulty port or unusually heavy loading). RMON statistics provide access to a broad range of statistics, including a total count of different frame types and sizes

passing through each port. All values displayed have been accumulated since the last system reboot, and are shown as counts per second. Statistics are refreshed every 60 seconds by default.

Note: RMON groups 2, 3 and 9 can only be accessed using SNMP management software such as EliteView.

Web – Click Statistics/Port Statistics. Select the required interface, and then click “Query.” You can also use the Refresh button at the bottom of the page to update the screen.

Interface ☒ Port ☐ Trunk

Query

Interface Statistics:

| | | | |
|----------------------------|---|----------------------------|---|
| Received Octets | 0 | Received Unicast Packets | 0 |
| Received Multicast Packets | 0 | Received Broadcast Packets | 0 |
| Received Discarded Packets | 0 | Received Unknown Packets | 0 |
| Received Errors | 0 | Transmit Octets | 0 |
| Transmit Unicast Packets | 0 | Transmit Multicast Packets | 0 |
| Transmit Broadcast Packets | 0 | Transmit Discarded Packets | 0 |
| Transmit Errors | 0 | | |

Etherlike Statistics:

| | | | |
|---------------------------|---|------------------------------|---|
| Alignment Errors | 0 | Late Collisions | 0 |
| FCS Errors | 0 | Excessive Collisions | 0 |
| Single Collision Frames | 0 | Internal MAC Transmit Errors | 0 |
| Multiple Collision Frames | 0 | Carrier Sense Errors | 0 |
| SQE Test Errors | 0 | Frames Too Long | 0 |
| Deferred Transmissions | 0 | Internal MAC Receive Errors | 0 |

RMON Statistics:

| | | | |
|----------------------|---|------------------------|---|
| Drop Events | 0 | Jabbers | 0 |
| Received Bytes | 0 | Collisions | 0 |
| Received Frames | 0 | 64 Bytes Frames | 0 |
| Broadcast Frames | 0 | 65-127 Bytes Frames | 0 |
| Multicast Frames | 0 | 128-255 Bytes Frames | 0 |
| CRC/Alignment Errors | 0 | 256-511 Bytes Frames | 0 |
| Undersize Frames | 0 | 512-1023 Bytes Frames | 0 |
| Oversize Frames | 0 | 1024-1518 Bytes Frames | 0 |
| Fragments | 0 | | |

Refresh

CLI – This example shows statistics for port 13.

```

Console#show interfaces counters ethernet 1/13
Ethernet 1/13
  Iftable stats:
    Octets input: 868453, Octets output: 3492122
    Unicast input: 7315, Unicast output: 6658
    Discard input: 0, Discard output: 0
    Error input: 0, Error output: 0
    Unknown protos input: 0, QLen output: 0
  Extended iftable stats:
    Multi-cast input: 0, Multi-cast output: 17027
    Broadcast input: 231, Broadcast output: 7
  Ether-like stats:
    Alignment errors: 0, FCS errors: 0
    Single Collision frames: 0, Multiple collision frames: 0
    SQE Test errors: 0, Deferred transmissions: 0
    Late collisions: 0, Excessive collisions: 0
    Internal mac transmit errors: 0, Internal mac receive errors: 0
    Frame too longs: 0, Carrier sense errors: 0
    Symbol errors: 0
  RMON stats:
    Drop events: 0, Octets: 4422579, Packets: 31552
    Broadcast pkts: 238, Multi-cast pkts: 17033
    Undersize pkts: 0, Oversize pkts: 0
    Fragments: 0, Jabbers: 0
    CRC align errors: 0, Collisions: 0
    Packet size <= 64 octets: 25568, Packet size 65 to 127 octets: 1616
    Packet size 128 to 255 octets: 1249, Packet size 256 to 511 octets:
1449
    Packet size 512 to 1023 octets: 802, Packet size 1024 to 1518
octets: 871
Console#

```


CHAPTER 3

COMMAND LINE INTERFACE

This chapter describes how to use the Command Line Interface (CLI).

Using the Command Line Interface

Accessing the CLI

When accessing the management interface for the switch over a direct connection to the server's console port, or via a Telnet connection, the switch can be managed by entering command keywords and parameters at the prompt. Using the switch's command-line interface (CLI) is very similar to entering commands on a UNIX system.

Console Connection

To access the switch through the console port, perform these steps:

1. At the console prompt, enter the user name and password. (The default user names are "admin" and "guest" with corresponding passwords of "admin" and "guest.") When the administrator user name and password is entered, the CLI displays the "Console#" prompt and enters privileged access mode (i.e., Privileged Exec). But when the guest user name and password is entered, the CLI displays the "Console>" prompt and enters normal access mode (i.e., Normal Exec).
2. Enter the necessary commands to complete your desired tasks.
3. When finished, exit the session with the "quit" or "exit" command.

After connecting to the system through the console port, the login screen displays:

```
User Access Verification

Username: admin
Password:

      CLI session with the SMC8624T is opened.
      To end the CLI session, enter [Exit].

Console#
```

Telnet Connection

Telnet operates over the IP transport protocol. In this environment, your management station and any network device you want to manage over the network must have a valid IP address. Valid IP addresses consist of four numbers, 0 to 255, separated by periods. Each address consists of a network portion and host portion. For example, the IP address assigned to this switch, 10.1.0.1, consists of a network portion (10.1.0) and a host portion (1).

To access the switch through a Telnet session, you must first set the IP address for the switch, and set the default gateway if you are managing the switch from a different IP subnet. For example,

```
Console(config)#interface vlan 1
Console(config-if)#ip address 10.1.0.1 255.255.255.0
Console(config-if)#exit
Console(config)#ip default-gateway 10.1.0.254
```

If your corporate network is connected to another network outside your office or to the Internet, you need to apply for a registered IP address. However, if you are attached to an isolated network, then you can use any IP address that matches the network segment to which you are attached.

After you configure the switch with an IP address, you can open a Telnet session by performing these steps.

1. From the remote host, enter the Telnet command and the IP address of the device you want to access.
2. At the prompt, enter the user name and system password. The CLI will display the “Vty-0#” prompt for the administrator to show that you are using privileged access mode (i.e., Privileged Exec), or “Vty-0>” for the guest to show that you are using normal access mode (i.e., Normal Exec).
3. Enter the necessary commands to complete your desired tasks.
4. When finished, exit the session with the “quit” or “exit” command.

After entering the Telnet command, the login screen displays:

```
Username: admin
Password:

      CLI session with the SMC8624T is opened.
      To end the CLI session, enter [Exit].

Vty-0#
```

Note: You can open up to four sessions to the device via Telnet.

Entering Commands

This section describes how to enter CLI commands.

Keywords and Arguments

A CLI command is a series of keywords and arguments. Keywords identify a command, and arguments specify configuration parameters. For example, in the command “show interfaces status ethernet 1/5,” **show** **interfaces** and **status** are keywords, **ethernet** is an argument that specifies the interface type, and **1/5** specifies the unit/port.

You can enter commands as follows:

- To enter a simple command, enter the command keyword.
- To enter multiple commands, enter each command in the required order. For example, to enable Privileged Exec command mode, and display the startup configuration, enter:

```
Console>enable  
Console#show startup-config
```

- To enter commands that require parameters, enter the required parameters after the command keyword. For example, to set a password for the administrator, enter:

```
Console(config)#username admin password 0 smith
```

Minimum Abbreviation

The CLI will accept a minimum number of characters that uniquely identify a command. For example, the command “configure” can be entered as **config**. If an entry is ambiguous, the system will prompt for further input.

Command Completion

If you terminate input with a Tab key, the CLI will print the remaining characters of a partial keyword up to the point of ambiguity. In the “logging console” example, typing **log** followed by a tab will result in printing the command up to “**logging**.”

Getting Help on Commands

You can display a brief description of the help system by entering the **help** command. You can also display command syntax by using the “?” character to list keywords or parameters.

Showing Commands

If you enter a “?” at the command prompt, the system will display the first level of keywords for the current command class (Normal Exec or Privileged Exec) or configuration class (Global, Interface, Line, or VLAN Database). You can also display a list of valid keywords for a specific command. For example, the command “**show ?**” displays a list of possible show commands:

```

Console#show ?
  bridge          Bridge information
  bridge-ext      Bridge extend information
  garp            Garp property
  gvrp            Show gvrp information of interface
  history         Information of history
  interfaces      Information of interfaces
  ip              Ip
  line            TTY line information
  logging         Show the contents of logging buffers
  map             Map priority
  port            Characteristics of the port
  queue          Information of priority queue
  radius-server   Radius server information
  running-config The system configuration of running
  snmp            SNMP statistics
  startup-config  The system configuration of starting up
  system          Information of system
  users           Display information about terminal lines
  version         System hardware and software status
  vlan           Switch VLAN Virtual Interface
Console#show

```

The command “**show interfaces ?**” will display the following information:

```

Console>show interfaces ?
  counters      Information of interfaces counters
  status        Information of interfaces status
  switchport    Information of interfaces switchport

```

Partial Keyword Lookup

If you terminate a partial keyword with a question mark, alternatives that match the initial letters are provided. (Remember not to leave a space

between the command and question mark.) For example “s?” shows all the keywords starting with “s.”

```
Console#show s?  
snmp          startup-config  system
```

Negating the Effect of Commands

For many configuration commands you can enter the prefix keyword “**no**” to cancel the effect of a command or reset the configuration to the default value. For example, the **logging** command will log system messages to a host server. To disable logging, specify the **no logging** command. This guide describes the negation effect for all applicable commands.

Using Command History

The CLI maintains a history of commands that have been entered. You can scroll back through the history of commands by pressing the up arrow key. Any command displayed in the history list can be executed again, or first modified and then executed.

Using the **show history** command displays a longer list of recently executed commands.

Understanding Command Modes

The command set is divided into Exec and Configuration classes. Exec commands generally display information on system status or clear statistical counters. Configuration commands, on the other hand, modify interface parameters or enable certain switching functions. These classes are further divided into different modes. Available commands depend on the selected mode. You can always enter a question mark “?” at the prompt to display a list of the commands available for the current mode. The

command classes and associated modes are displayed in the following table:

| Class | Mode |
|----------------|------------|
| Exec | Normal |
| | Privileged |
| Configuration* | Global |
| | Interface |
| | Line |
| | VLAN |

* You must be in Privileged Exec mode to access any of the configuration modes.

Exec Commands

When you open a new console session on switch with the user name “guest,” the system enters Normal Exec command mode (or guest mode). Only a limited number of the commands are available in this mode. You can access all the commands only in Privileged Exec command mode (or administrator mode). To access Privilege Exec mode, open a new console session with the user name “admin,” or enter the **enable** command (followed by the privileged level password if so configured). The command prompt displays as “Console>” for Normal Exec mode and “Console#” for Privileged Exec mode.

To enter Privileged Exec mode, enter the following commands and passwords:

```
Username: admin
Password: [system login password]

      CLI session with the SMC8624T is opened.
      To end the CLI session, enter [Exit].

Console#
```

```
Username: guest
Password: [system login password]

    CLI session with the SMC8624T is opened.
    To end the CLI session, enter [Exit].

Console#enable
Password: [privileged level password if so configured]
Console#
```

Configuration Commands

Configuration commands are privileged level commands used to modify switch settings. These commands modify the running configuration only and are not saved when the switch is rebooted. To store the running configuration in nonvolatile storage, use the **copy running-config startup-config** command.

The configuration commands are organized into three different modes:

- Global Configuration - These commands modify the system level configuration, and include commands such as **hostname** and **snmp-server community**.
- Interface Configuration - These commands modify the port configuration such as **speed-duplex** and **negotiation**.
- Line Configuration - These commands modify the console port configuration, and include command such as **parity** and **databits**.

To enter the Global Configuration mode, enter the command **configure** in Privileged Exec mode. The system prompt will change to “Console(config)#” which gives you access privilege to all Global Configuration commands.

```
Console#configure
Console(config)#
```

To enter Interface, Line Configuration, or VLAN mode, you must enter the “**interface ...**,” “**line...**” or “**vlan database**” command while in Global

Configuration mode. The system prompt will change to “Console(config-if)#,” “Console(config-line)#” or Console(config-vlan)” indicating that you have access privileges to the associated commands. You can use the **end** command to return to the Privileged Exec mode.

```
Console(config)#interface ethernet 1/5
Console(config-if)#exit
Console(config)#line console
Console(config-line)#
```

Command Line Processing

Commands are not case sensitive. You can abbreviate commands and parameters as long as they contain enough letters to differentiate them from any other currently available commands or parameters. You can use the Tab key to complete partial commands, or enter a partial command followed by the “?” character to display a list of possible matches. You can also use the following editing keystrokes for command-line processing:

| Keystroke | Function |
|-----------------------------|---|
| Ctrl-A | Shifts cursor to start of command line. |
| Ctrl-B | Shifts cursor to the left one character. |
| Ctrl-E | Shifts cursor to end of command line. |
| Ctrl-F | Shifts cursor to the right one character. |
| Ctrl-P | Shows the last command. |
| Ctrl-U | Deletes the entire line. |
| Ctrl-W | Deletes the last word typed. |
| Delete key or backspace key | Erases a mistake when entering a command. |

Command Groups

The system commands can be broken down into the functional groups shown below.

| Command Group | Description | Page |
|---------------------------|---|-------|
| General | Basic commands for entering privileged access mode, restarting the system, or quitting the CLI | 3-12 |
| Flash/File | Manages code image or switch configuration files | 3-18 |
| System Management | Controls system logs, system passwords, user name, jumbo frame support, browser management options, and a variety of other system information | 3-24 |
| Radius Client | Configures RADIUS client-server authentication for logon access | 3-39 |
| SNMP | Activates authentication failure traps; configures community access strings, and trap managers | 3-44 |
| IP | Configures the IP address and gateway for management access, displays the default gateway, or pings a specified device | 3-50 |
| Line | Sets communication parameters for the serial port, including baud rate and console time-out. | 3-57 |
| Interface | Configures the connection parameters for all Ethernet ports, aggregated links, and VLANs | 3-68 |
| Address Table | Configures the address table for filtering specified addresses, displaying current entries, clearing the table, or setting the aging time | 3-79 |
| Spanning Tree | Configures Spanning Tree settings for the switch | 3-84 |
| VLAN | Configures VLAN settings, and defines port membership for VLAN groups | 3-94 |
| GVRP and Bridge Extension | Configures GVRP settings that permit automatic VLAN learning; shows the configuration for bridge extension MIB | 3-105 |
| IGMP Snooping | Configures IGMP multicast filtering, querier eligibility, query parameters, and specifies ports attached to a multicast router | 3-110 |

| Command Group | Description | Page |
|------------------------|--|-------|
| Priority | Sets port priority for untagged frames, relative weight for each priority queue, also sets priority for IP precedence and DSCP | 3-121 |
| Mirror Port | Mirrors data to another port for analysis without affecting the data passing through or the performance of the monitored port | 3-133 |
| Port Trunking and LACP | Statically groups multiple ports into a single logical trunk; configures Link Aggregation Control Protocol for port trunks | 3-135 |

Note that the access mode shown in the following tables is indicated by these abbreviations:

NE (Normal Exec)

PE (Privileged Exec)

GC (Global Configuration)

IC (Interface Configuration)

LC (Line Configuration)

VC (VLAN Database Configuration)

General Commands

| Command | Function | Mode | Page |
|-----------|--|-------------------|------|
| enable | Activates privileged mode | NE | 3-12 |
| disable | Returns to normal mode from privileged mode | PE | 3-13 |
| configure | Activates global configuration mode | PE | 3-14 |
| reload | Restarts the system | PE | 3-16 |
| end | Returns to Privileged Exec mode | GC, IC, LC, VC | 3-16 |
| exit | Returns to the previous configuration mode, or exits the CLI | any | 3-17 |
| quit | Exits a CLI session | NE, PE | 3-17 |
| help | Shows how to use help | any | NA |
| ? | Shows options for command completion (context sensitive) | any | NA |

enable

Use this command to activate Privileged Exec mode. In privileged mode, additional commands are available, and certain commands display additional information. See “Understanding Command Modes” on page 3-6.

Syntax

enable [*level*]

level - Privilege level to log into the device.

The device has two predefined privilege levels: 0: Normal Exec, 15: Privileged Exec. Enter level 15 to access Privileged Exec mode.

Default Setting

Level 15

Command Mode

Normal Exec

Command Usage

- “super” is the default password required to change the command mode from Normal Exec to Privileged Exec. (To set this password, see the **enable password** command on page 3-27.)
- The “#” character is appended to the end of the prompt to indicate that the system is in privileged access mode.
- You only need to use Level 15. Setting the password for Level 0 has no effect.
- You cannot set a null password with the **enable password** command. You will have to enter a password to access the Privileged Exec mode.

Example

```
Console#enable  
Console#
```

Related Commands

disable
enable password

disable

Use this command to return to Normal Exec mode from privileged mode. In normal access mode, you can only display basic information on the switch's configuration or Ethernet statistics. To gain access to all commands, you must use the privileged mode. See “Understanding Command Modes” on page 3-6.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

The “>” character is appended to the end of the prompt to indicate that the system is in normal access mode.

Example

```
Console#disable  
Console>
```

Related Commands

enable

configure

Use this command to activate Global Configuration mode. You must enter this mode to modify any settings on the switch. You must also enter Global Configuration mode prior to enabling some of the other configuration modes, including Interface Configuration, Line Configuration, and VLAN Database Configuration. See “Understanding Command Modes” on page 3-6.

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#configure  
Console(config)#
```

Related Commands

end

show history

Use this command to show the contents of the command history buffer.

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Command Usage

The history buffer size is fixed at 20 commands.

Example

In this example, the show history command lists the contents of the command history buffer:

```
Console#show history
Execution command history:
 2 config
 1 show history

Configuration command history:
 4 interface vlan 1
 3 exit
 2 interface vlan 1
 1 end

Console#
```

The **!** command repeats commands from the Execution command history buffer when you are in Normal Exec or Privileged Exec Mode, and commands from the Configuration command history buffer when you are in any of the configuration modes. In this example, the **!2** command repeats the second command in the Execution history buffer (**config**).

```
Console#!2
Console#config
Console(config)#
```

reload

Use this command to restart the system.

Note: When the system is restarted, it will always run the Power-On Self-Test. It will also retain all configuration information stored in non-volatile memory by the **copy running-config startup-config** command.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

This command resets the entire system.

Example

This example shows how to reset the switch:

```
Console#reload
System will be restarted, continue <y/n>? y
```

end

Use this command to return to Privileged Exec mode.

Default Setting

None

Command Mode

Global Configuration, Interface Configuration, Line Configuration,
VLAN Database Configuration

Example

This example shows how to return to the Privileged Exec mode from the Interface Configuration mode:

```
Console(config-if)#end
Console#
```

exit

Use this command to return to the previous configuration mode or exit the configuration program.

Default Setting

None

Command Mode

Any

Example

This example shows how to return to the Privileged Exec mode from the Global Configuration mode, and then quit the CLI session:

```
Console(config)#exit
Console#exit

Press ENTER to start session

User Access Verification

Username:
```

quit

Use this command to exit the configuration program.

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Command Usage

The quit and exit commands can both exit the configuration program.

Example

This example shows how to quit a CLI session:

```
Console#quit

Press ENTER to start session

User Access Verification

Username:
```

Flash/File Commands

These commands are used to manage the system code or configuration files.

| Command | Function | Mode | Page |
|-------------|--|------|------|
| copy | Copies a code image or a switch configuration to or from Flash memory or a TFTP server | PE | 3-18 |
| delete | Deletes a file or code image | PE | 3-20 |
| dir | Displays a list of files in Flash memory | PE | 3-21 |
| whichboot | Displays the files booted | PE | 3-22 |
| boot system | Specifies the file or image used to start up the system | GC | 3-23 |

copy

Use this command to move (upload/download) a code image or configuration file between the switch's Flash memory and a TFTP server. When you save the system code or configuration settings to a file on a TFTP server, that file can later be downloaded to the switch to restore system operation. The success of the file transfer depends on the accessibility of the TFTP server and the quality of the network connection.

Syntax

```
copy file {file | running-config | startup-config | tftp}
copy running-config {file | startup-config | tftp}
copy startup-config {file | running-config | tftp}
copy tftp {file | running-config | startup-config}
```

- *file* - Keyword that allows you to copy to/from a file.
- **running-config** - Keyword that allows you to copy to/from the current running configuration.
- **startup-config** - The configuration used for system initialization.
- **tftp** - Keyword that allows you to copy to/from a TFTP server.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

- The system prompts for data required to complete the copy command.
- The destination file name should not contain slashes (\ or /), the leading letter of the file name should not be a period (.), and the length of file name should be 1 to 31 characters. (Valid characters: A-Z, a-z, 0-9, “:”, “-”, “_”)
- The number of user-defined configuration files is limited only by available Flash memory space.
- You can use “Factory_Default_Config.cfg” as the source to copy from the factory default configuration file, but you cannot use “Factory_Default_Config.cfg” as the destination.
- To replace the startup configuration, you must use startup-config as the destination.
- The Boot ROM image cannot be uploaded or downloaded from the TFTP server. You must use a direct console connection and access the download menu during a boot up to download the Boot ROM (or diagnostic) image. See “Upgrading Firmware via the Serial Port” on page A-2 for more details.

Example

The following example shows how to upload the configuration settings to a file on the TFTP server:

```

Console#copy file tftp
Choose file type:
 1. config:  2. opcode: <1-2>: 1
Source file name: startup
TFTP server ip address: 10.1.0.99
Destination file name: startup.01
/
Console#

```

The following example shows how to copy the running configuration to a startup file.

```
Console#copy running-config file
destination file name : startup
/
Console#
```

The following example shows how to download a configuration file:

```
Console#copy tftp startup-config
TFTP server ip address: 10.1.0.99
Source configuration file name: startup.01
Startup configuration file name [startup]:
/
Console#
```

delete

Use this command to delete a file or image.

Syntax

delete *filename*

filename - Name of the configuration file or image name.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

- If the file type is used for system startup, then this file cannot be deleted.
- “Factory_Default_Config.cfg” cannot be deleted.

Example

This example shows how to delete the test2.cfg configuration file from Flash memory.

```
Console#delete test2.cfg
Console#
```

Related Commands

dir

dir

Use this command to display a list of files in Flash memory.

Syntax

dir [**boot-rom** | **config** | **opcode** [:*filename*]]

The type of file or image to display includes:

- **boot-rom** - Boot ROM (or diagnostic) image file
- **config** - Switch configuration file
- **opcode** - Run-time operation code image file.
- *filename* - Name of the file or image. If this file exists but contains errors, information on this file cannot be shown.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

- If you enter the command **dir** without any parameters, the system displays all files.

- File information is shown below:

| Column Heading | Description |
|----------------|--|
| file name | The name of the file. |
| file type | File types: Boot-Rom, Operation Code, and Config file. |
| startup | Shows if this file is used when the system is started. |
| size | The length of the file in bytes. |

Example

The following example shows how to display all file information:

| | | | | |
|-------------|----------------------------|-------------------|---------|-------------|
| Console#dir | | | | |
| | file name | file type | startup | size (byte) |
| | diag_0060 | Boot-Rom image | Y | 111360 |
| | run_01642 | Operation Code | N | 1074304 |
| | run_0200 | Operation Code | Y | 1083008 |
| | Factory_Default_Config.cfg | Config File | N | 2574 |
| | startup | Config File | Y | 2710 |
| | | | | |
| | | Total free space: | | 0 |
| Console# | | | | |

whichboot

Use this command to display which files booted.

Default Setting

None

Command Mode

Privileged Exec

Example

This example shows the information displayed by the **whichboot** command. See the table on the previous page for a description of the file information displayed by this command.

| | | | | |
|-------------------|----------------|---------|-------------|--|
| Console#whichboot | | | | |
| file name | file type | startup | size (byte) | |
| ----- | | | | |
| diag_0060 | Boot-Rom image | Y | 111360 | |
| run_0200 | Operation Code | Y | 1083008 | |
| startup | Config File | Y | 2710 | |
| Console# | | | | |

boot system

Use this command to specify the file or image used to start up the system.

Syntax

boot system {**boot-rom** | **config** | **opcode**}: *filename*

The type of file or image to set as a default includes:

- **boot-rom** - Boot ROM
- **config** - Configuration file
- **opcode** - Run-time operation code

The colon (:) is required.

filename - Name of the configuration file or image name.

Default Setting

None

Command Mode

Global Configuration

Command Usage

- A colon (:) is required after the specified file type.
- If the file contains an error, it cannot be set as the default file.

Example

```
Console(config)#boot system config: startup
Console(config)#
```

Related Commands

dir
whichboot

System Management Commands

These commands are used to control system logs, passwords, user name, browser configuration options, and display or configure a variety of other system information.

| Command | Function | Mode | Page |
|-----------------------------------|--|------|------|
| <i>Device Description Command</i> | | | |
| hostname | Specifies or modifies the host name for the device | GC | 3-25 |
| <i>User Access Commands</i> | | | |
| enable password | Sets a password to control access to various privilege levels | GC | 3-27 |
| <i>Jumbo Frame Command</i> | | | |
| jumbo frame | Allows jumbo frames to pass through the switch | GC | 3-28 |
| <i>Web Server Commands</i> | | | |
| ip http port | Specifies the port to be used by the Web browser interface | GC | 3-29 |
| ip http server | Allows the switch to be monitored or configured from a browser | GC | 3-30 |
| <i>Event Logging Commands</i> | | | |
| logging on | Controls logging of error messages | GC | 3-30 |
| logging history | Limits syslog messages sent to the SNMP network management station based on severity | GC | 3-31 |

| Command | Function | Mode | Page |
|-------------------------------|---|-----------|------|
| clear logging | Clears messages from the logging buffer | PE | 3-33 |
| show logging | Displays the state of logging | PE | 3-33 |
| <i>System Status Commands</i> | | | |
| show startup-config | Displays the contents of the configuration file (stored in Flash memory) that is used to start up the system | PE | 3-34 |
| show running-config | Displays the configuration data currently in use | PE | 3-36 |
| show system | Displays system information | NE, PE | 3-37 |
| show users | Shows all active console and Telnet sessions, including user name, idle time, and IP address of Telnet client | NE, PE | 3-37 |
| show version | Displays version information for the system | NE, PE | 3-38 |

hostname

Use this command to specify or modify the host name for this device. Use the **no** form to restore the default host name.

Syntax

hostname *name*

no hostname

name - The name of this host. (Maximum length: 255 characters)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#hostname SMC8624T
Console(config)#
```

username

Use this command to require user name authentication at login. Use the **no** form to remove a user name.

Syntax

```
username name {access-level level | nopassword | password {0 | 7} password}  
no username name
```

- *name* - The name of the user.
Up to 8 characters, case sensitive.
Maximum number of users: 16
- **access-level** *level* - Specifies the user level.
- The device has two predefined privilege levels:
0: Normal Exec, **15**: Privileged Exec.
- **nopassword** - No password is required for this user to log in.
- **{0 | 7}** - 0 means plain password, 7 means encrypted password.
- **password** *password* - The authentication password for the user.
(Maximum length: 8 characters, case sensitive)

Default Setting

- The default access level is Normal Exec.
- The factory defaults for the user names and passwords are:

| username | access-level | password |
|----------|--------------|----------|
| guest | 0 | guest |
| admin | 15 | admin |

Command Mode

Global Configuration

Command Usage

The encrypted password is required for compatibility with legacy password settings (i.e., plain text or encrypted) when reading the configuration file during system bootup or when downloading the configuration file from a TFTP server. There is no need for you to manually configure encrypted passwords.

Example

This example shows how to set the access level and password for a user.

```
Console(config)#username bob access-level 15
Console(config)#username bob password 0 smith
Console(config)#
```

enable password

After initially logging onto the system, you should set the administrator (Privileged Exec) and guest (Normal Exec) passwords. Remember to record them in a safe place. Use the `enable password` command to set the password for access to the Privileged Exec level from the Normal Exec level. Use the **no** form to reset the default password.

Syntax

```
enable password [level level] {0 | 7} password
no enable password [level level]
```

- **level level** - Level for which the password applies.
- The device has two predefined privilege levels: 0: Normal Exec, 15: Privileged Exec. Only level 15 is valid for this command.
- {**0** | **7**} - 0 means plain password, 7 means encrypted password.
- *password* - password for this privilege level.

Default Setting

This default password is “super”

Command Mode

Global Configuration

Command Usage

The encrypted password is required for compatibility with legacy password settings (i.e., plain text or encrypted) when reading the configuration file during system bootup or when downloading the configuration file from a TFTP server. There is no need for you to manually configure encrypted passwords.

Example

```
Console(config)#enable password level 15 0 admin
Console(config)#
```

Related Commands

enable

jumbo frame

Use this command to enable jumbo frames through the switch. Use the **no** form to disable jumbo frames.

Syntax

jumbo frame
no jumbo frame

Default Setting

Disabled

Command Mode

Global Configuration

Command Usage

- This switch provides more efficient throughput for large sequential data transfers by supporting jumbo frames up to 9000 bytes. Compared to standard Ethernet frames that run only up to 1.5 KB, using jumbo frames significantly reduces the per-packet overhead required to process protocol encapsulation fields.

- To use jumbo frames, both the source and destination end nodes (such as a computer or server) must support this feature. Also, when the connection is operating at full duplex, all switches in the network between the two end nodes must be able to accept the extended frame size. And for half-duplex connections, all devices in the collision domain would need to support jumbo frames.
- Enabling jumbo frames will limit the maximum threshold for broadcast storm control to 64 packets per second. (See the “broadcast” command on page 3-75.)

Example

```
Console(config)#jumbo frame
Console(config)#
```

ip http port

Use this command to specify the TCP port number used by the Web browser interface. Use the **no** form to use the default port.

Syntax

ip http port *port-number*
no ip http port

port-number - The TCP port to be used by the browser interface.
 (Range: 1-65535)

Default Setting

80

Command Mode

Global Configuration

Example

```
Console(config)#ip http port 769
Console(config)#
```

Related Commands

ip http server

ip http server

Use this command to allow this device to be monitored or configured from a browser. Use the **no** form to disable this function.

Syntax

ip http server
no ip http server

Default Setting

Enabled

Command Mode

Global Configuration

Example

```
Console(config)#ip http server
Console(config)#
```

Related Commands

ip http port

logging on

Use this command to control logging of error messages. This command sends debug or error messages to a logging process. The **no** form disables the logging process.

Syntax

logging on
no logging on

Default Setting

None

Command Mode

Global Configuration

Command Usage

The logging process controls error messages to be sent to SNMP trap receivers. You can use the logging history command to control the type of error messages that are stored in memory and sent to a specified SNMP trap receiver.

Example

```
Console(config)#logging on
Console(config)#
```

Related Commands

logging history
clear logging

logging history

Use this command to limit syslog messages sent to the Simple Network Management Protocol network management station based on severity. The **no** form returns the logging of syslog messages to the default level.

Syntax

logging history {**flash** | **ram**} *level*
no logging history {**flash** | **ram**}

- **flash** - Event history stored in Flash memory (i.e., permanent memory).
- **ram** - Event history stored in temporary RAM (i.e., memory flushed on power reset).

- *level* - One of the level arguments listed below. Messages sent include the selected level up through level 0.

| Level Argument | Level | Description | Syslog Definition |
|----------------|-------|----------------------------------|-------------------|
| emergencies | 0 | System unusable | LOG_EMERG |
| alerts | 1 | Immediate action needed | LOG_ALERT |
| critical | 2 | Critical conditions | LOG_CRIT |
| errors | 3 | Error conditions | LOG_ERR |
| warnings | 4 | Warning conditions | LOG_WARNING |
| notifications | 5 | Normal but significant condition | LOG_NOTICE |
| informational | 6 | Informational messages only | LOG_INFO |
| debugging | 7 | Debugging messages | LOG_DEBUG |

Default Setting

Flash: errors (level 3 - 0)

RAM: warnings (level 7 - 0)

Command Mode

Global Configuration

Command Usage

Sending syslog messages to the SNMP network management station occurs when you enable syslog traps with the `snmp enable traps` command.

Example

```
Console(config)#logging history ram 0
Console(config)#
```

Related Commands

`snmp-server enable traps`

`snmp-server host`

clear logging

Use this command to clear messages from the log buffer.

Syntax

clear logging [**flash** | **ram**]

- **flash** - Event history stored in Flash memory (i.e., permanent memory).
- **ram** - Event history stored in temporary RAM (i.e., memory flushed on power reset).

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#clear logging
Console#
```

Related Commands

show logging

show logging

Use this command to display the logging configuration for system and event messages.

Syntax

show logging {**flash** | **ram**}

- **flash** - Event history stored in Flash memory (i.e., permanent memory).
- **ram** - Event history stored in temporary RAM (i.e., memory flushed on power reset).

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show logging flash
Syslog logging: Disable
History logging in FLASH: level errors
Console#
```

show startup-config

Use this command to display the configuration file stored in non-volatile memory that is used to start up the system.

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show startup-config
building startup-config, please wait.....
!
!
snmp-server community private rw
snmp-server community public ro
!
username admin access-level 15
username admin password 7 21232f297a57a5a743894a0e4a801fc3
username guest access-level 0
username guest password 7 084e0343a0486ff05530df6c705c8bb4
enable password level 15 7 1b3231655cebb7a1f783eddf27d254ca
!
vlan database
vlan 1 name DefaultVlan media ethernet state active
!
!
interface ethernet 1/1
switchport allowed vlan add 1 untagged
switchport native vlan 1

.
.
.
.
.
.

interface ethernet 1/24
switchport allowed vlan add 1 untagged
switchport native vlan 1
!
interface vlan 1
ip address 10.1.0.1 255.255.255.0
!
!
line console
!
!
line vty
!
!
end
Console#
```

Related Commands

show running-config

show running-config

Use this command to display the configuration information currently in use.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

Use this command in conjunction with the **show startup-config** command to compare the information in running memory to the information stored in non-volatile memory.

Example

```
Console#show running-config
building running-config, please wait.....
!
!
snmp-server community private rw
snmp-server community public ro

.
.
.
.
.

ip http port
interface vlan 1
 ip address 10.1.0.1 255.255.255.0
!
no bridge 1 spanning-tree
!
line console
!
line vty
!
end
Console#
```

Related Commands

show startup-config

show system

Use this command to display system information.

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Example

```
Console#show system
System description: SMC TigerSwitch - SMC8624T
System OID string: 1.3.6.1.4.1.202.20.25
System information
  System Up time: 0 days, 1 hours, 23 minutes, and 44.61 seconds
  System Name      : SMC switch
  System Location   : Boston
  System Contact    : Charles
  MAC address       : 00-30-f1-47-58-3a
  Web server        : enable
  Web server port   : 80
  POST result       :
UART Loopback Test.....PASS
Timer Test.....PASS
DRAM Test .....PASS
I2C Initialization.....PASS
Runtime Image Check .....PASS
PCI Device Check .....PASS
Switch Driver Initialization.....PASS
Switch Internal Loopback Test.....PASS
----- DONE -----
Console#
```

show users

Shows all active console and Telnet sessions, including user name, idle time, and IP address of Telnet client.

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Example

```
Console#show users
Username accounts:
Username Privilege
-----
    guest          0
    admin          15

Online users:
Line      Username Idle time (h:m:s) Remote IP addr.
-----
* 0   console   admin          0:00:00
  1   vty 0     admin          0:04:37      10.1.0.19

Console#
```

show version

Use this command to display hardware and software version information for the system.

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Example

```
Console#show version
Unit1
Serial number      :A217056372
Service tag        :[NONE]
Hardware version    :R0C
Number of ports     :24
Main power status   :up
Redundant power status :not present
Agent(master)
Unit id            :1
Loader version      :1.0.0.0
Boot rom version    :1.0.0.0
Operation code version :1.0.1.4
Console#
```

RADIUS Client Commands

Remote Authentication Dial-in User Service (RADIUS) is a system that uses a central server running RADIUS software to control access to RADIUS-aware devices on the network. A RADIUS server contains a database of multiple user name/password pairs with associated privilege levels for each user or group that require management access to a switch using the console port, Telnet or Web.

| Command | Function | Mode | Page |
|--------------------------|---|------|------|
| authentication login | Defines logon authentication method and precedence | GC | 3-39 |
| radius-server host | Specifies the RADIUS server | GC | 3-40 |
| radius-server port | Sets the RADIUS server network port | GC | 3-41 |
| radius-server key | Sets the RADIUS encryption key | GC | 3-41 |
| radius-server retransmit | Sets the number of retries | GC | 3-42 |
| radius-server timeout | Sets the interval between sending authentication requests | GC | 3-43 |
| show radius-server | Shows the current RADIUS settings | PE | 3-43 |

authentication login

Use this command to define the login authentication method and precedence. Use the **no** form to restore the default.

Syntax

authentication login {**radius** | **local** | **radius local** | **local radius**}
no authentication login

- **radius** - Use RADIUS server password only.
- **local** - Use local password only.
- **radius local** - Use RADIUS server password first and local password next.
- **local radius** - Use local password first and RADIUS server password next.

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#authentication login radius
Console(config)#
```

Related Commands

username - for setting the local user names and passwords

radius-server host

Use this command to specify the RADIUS server. Use the **no** form to restore the default.

Syntax

radius-server host *host_ip_address*
no radius-server host

host_ip_address - IP address of server.

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#radius-server host 192.168.1.25
Console(config)#
```

radius-server port

Use this command to set the RADIUS server network port. Use the **no** form to restore the default.

Syntax

radius-server port *port_number*
no radius-server port

port_number - RADIUS server UDP port used for authentication messages. (Range: 1-65535)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#radius-server port 181
Console(config)#
```

radius-server key

Use this command to set the RADIUS encryption key. Use the **no** form to restore the default.

Syntax

radius-server key *key_string*
no radius-server key

key_string - Encryption key used to authenticate logon access for client. Do not use blank spaces in the string. (Maximum length: 20 characters)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#radius-server key green
Console(config)#
```

radius-server retransmit

Use this command to set the number of retries. Use the **no** form to restore the default.

Syntax

radius-server retransmit *number_of_retries*
no radius-server retransmit

number_of_retries - Number of times the switch will try to authenticate logon access via the RADIUS server. (Range: 1 - 30)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#radius-server retransmit 5
Console(config)#
```


radius-server timeout

Use this command to set the interval between transmitting authentication requests to the RADIUS server. Use the **no** form to restore the default.

Syntax

radius-server timeout *number_of_seconds*
no radius-server timeout

number_of_seconds - Number of seconds the switch waits for a reply before resending a request. (Range: 1-65535)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#radius-server timeout 10
Console(config)#
```

show radius-server

Use this command to display the current settings for the RADIUS server.

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show radius-server
Server IP address: 10.1.0.99
Communication key with radius server:
Server port number: 1812
Retransmit times: 2
Request timeout: 5
Console#
```

SNMP Commands

Controls access to this switch from SNMP management stations, as well as the error types sent to trap managers.

| Command | Function | Mode | Page |
|--------------------------|---|--------|------|
| snmp-server community | Sets up the community access string to permit access to SNMP commands | GC | 3-44 |
| snmp-server contact | Sets the system contact string | GC | 3-45 |
| snmp-server location | Sets the system location string | GC | 3-46 |
| snmp-server host | Specifies the recipient of an SNMP notification operation | GC | 3-46 |
| snmp-server enable traps | Enables the device to send SNMP traps or inform requests (i.e., SNMP notifications) | GC | 3-48 |
| show snmp | Displays the status of SNMP communications | NE, PE | 3-49 |

snmp-server community

Use this command to define the community access string for the Simple Network Management Protocol. Use the **no** form to remove the specified community string.

Syntax

snmp-server community *string* [**ro** | **rw**]
no snmp-server community *string*

- *string* - Community string that acts like a password and permits access to the SNMP protocol. (Maximum length: 32 characters, case sensitive; Maximum number of strings: 5)
- **ro** - Specifies read-only access. Authorized management stations are only able to retrieve MIB objects.
- **rw** - Specifies read-write access. Authorized management stations are able to both retrieve and modify MIB objects.

Default Setting

- public - Read-only access. Authorized management stations are only able to retrieve MIB objects.
- private - Read-write access. Authorized management stations are able to both retrieve and modify MIB objects.

Command Mode

Global Configuration

Command Usage

The first `snmp-server community` command you enter enables SNMP (SNMPv1). The **no** `snmp-server community` command disables all versions of SNMP.

Example

```
Console(config)#snmp-server community alpha rw
Console(config)#
```

snmp-server contact

Use this command to set the system contact string. Use the **no** form to remove the system contact information.

Syntax

snmp-server contact *string*
no snmp-server contact

string - String that describes the system contact information.
(Maximum length: 255 characters)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#snmp-server contact Paul
Console(config)#
```

Related Commands

snmp-server location

snmp-server location

Use this command to set the system location string. Use the **no** form to remove the location string.

Syntax

snmp-server location *text*

no snmp-server location

text - String that describes the system location.
(Maximum length: 255 characters)

Default Setting

None

Command Mode

Global Configuration

Example

```
Console(config)#snmp-server location WC-19
Console(config)#
```

Related Commands

snmp-server contact

snmp-server host

Use this command to specify the recipient of a Simple Network Management Protocol notification operation. Use the **no** form to remove the specified host.

Syntax

snmp-server host *host-addr community-string*

no snmp-server host *host-addr*

- *host-addr* - Name or Internet address of the host (the targeted recipient). (Maximum host addresses: 5 trap destination ip address entries)
- *community-string* - Password-like community string sent with the notification operation. Though you can set this string using the **snmp-server host** command by itself, we recommend you define this string using the **snmp-server community** command prior to using the **snmp-server host** command. (Maximum length: 32 characters)

Default Setting

None

Command Mode

Global Configuration

Command Usage

If you do not enter an **snmp-server host** command, no notifications are sent. In order to configure the switch to send SNMP notifications, you must enter at least one **snmp-server host** command. In order to enable multiple hosts, you must issue a separate **snmp-server host** command for each host.

The **snmp-server host** command is used in conjunction with the **snmp-server enable traps** command. Use the **snmp-server enable traps** command to specify which SNMP notifications are sent globally. For a host to receive notifications, at least one **snmp-server enable traps** command and the **snmp-server host** command for that host must be enabled.

However, some notification types cannot be controlled with the **snmp-server enable traps** command. For example, some notification types are always enabled.

Example

```
Console(config)#snmp-server host 10.1.19.23 batman
Console(config)#
```

Related Commands

snmp-server enable traps

snmp-server enable traps

Use this command to enable this device to send Simple Network Management Protocol traps or informs (SNMP notifications). Use the **no** form to disable SNMP notifications.

Syntax

snmp-server enable traps [authentication | link-up-down]

no snmp-server enable traps [authentication | link-up-down]

- **authentication** - Keyword to issue authentication failure traps.
- **link-up-down** - Keyword to issue link-up or link-down traps.

Note: The link-up-down trap can only be enabled/disabled via the command line interface.

Default Setting

Issue all traps.

Command Mode

Global Configuration

Command Usage

If you do not enter an **snmp-server enable traps** command, no notifications controlled by this command are sent. In order to configure this device to send SNMP notifications, you must enter at least one **snmp-server enable traps** command. If you enter the command with no keywords, all notification types are enabled. If you enter the command with a keyword, only the notification type related to that keyword is enabled.

The **snmp-server enable traps** command is used in conjunction with the **snmp-server host** command. Use the **snmp-server host** command to specify which host or hosts receive SNMP notifications. In order to send notifications, you must configure at least one **snmp-server host** command.

The notification types used in this command all have an associated MIB object that allows them to be globally enabled or disabled. Not all of the notification types have notificationEnable MIB objects, so some of these cannot be controlled using the **snmp-server enable traps** command.

Example

```
Console(config)#snmp-server enable traps link-up-down
Console(config)#
```

Related Commands

snmp-server host

show snmp

Use this command to check the status of SNMP communications.

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Command Usage

This command provides counter information for SNMP operations.

Example

```
SNMP traps:
  Authentication: enable
  Link-up-down: enable

SNMP communities:
  1. private, and the privilege is read-write
  2. public, and the privilege is read-only

0 SNMP packets input
  0 Bad SNMP version errors
  0 Unknown community name
  0 Illegal operation for community name supplied
  0 Encoding errors
  0 Number of requested variables
  0 Number of altered variables
  0 Get-request PDUs
  0 Get-next PDUs
  0 Set-request PDUs
0 SNMP packets output
  0 Too big errors
  0 No such name errors
  0 Bad values errors
  0 General errors
  0 Response PDUs
  0 Trap PDUs

SNMP logging: disabled
Console#
```

IP Commands

An IP address may be used for management access to the switch over your network. By default, the switch uses DHCP to assign IP settings to VLAN 1 on the switch. If you wish to manually configure IP settings, you need to change the switch’s user-specified defaults (IP address 0.0.0.0 and netmask 255.0.0.0) to values that are compatible with your network. You may also need to establish a default gateway between the switch and management stations that exist on another network segment.

| Command | Function | Mode | Page |
|-----------------|--|------|------|
| ip address | Sets the IP address for this device | IC | 3-51 |
| ip dhcp restart | Submits a BOOTP or DHCP client request | PE | 3-52 |

| Command | Function | Mode | Page |
|-----------------------|---|-----------|------|
| ip default-gateway | Defines the default gateway through which an in-band management station can reach this device | GC | 3-53 |
| show ip interface | Displays the IP settings for this device | PE | 3-54 |
| show ip redirects | Displays the default gateway configured for this device | PE | 3-55 |
| ping | Sends ICMP echo request packets to another node on the network | NE, PE | 3-55 |

ip address

Use this command to set the IP address for this device. Use the **no** form to restore the default IP address.

Syntax

ip address {*ip-address netmask* | **bootp** | **dhcp**}

no ip address

- *ip-address* - IP address
- *netmask* - Network mask for the associated IP subnet. This mask identifies the host address bits used for routing to specific subnets.
- **bootp** - Obtains IP address from BOOTP.
- **dhcp** - Obtains IP address from DHCP.

Default Setting

IP address: 0.0.0.0

Netmask: 255.0.0.0

Command Mode

Interface Configuration (VLAN)

Command Usage

- You must assign an IP address to this device to gain management access over the network. You can manually configure a specific IP address, or direct the device to obtain an address from a BOOTP or DHCP server. Valid IP addresses consist of four numbers, 0 to 255,

separated by periods. Anything outside this format will not be accepted by the configuration program.

- If you select the **bootp** or **dhcp** option, IP is enabled but will not function until a BOOTP or DHCP reply has been received. Requests will be broadcast periodically by this device in an effort to learn its IP address. (BOOTP and DHCP values can include the IP address, default gateway, and subnet mask).
- You can start broadcasting BOOTP or DHCP requests by entering an **ip dhcp restart** command, or by rebooting the switch.

Note: Only one VLAN interface can be assigned an IP address (the default is VLAN 1). This defines the management VLAN, the only VLAN through which you can gain management access to the switch. If you assign an IP address to any other VLAN, the new IP address overrides the original IP address and this becomes the new management VLAN.

Example

In the following example, the device is assigned an address in VLAN 1.

```
Console(config)#interface vlan 1
Console(config-if)#ip address 192.168.1.5 255.255.255.0
Console(config-if)#
```

Related Commands

ip dhcp restart

ip dhcp restart

Use this command to submit a BOOTP or DHCP client request.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

- DHCP requires the server to reassign the client's last address if available.
- If the BOOTP or DHCP server has been moved to a different domain, the network portion of the address provided to the client will be based on this new domain.

Example

In the following example, the device is reassigned the same address.

```
Console(config)#interface vlan 1
Console(config-if)#ip address dhcp
Console(config-if)#exit
Console#ip dhcp restart
Console#show ip interface
IP interface vlan
  IP address and netmask: 10.1.0.54 255.255.255.0 on VLAN 1,
  and address mode: Dhcp.
Console#
```

Related Commands

ip address

ip default-gateway

Use this command to establish a static route between this device and management stations that exist on another network segment. Use the **no** form to remove the static route.

Syntax

ip default-gateway *gateway*
no ip default-gateway

gateway - IP address of the default gateway

Default Setting

No static route is established.

Command Mode

Global Configuration

Command Usage

A gateway must be defined if the management station is located in a different IP segment.

Example

The following example defines a default gateway for this device:

```
Console(config)#ip default-gateway 10.1.0.254
Console(config)#
```

Related Commands

show ip redirects

show ip interface

Use this command to display the settings of an IP interface.

Default Setting

All interfaces

Command Mode

Privileged Exec

Command Usage

This switch can only be assigned one IP address. This address is used for managing the switch.

Example

```
Console#show ip interface
IP address and netmask: 10.1.0.54 255.255.255.0 on VLAN 1,
and address mode: User specified.
Console#
```

Related Commands

show ip redirects

show ip redirects

Use this command to show the default gateway configured for this device.

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show ip redirects
ip default gateway 10.1.0.254
Console#
```

Related Commands

ip default-gateway

ping

Use this command to send ICMP echo request packets to another node on the network.

Syntax

ping *host* [**count** *count*][**size** *size*]

- *host* - IP address or IP alias of the host.
- *count* - Number of packets to send. (Range: 1-16, default: 5)
- *size* - Number of bytes in a packet. (Range: 32-512, default: 32)
The actual packet size will be eight bytes larger than the size specified because the switch adds header information.

Default Setting

This command has no default for the host.

Command Mode

Normal Exec, Privileged Exec

Command Usage

- Use the ping command to see if another site on the network can be reached.
- Following are some results of the ping command:
 - *Normal response* - The normal response occurs in one to ten seconds, depending on network traffic.
 - *Destination does not respond* - If the host does not respond, a “timeout” appears in ten seconds.
 - *Destination unreachable* - The gateway for this destination indicates that the destination is unreachable.
 - *Network or host unreachable* - The gateway found no corresponding entry in the route table.
- Press <Esc> to stop pinging.

Example

```
Console#ping 10.1.0.9
Type ESC to abort.
PING to 10.1.0.9, by 5 32-byte payload ICMP packets, timeout is 5
seconds
response time: 10 ms
response time: 10 ms
response time: 10 ms
response time: 10 ms
response time: 0 ms
Ping statistics for 10.1.0.9:
 5 packets transmitted, 5 packets received (100%), 0 packets lost (0%)
Approximate round trip times:
  Minimum = 0 ms, Maximum = 10 ms, Average = 8 ms
Console#
```

Related Commands

interface

Line Commands

You can access the onboard configuration program by attaching a VT100 compatible device to the server's serial port. These commands are used to set communication parameters for the serial port or a virtual terminal.

Note that Telnet is considered a virtual terminal connection, and the only commands that apply to Telnet include **exec-timeout** and **password-thresh**.

| Command | Function | Mode | Page |
|-----------------|--|-----------|------|
| line | Identifies a specific line for configuration and starts the line configuration mode | GC | 3-58 |
| login | Enables password checking at login | LC | 3-59 |
| password | Specifies a password on a line | LC | 3-60 |
| exec-timeout | Sets the interval that the command interpreter waits until user input is detected | LC | 3-61 |
| password-thresh | Sets the password intrusion threshold, which limits the number of failed logon attempts | LC | 3-62 |
| silent-time | Sets the amount of time the management console is inaccessible after the number of unsuccessful logon attempts exceeds the threshold set by the password-thresh command | LC | 3-63 |
| databits | Sets the number of data bits per character that are interpreted and generated by hardware | LC | 3-64 |
| parity | Defines the generation of a parity bit | LC | 3-65 |
| speed | Sets the terminal baud rate | LC | 3-65 |
| stopbits | Sets the number of the stop bits transmitted per byte | LC | 3-66 |
| show line | Displays a terminal line's parameters | NE, PE | 3-67 |

line

Use this command to identify a specific line for configuration, and to process subsequent line configuration commands.

Syntax

line {**console** | **vty**}

- **console** - Console terminal line.
- **vty** - Virtual terminal for remote console access.

Default Setting

There is no default line.

Command Mode

Global Configuration

Command Usage

Telnet is considered a virtual terminal connection and will be shown as “Vty” in screen displays such as **show users**. However, the serial communication parameters (e.g., databits) do not affect Telnet connections.

Example

To enter console line mode, enter the following command:

```
Console(config)#line console
Console(config-line)#
```

Related Commands

show line
show users

login

Use this command to enable password checking at login. Use the **no** form to disable password checking and allow connections without a password.

Syntax

login [**local**]

no login

local - Selects local password checking. Authentication is based on the user name specified with the **username** command.

Default Setting

By default, virtual terminals require a password. If you do not set a password for a virtual terminal, it will respond to attempted connections by displaying an error message and closing the connection.

Command Mode

Line Configuration

Command Usage

If you specify **login** without the **local** option, authentication is based on the **password** specified with the **password** line configuration command.

Example

```
Console(config-line)#login local
Console(config-line)#
```

Related Commands

username

password

password

Use this command to specify the password for a line. Use the **no** form to remove the password.

Syntax

password {**0** | **7**} *password*

no password

- {**0** | **7**} - 0 means plain password, 7 means encrypted password
- *password* - Character string that specifies the line password. The string can contain any alphanumeric characters, besides spaces, and can contain up to 8 characters. The password is case sensitive.

Default Setting

No password is specified.

Command Mode

Line Configuration

Command Usage

- When a connection is started on a line with password protection, the system prompts for the password. If you enter the correct password, the system shows a prompt. You can use the **password-thresh** command to set the number of times a user can enter an incorrect password before the system terminates the line connection and returns the terminal to the idle state.
- The encrypted password is required for compatibility with legacy password settings (i.e., plain text or encrypted) when reading the configuration file during system bootup or when downloading the configuration file from a TFTP server. There is no need for you to manually configure encrypted passwords.

Example

```
Console(config-line)#password 0 secret
Console(config-line)#
```

Related Commands

login
password-thresh

exec-timeout

Use this command to set the interval that the system waits until user input is detected. Use the **no** form to remove the timeout definition.

Syntax

exec-timeout *seconds*
no exec-timeout

seconds - Integer that specifies the number of seconds.
(Range: 0 - 65535 seconds; 0: no timeout)

Default Setting

CLI: No timeout
Telnet: 10 minutes

Command Mode

Line Configuration

Command Usage

- If input is detected, the system resumes the current connection; or if no connections exist, it returns the terminal to the idle state and disconnects the incoming session.
- This command applies to both the local console and Telnet connections.
- The timeout for Telnet cannot be disabled.

Example

To set the timeout to two minutes, enter this command:

```
Console(config-line)#exec-timeout 120  
Console(config-line)#
```

password-thresh

Use this command to set the password intrusion threshold which limits the number of failed logon attempts. Use the **no** form to remove the threshold value.

Syntax

password-thresh *threshold*

no password-thresh

threshold - The number of allowed password attempts.
(Range: 1-120; 0: no threshold)

Default Setting

The default value is three attempts.

Command Mode

Line Configuration

Command Usage

- When the logon attempt threshold is reached, the system interface becomes silent for a specified amount of time before allowing the next logon attempt. Use the **silent-time** command to set this interval.
- This command applies to both the local console and Telnet connections.

Example

To set the password threshold to five attempts, enter this command:

```
Console(config-line)#password-thresh 5
Console(config-line)#
```

Related Commands

silent-time

silent-time

Use this command to set the amount of time the management console is inaccessible after the number of unsuccessful logon attempts exceeds the threshold set by the **password-thresh** command. Use the **no** form to remove the silent time value.

Syntax

silent-time *seconds*

no silent-time

seconds - The number of seconds to disable console response.
(Range: 0-65535; 0: no silent-time)

Default Setting

The default value is no silent-time.

Command Mode

Line Configuration

Command Usage

If the password threshold was not set with the **password-thresh** command, silent-time begins after the default value of three failed logon attempts.

Example

To set the silent time to 60 seconds, enter this command:

```
Console(config-line)#silent-time 60
Console(config-line)#
```

Related Commands

password-thresh

databits

Use this command to set the number of data bits per character that are interpreted and generated by the console port. Use the **no** form to restore the default value.

Syntax

databits {7 | 8}

no databits

- 7 - Seven data bits per character.
- 8 - Eight data bits per character.

Default Setting

8 data bits per character

Command Mode

Line Configuration

Command Usage

The **databits** command can be used to mask the high bit on input from devices that generate 7 data bits with parity. If parity is being generated, specify 7 data bits per character. If no parity is required, specify 8 data bits per character.

Example

To specify 7 data bits, enter this command:

```
Console(config-line)#databits 7
Console(config-line)#
```

Related Commands

parity

parity

Use this command to define generation of a parity bit. Use the **no** form to restore the default setting.

Syntax

parity {**none** | **even** | **odd**}
no parity

- **none** - No parity
- **even** - Even parity
- **odd** - Odd parity

Default Setting

No parity

Command Mode

Line Configuration

Command Usage

Communication protocols provided by devices such as terminals and modems often require a specific parity bit setting.

Example

To specify no parity, enter this command:

```
Console(config-line)#parity none
Console(config-line)#
```

speed

Use this command to set the terminal line's baud rate. This command sets both the transmit (to terminal) and receive (from terminal) speeds. Use the **no** form to restore the default setting.

Syntax

speed *bps*
no speed

bps - Baud rate in bits per second.

(Options: 9600, 57600, 38400, 19200, 115200 bps)

Default Setting

9600 bps

Command Mode

Line Configuration

Command Usage

Set the speed to match the baud rate of the device connected to the serial port. Some baud rates available on devices connected to the port might not be supported. The system indicates if the speed you selected is not supported.

Example

To specify 57600 bps, enter this command:

```
Console(config-line)#speed 57600
Console(config-line)#
```

stopbits

Use this command to set the number of the stop bits transmitted per byte. Use the **no** form to restore the default setting.

Syntax

stopbits {1 | 2}

- 1 - One stop bit
- 2 - Two stop bits

Default Setting

1 stop bit

Command Mode

Line Configuration

Example

To specify 2 stop bits, enter this command:

```
Console(config-line)#stopbits 2
Console(config-line)#
```

show line

Use this command to display the terminal line's parameters.

Syntax

show line [**console** | **vty**]

- **console** - Console terminal line.
- **vty** - Virtual terminal for remote console access.

Default Setting

Shows all lines

Command Mode

Normal Exec, Privileged Exec

Example

To show all lines, enter this command:

```
Console#show line
Console configuration:
  Password threshold: 3 times
  Interactive timeout: Disabled
  Silent time: Disabled
  Baudrate: 9600
  Databits: 8
  Parity: none
  Stopbits: 1

Vty configuration:
  Password threshold: 3 times
  Interactive timeout: 65535
Console#
```

Interface Commands

These commands are used to display or set communication parameters for an Ethernet port, aggregated link, or VLAN.

| Command | Function | Mode | Page |
|-------------------------------|---|-----------|------|
| interface | Configures an interface type and enters interface configuration mode | GC | 3-69 |
| description | Adds a description to an interface configuration | IC | 3-69 |
| speed-duplex | Configures the speed and duplex operation of a given interface when autonegotiation is disabled | IC | 3-70 |
| negotiation | Enables autonegotiation of a given interface | IC | 3-71 |
| capabilities | Advertises the capabilities of a given interface for use in autonegotiation | IC | 3-72 |
| flowcontrol | Enables flow control on a given interface | IC | 3-73 |
| shutdown | Disables an interface | IC | 3-74 |
| switchport broadcast | Configures broadcast storm control | IC | 3-75 |
| show interfaces status | Displays status for the specified interface | NE, PE | 3-76 |
| show interfaces counters | Displays statistics for the specified interface | NE, PE | 3-77 |
| show interfaces switchport | Displays the administrative and operational status of an interface | NE, PE | 3-78 |

interface

Use this command to configure an interface type and enter interface configuration mode.

Syntax

interface *interface*

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)
- **vlan** *vlan-id* (Range: 1-4094)

Default Setting

None

Command Mode

Global Configuration

Example

To specify the Ethernet port, enter the following command:

```
Console(config)#interface ethernet 1/25
Console(config-if)#
```

description

Use this command to add a description to an interface. Use the **no** form to remove the description.

Syntax

description *string*

no description

string - Comment or a description to help you remember what is attached to this interface. (Range: 1-64 characters)

Default Setting

None

Command Mode

Interface Configuration (Ethernet, Port Channel)

Example

The following example adds a description to Ethernet port 15.

```
Console(config)#interface ethernet 1/15
Console(config-if)#description RD-SW#3
Console(config-if)#
```

speed-duplex

Use this command to configure the speed and duplex mode of a given interface when autonegotiation is disabled. Use the **no** form to restore the default.

Syntax

speed-duplex {1000full | 100full | 100half | 10full | 10half}
no speed-duplex

- **1000full** - Forces 1000 Mbps full-duplex operation
- **100full** - Forces 100 Mbps full-duplex operation
- **100half** - Forces 100 Mbps half-duplex operation
- **10full** - Forces 10 Mbps full-duplex operation
- **10half** - Forces 10 Mbps half-duplex operation

Default Setting

- Auto-negotiation is enabled by default.
- When auto-negotiation is disabled, the default speed-duplex setting is 1000full for Gigabit Ethernet ports.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

To force operation to the speed and duplex mode specified in a speed-duplex command, use the **no negotiation** command to disable auto-negotiation on the selected interface.

Example

The following example configures port 5 to 100 Mbps, half-duplex operation.

```
Console(config)#interface ethernet 1/5
Console(config-if)#speed-duplex 100half
Console(config-if)#no negotiation
Console(config-if)#
```

Related Commands

negotiation

negotiation

Use this command to enable autonegotiation for a given interface. Use the **no** form to disable autonegotiation.

Syntax

negotiation
no negotiation

Default Setting

Enabled

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

If autonegotiation is disabled, auto-MDI/MDI-X pin signal configuration will also be disabled for the RJ-45 ports.

Example

The following example configures port 11 to use autonegotiation.

```
Console(config)#interface ethernet 1/11
Console(config-if)#negotiation
Console(config-if)#
```

capabilities

Use this command to advertise the port capabilities of a given interface during autonegotiation. Use the **no** form with parameters to remove an advertised capability, or the **no** form without parameters to restore the default values.

Syntax

capabilities {**1000full** | **100full** | **100half** | **10full** | **10half** | **flowcontrol** | **symmetric**}

no port-capabilities [**1000full** | **100full** | **100half** | **10full** | **10half** | **flowcontrol** | **symmetric**]

- **1000full** - Supports 1000 Mbps full-duplex operation
- **100full** - Supports 100 Mbps full-duplex operation
- **100half** - Supports 100 Mbps half-duplex operation
- **10full** - Supports 10 Mbps full-duplex operation
- **10half** - Supports 10 Mbps half-duplex operation
- **flowcontrol** - Supports flow control
- **symmetric** - Transmits and receives pause frames for flow control

Default Setting

The default values for Gigabit Ethernet include all settings.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Example

The following example configures Ethernet port 5 capabilities to 100half, 100full and flow control.

```
Console(config)#interface ethernet 1/5
Console(config-if)#capabilities 100half
Console(config-if)#capabilities 100full
Console(config-if)#capabilities flowcontrol
Console(config-if)#
```

flowcontrol

Use this command to enable flow control. Use the **no** form to disable flow control.

Syntax

flowcontrol
no flowcontrol

Default Setting

Flow control enabled

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- Flow control can eliminate frame loss by “blocking” traffic from end stations or segments connected directly to the switch when its buffers fill. When enabled, back pressure is used for half-duplex operation and IEEE 802.3x for full-duplex operation.
- To enable flow control under autonegotiation, **flowcontrol** must be included in the capabilities list for any port.
- To force operation to the mode specified in a **flowcontrol** command, use the **no negotiation** command to disable auto-negotiation on the selected interface.
- Flow control should not be used if a port is connected to a hub. Otherwise flow control signals will be propagated throughout the segment.

- Due to a hardware limitation, flow control only works on those ports located in the same chip (ports 1-12 and ports 13-24). Cross-chip flow control does not work.

Example

The following example enables flow control on port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#flowcontrol
Console(config-if)#no negotiation
Console(config-if)#
```

Related Commands

capabilities (flowcontrol, symmetric)

shutdown

Use this command to disable an interface. To restart a disabled interface, use the **no** form.

Syntax

shutdown
no shutdown

Default Setting

All interfaces are enabled.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

This command allows you to disable a port due to abnormal behavior (e.g., excessive collisions), and then reenable it after the problem has been resolved. You may also want to disable a port for security reasons.

Example

The following example disables port 5.

```
Console(config)#interface ethernet 1/5
Console(config-if)#shutdown
Console(config-if)#
```

switchport broadcast

Use this command to configure broadcast storm control. Use the **no** form to disable broadcast storm control.

Syntax

switchport broadcast packet-rate *rate*
no switchport broadcast

rate - Threshold level as a rate; i.e., packets per second.
(Range: 16, 64, 128, 256)

Default Setting

Enabled for all ports
Packet-rate limit: 256 packets per second

Command Mode

Interface Configuration (Ethernet)

Command Usage

- When broadcast traffic exceeds the specified threshold, packets above that threshold are dropped.
- This command can enable or disable broadcast storm control for the selected interface. However, the specified threshold value applies to all ports on the switch.

Example

The following shows how to configure broadcast storm control at 64 packets per second on port 5:

```
Console(config)#interface ethernet 1/5
Console(config-if)#switchport broadcast packet-rate 64
Console(config-if)#
```

show interfaces status

Use this command to display the status for an interface.

Syntax

show interfaces status *interface*

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)
- **vlan** *vlan-id* (Range: 1-4094)

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Example

```

Console#show interfaces status ethernet 1/7
Information of Eth 1/7
Basic information:
  Port type: 1000t
  Mac address: 00-30-f1-47-58-40
Configuration:
  Name:
  Port admin: Up
  Speed-duplex: Auto
  Capabilities: 10half, 10full, 100half, 100full, 1000full,
  Broadcast storm: Enabled
  Broadcast storm limit: 256 packets/second
  Flow control: Disabled
  LACP: Disabled
Current status:
  Link status: Up
  Port operation status: Up
  Operation speed-duplex: 1000full
  Flow control type: None
Console#

```

show interfaces counters

Use this command to display statistics for an interface.

Syntax

show interfaces counters *interface*

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

None

Command Mode

Normal Exec, Privileged Exec

Example

```
Console#show interfaces counters ethernet 1/7
Ethernet 1/ 7
  Iftable stats:
    Octets input: 30658, Octets output: 196550
    Unicast input: 6, Unicast output: 5
    Discard input: 0, Discard output: 0
    Error input: 0, Error output: 0
    Unknown protos input: 0, QLen output: 0
  Extended iftable stats:
    Multi-cast input: 0, Multi-cast output: 3064
    Broadcast input: 262, Broadcast output: 1
  Ether-like stats:
    Alignment errors: 0, FCS errors: 0
    Single Collision frames: 0, Multiple collision frames: 0
    SQE Test errors: 0, Deferred transmissions: 0
    Late collisions: 0, Excessive collisions: 0
    Internal mac transmit errors: 0, Internal mac receive errors: 0
    Frame too longs: 0, Carrier sense errors: 0
    Symbol errors: 0
  RMON stats:
    Drop events: 0, Octets: 227208, Packets: 3338
    Broadcast pkts: 263, Multi-cast pkts: 3064
    Undersize pkts: 0, Oversize pkts: 0
    Fragments: 0, Jabbers: 0
    CRC align errors: 0, Collisions: 0
    Packet size <= 64 octets: 3150, Packet size 65 to 127 octets: 139
    Packet size 128 to 255 octets: 49, Packet size 256 to 511 octets: 0
    Packet size 512 to 1023 octets: 0, Packet size 1024 to 1518 octets: 0
Console#
```

show interfaces switchport

Use this command to display advanced interface configuration settings.

Syntax

show interfaces switchport [*interface*]

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

Shows all interfaces.

Command Mode

Normal Exec, Privileged Exec

Example

This example shows the configuration setting for Ethernet port 15.

```

Console#show interfaces switchport ethernet 1/15
Information of Eth 1/15
broadcast threshold: Enabled, 256 packets/second
Lacp status: Disabled
VLAN membership mode: Hybrid
Ingress rule: Disabled
Acceptable frame type: All frames
Native VLAN: 1
Priority for untagged traffic: 0
Gvrp status: Enabled
Allowed Vlan: 1(u),
Forbidden Vlan:
Console#

```

Address Table Commands

These commands are used to configure the address table for filtering specified addresses, displaying current entries, clearing the table, or setting the aging time.

| Command | Function | Mode | Page |
|-------------------------|---|------|------|
| bridge address | Maps a static address to a port in a VLAN | GC | 3-80 |
| show bridge | Displays classes of entries in the bridge-forwarding database | PE | 3-81 |
| clear bridge | Removes any learned entries from the forwarding database and clears the transmit and receive counts for any statically or system configured entries | PE | 3-82 |
| bridge-group aging-time | Sets the aging time of the address table | GC | 3-83 |
| show bridge aging-time | Shows the aging time for the address table | PE | 3-83 |

bridge address

Use this command to map a static address to a port in a VLAN. Use the **no** form to remove an address.

Syntax

bridge *bridge-group* **address** *mac-address* **vlan** *vlan-id* **forward** *interface*
[*action*]

no bridge *bridge-group* **address** *address* **vlan** *vlan-id*

- *bridge-group* - Bridge group index (bridge 1).
- *mac-address* - MAC address.
- *vlan-id* - VLAN ID (Range: 1-4094)
- *interface*
 - **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
 - **port-channel** *channel-id* (Range: 1-6)
- *action* -
 - **delete-on-reset** - Assignment lasts until switch is reset.
 - **permanent** - Assignment is permanent.

Default Setting

No static addresses are defined. The default mode is **permanent**.

Command Mode

Global Configuration

Command Usage

The static address for a host device can be assigned to a specific port within a specific VLAN. Use this command to add static addresses to the MAC Address Table. Static addresses have the following characteristics:

- Static addresses will not be removed from the address table when a given interface link is down.

- Static addresses are bound to the assigned interface and will not be moved. When a static address is seen on another interface, the address will be ignored and will not be written to the address table.

Example

```
Console(config)#bridge 1 address 00-e0-29-94-34-de vlan 1 forward
ethernet 1/1 delete-on-reset
Console(config)#
```

show bridge

Use this command to view classes of entries in the bridge-forwarding database.

Syntax

show bridge *bridge-group* [*interface*] [*address* [*mask*]] [**vlan** *vlan-id*]
[sort {address | vlan | interface}]

- *bridge-group* - Bridge group index (bridge 1)
- *interface*
 - **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
 - **port-channel** *channel-id* (Range: 1-6)
- *address* - MAC address.
- *mask* - Bits to ignore in the address.
- *vlan-id* - VLAN ID (Range: 1-4094)
- **sort** - Sort by address, vlan or interface.

Default Setting

None

Command Mode

Privileged Exec

Command Usage

- The MAC Address Table contains the MAC addresses associated with each interface. Note that the Type field may include the following types:
 - Learned - dynamic address entries
 - Permanent - static entry
 - Delete-on-reset - static entry to be deleted when system is reset
- The maximum number of address entries is 8191.

Example

```
Console#show bridge 1
Interface Mac Address      Vlan Type
-----
Eth 1/ 1 00-e0-29-94-34-de 1 Delete-on-reset
Console#
```

clear bridge

Use this command to remove any learned entries from the forwarding database and to clear the transmit and receive counts for any static or system configured entries.

Syntax

clear bridge [*bridge-group*]

bridge-group - Bridge group index (bridge 1).

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#clear bridge 1
Console#
```


bridge-group aging-time

Use this command to set the aging time for entries in the address table.
Use the **no** form to restore the default aging time.

Syntax

bridge-group *bridge-group* **aging-time** *seconds*

no bridge-group *bridge-group* **aging-time**

- *bridge-group* - Bridge group index (bridge 1).
- *seconds* - Time is number of seconds (17-2184).

Default Setting

300 seconds

Command Mode

Global Configuration

Command Usage

The aging time is used to age out dynamically learned forwarding information.

Example

```
Console(config)#bridge-group 1 aging-time 100
Console(config)#
```

show bridge group aging-time

Use this command to show the aging time for entries in the address table.

Syntax

show bridge group *bridge-group* **aging-time**

bridge-group - Bridge group index (bridge 1)

Default Setting

None

Command Mode

Privileged Exec

Example

| |
|--|
| Console#show bridge group 1 aging-time Aging time: 300 sec. Console# |
|--|

Spanning Tree Commands

This section includes commands that configure the Spanning Tree Algorithm (STA) globally for the switch, and commands that configure STA for the selected interface.

| Command | Function | Mode | Page |
|------------------------|--|------|------|
| bridge spanning-tree | Enables the spanning tree protocol | GC | 3-86 |
| bridge forward-time | Configures the spanning tree bridge forward time | GC | 3-86 |
| bridge hello-time | Configures the spanning tree bridge hello time | GC | 3-87 |
| bridge max-age | Configures the spanning tree bridge maximum age | GC | 3-87 |
| bridge priority | Configures the spanning tree bridge priority | GC | 3-88 |
| bridge-group path-cost | Configures the spanning tree path cost of an interface | IC | 3-89 |
| bridge-group priority | Configures the spanning tree priority of an interface | IC | 3-90 |
| bridge-group portfast | Sets an interface to fast forwarding | IC | 3-91 |
| show bridge group | Shows spanning tree configuration for the overall bridge or a selected interface | PE | 3-92 |

bridge spanning-tree

Use this command to enable STA globally for the switch. Use the **no** form to disable it.

Syntax

bridge *bridge-group* **spanning-tree**
no bridge *bridge-group* **spanning-tree**

bridge-group - Bridge group index (bridge 1).

Default Setting

Spanning tree is enabled.

Command Mode

Global Configuration

Command Usage

The Spanning Tree Algorithm (STA) can be used to detect and disable network loops, and to provide backup links between switches, bridges or routers. This allows the switch to interact with other bridging devices (that is, an STA-compliant switch, bridge or router) in your network to ensure that only one route exists between any two stations on the network, and provide backup links which automatically take over when a primary link goes down.

Example

The following example shows how to enable the Spanning Tree Algorithm for the switch:

```
Console(config)#bridge 1 spanning-tree  
Console(config)#
```

bridge forward-time

Use this command to configure the spanning tree bridge forward time globally for this switch. Use the **no** form to restore the default.

Syntax

bridge *bridge-group* **forward-time** *seconds*

no bridge *bridge-group* **forward-time**

- *bridge-group* - Bridge group index (bridge 1).
- *seconds* - Time in seconds. (Range: 4 - 30 seconds)
- The minimum value is the higher of 4 or $[(\text{max-age} / 2) + 1]$.

Default Setting

15 seconds

Command Mode

Global Configuration

Command Usage

This command sets the maximum time (in seconds) the root device will wait before changing states (i.e., listening to learning to forwarding). This delay is required because every device must receive information about topology changes before it starts to forward frames. In addition, each port needs time to listen for conflicting information that would make it return to a blocking state; otherwise, temporary data loops might result.

Example

```
Console(config)#bridge 1 forward-time 20
Console(config)#
```

bridge hello-time

Use this command to configure the spanning tree bridge hello time globally for this switch. Use the **no** form to restore the default.

Syntax

bridge *bridge-group* **hello-time** *time*

no bridge *bridge-group* **hello-time**

bridge-group - Bridge group index (bridge 1).

time - Time in seconds, (range: 1 - 10 seconds).

The maximum value is the lower of 10 or $[(\text{max-age} / 2) - 1]$.

Default Setting

2 seconds

Command Mode

Global Configuration

Command Usage

This command sets the time interval (in seconds) at which the root device transmits a configuration message.

Example

```
Console(config)#bridge 1 hello-time 5
Console(config)#
```

bridge max-age

Use this command to configure the spanning tree bridge maximum age globally for this switch. Use the **no** form to restore the default.

Syntax

bridge *bridge-group* **max-age** *seconds*

no bridge *bridge-group* **max-age**

- *bridge-group* - Bridge group index (bridge 1).
- *seconds* - Time in seconds. (Range: 6-40 seconds)

- The minimum value is the higher of 6 or $[2 \times (\text{hello-time} + 1)]$.
- The maximum value is the lower of 40 or $[2 \times (\text{forward-time} - 1)]$.

Default Setting

20 seconds

Command Mode

Global Configuration

Command Usage

This command sets the maximum time (in seconds) a device can wait without receiving a configuration message before attempting to reconfigure. All device ports (except for designated ports) should receive configuration messages at regular intervals. Any port that ages out STA information (provided in the last configuration message) becomes the designated port for the attached LAN. If it is a root port, a new root port is selected from among the device ports attached to the network.

Example

```
Console(config)#bridge 1 max-age 40
Console(config)#
```

bridge priority

Use this command to configure the spanning tree priority globally for this switch. Use the **no** form to restore the default.

Syntax

bridge *bridge-group* **priority** *priority*
no bridge *bridge-group* **priority**

- *bridge-group* - Bridge group index (bridge 1).
- *priority* - Priority of the bridge. (Range: 0 - 65535)

Default Setting

32768

Command Mode

Global Configuration

Command Usage

Bridge priority is used in selecting the root device, root port, and designated port. The device with the highest priority becomes the STA root device. However, if all devices have the same priority, the device with the lowest MAC address will then become the root device.

Example

```
Console(config)#bridge 1 priority 40000
Console(config)#
```

bridge-group path-cost

Use this command to configure the spanning tree path cost for the specified interface. Use the **no** form to restore the default.

Syntax

bridge-group *bridge-group* **path-cost** *cost*

no bridge-group *bridge-group* **path-cost**

- *bridge-group* - Bridge group index (bridge 1).
- *cost* - The path cost for the port. (Range: 1-65535)

The recommended range is:

- Ethernet: 50-600
- Fast Ethernet: 10-60
- Gigabit Ethernet: 3-10

Default Setting

- Ethernet – half duplex: 100; full duplex: 95; trunk: 90
- Fast Ethernet – half duplex: 19; full duplex: 18; trunk: 15
- Gigabit Ethernet – full duplex: 4; trunk: 3

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- This command is used by the spanning-tree algorithm to determine the best path between devices. Therefore, lower values should be assigned to ports attached to faster media, and higher values assigned to ports with slower media.
- Path cost takes precedence over port priority.

Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#bridge-group 1 path-cost 50
Console(config-if)#
```

bridge-group priority

Use this command to configure the priority for the specified port. Use the **no** form to restore the default.

Syntax

bridge-group *bridge-group* **priority** *priority*
no bridge-group *bridge-group* **priority**

- *bridge-group* - Bridge group index (bridge 1).
- *priority* - The priority for a port. (Range: 0-255)

Default Setting

128

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- This command defines the priority for the use of a port in the spanning-tree algorithm. If the path cost for all ports on a switch are the same, the port with the highest priority (that is, lowest value) will be configured as an active link in the spanning tree.
- Where more than one port is assigned the highest priority, the port with lowest numeric identifier will be enabled.

Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#bridge-group 1 priority 0
Console(config-if)#
```

bridge-group portfast

Use this command to set a port to fast forwarding. Use the no form to disable fast forwarding.

Syntax

bridge-group *bridge-group* **portfast**
no bridge-group *bridge-group* **portfast**

bridge-group - Bridge group index (bridge 1).

Default Setting

Disabled

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- This command is used to enable/disable the fast spanning-tree mode for the selected port. In this mode, ports skip the Blocked, Listening and Learning states and proceed straight to Forwarding.
- Since end-nodes cannot cause forwarding loops, they can be passed through the spanning tree state changes more quickly than allowed by standard convergence time. Fast forwarding can achieve quicker convergence for end-node workstations and servers, and also overcome other STA related timeout problems. (Remember that fast forwarding should only be enabled for ports connected to an end-node device.)

Example

```
Console(config)#interface ethernet 1/5
Console(config-if)#bridge-group 1 portfast
Console(config-if)#
```

show bridge group

Use this command to show the spanning tree configuration.

Syntax

show bridge group *bridge-group* [*interface*]

- *bridge-group* - Bridge group index (bridge 1).
- *interface*
 - **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
 - **port-channel** *channel-id* (Range: 1-6)

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show bridge group 1 ethernet 1/11
Bridge-group information
-----
Spanning tree protocol           :ieee8021d
Spanning tree enable/disable    :enable
Priority                         :32768
Hello Time (sec.)               :2
Max Age (sec.)                  :20
Forward Delay (sec.)            :15
Designated Root                 :32768.0000e9000066
Curent root                     :0
Curent root cost                 :0
Number of topology changes      :1
Last topology changes time (sec.):2167
Hold times (sec.)               :1
-----
Eth 1/11 information
-----
Admin status                    : enable
STA state                       : broken
Path cost                       : 18
Priority                         : 128
Designated cost                 : 0
Designated port                 : 128.11
Designated root                 : 40000.123412341234
Designated bridge               :32768.0000e9000066
Fast forwarding                 :disable
Forward transitions              :0
Console#
```

VLAN Commands

A VLAN is a group of ports that can be located anywhere in the network, but communicate as though they belong to the same physical segment. This section describes commands used to create VLAN groups, add port members, specify how VLAN tagging is used, and enable automatic VLAN registration for the selected interface.

| Command | Function | Mode | Page |
|-----------------------------------|--|------|-------|
| <i>Edit VLAN Groups</i> | | | |
| vlan database | Enters VLAN database mode to add, change, and delete VLANs | GC | 3-95 |
| vlan | Configures a VLAN, including VID, name and state | VC | 3-96 |
| <i>Configure VLAN Interfaces</i> | | | |
| interface vlan | Enters interface configuration mode for specified VLAN | IC | 3-97 |
| switchport mode | Configures VLAN membership mode for an interface | IC | 3-98 |
| switchport acceptable-frame-types | Configures frame types to be accepted by an interface | IC | 3-99 |
| switchport ingress-filtering | Enables ingress filtering on an interface | IC | 3-100 |
| switchport native vlan | Configures the PVID (native VLAN) of an interface | IC | 3-101 |
| switchport allowed vlan | Configures the VLANs associated with an interface | IC | 3-102 |
| switchport gvrp | Enables GVRP for an interface | IC | 3-105 |
| switchport forbidden vlan | Configures forbidden VLANs for an interface | IC | 3-103 |

| Command | Function | Mode | Page |
|---------------------------------|---|-----------|-------|
| <i>Display VLAN Information</i> | | | |
| show vlan | Shows VLAN information | NE, PE | 3-104 |
| show interfaces status vlan | Displays status for the specified VLAN interface | NE, PE | 3-76 |
| show interfaces switchport | Displays the administrative and operational status of an interface | NE, PE | 3-78 |

vlan database

Use this command to enter VLAN database mode. All commands in this mode will take effect immediately.

Default Setting

None

Command Mode

Global Configuration

Command Usage

- Use the VLAN database command mode to add, change, and delete VLANs. After finishing configuration changes, you can display the VLAN settings by entering the **show vlan** command.
- Use the **interface vlan** command mode to define the port membership mode and add or remove ports from a VLAN. The results of these commands are written to the running-configuration file, and you can display this file by entering the **show running-config** command.

Example

```
Console(config)#vlan database
Console(config-vlan)#
```

Related Commands

show vlan

vlan

Use this command to configure a VLAN. Use the **no** form to restore the default settings or delete a VLAN.

Syntax

vlan *vlan-id* [**name** *vlan-name*] **media ethernet** [**state** {**active** | **suspend**}]

no vlan *vlan-id* [**name** | **state**]

- *vlan-id* - ID of configured VLAN. (Range: 1-4094, no leading zeroes)
- **name** - Keyword to be followed by the VLAN name.
 - *vlan-name* - ASCII string from 1 to 32 characters.
- **media ethernet** - Ethernet media type.
- **state** - Keyword to be followed by the VLAN state.
 - **active** - VLAN is operational.
 - **suspend** - VLAN is suspended. Suspended VLANs do not pass packets.

Default Setting

By default only VLAN 1 exists and is active.

Command Mode

VLAN Database Configuration

Command Usage

- When **no vlan** *vlan-id* is used, the VLAN is deleted.
- When **no vlan** *vlan-id* **name** is used, the VLAN name is removed.
- When **no vlan** *vlan-id* **state** is used, the VLAN returns to the default state (i.e., active).
- You can configure up to 255 VLANs on the switch.

Example

The following example adds a VLAN, using vlan-id 105 and name RD5. The VLAN is activated by default.

```
Console(config)#vlan database
Console(config-vlan)#vlan 105 name RD5 media ethernet
Console(config-vlan)#
```

Related Commands

show vlan

interface vlan

Use this command to enter interface configuration mode for VLANs, and configure a physical interface.

Syntax

interface vlan *vlan-id*

vlan-id - ID of the configured VLAN. (Range: 1-4094, no leading zeroes)

Default Setting

None

Command Mode

Global Configuration

Example

The following example shows how to set the interface configuration mode to VLAN 1, and then assign an IP address to the VLAN:

```
Console(config)#interface vlan 1
Console(config-if)#ip address 192.168.1.254 255.255.255.0
Console(config-if)#
```

Related Commands

shutdown

switchport mode

Use this command to configure the VLAN membership mode for a port.
Use the **no** form to restore the default.

Syntax

switchport mode {trunk | hybrid}
no switchport mode

- **trunk** - Specifies a port as an end-point for a VLAN trunk. A trunk is a direct link between two switches, so the port transmits and receives tagged frames that identify the source VLAN.
- **hybrid** - Keyword that specifies a hybrid VLAN interface. The port may receive or transmit tagged or untagged frames. Any frames that are not tagged will be assigned to the default VLAN.

Default Setting

All ports are in hybrid mode with the PVID set to VLAN 1.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

This command and the **switchport acceptable-frame-types** command have the same effect.

Example

The following shows how to set the configuration mode to port 1, and then set the switchport mode to hybrid:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport mode hybrid
Console(config-if)#
```

Related Commands

switchport acceptable-frame-types

switchport acceptable-frame-types

Use this command to configure the acceptable frame types for a port. Use the **no** form to restore the default.

Syntax

```
switchport acceptable-frame-types {all | tagged}  
no switchport acceptable-frame-types
```

- **all** - The port passes all frames, tagged or untagged.
- **tagged** - The port only passes tagged frames.

Default Setting

All frame types

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- If a port is connected to a VLAN-aware device at the other end of a VLAN trunk, you can set the port to pass only tagged frames. Otherwise, you must configure the port to pass all frame types.
- This command and the **switchport mode** command have the same effect.

Example

The following example shows how to restrict the traffic passed on port 1 to tagged frames:

```
Console(config)#interface ethernet 1/1  
Console(config-if)#switchport acceptable-frame-types tagged  
Console(config-if)#
```

Related Commands

switchport mode

switchport ingress-filtering

Use this command to enable ingress filtering for an interface. Use the **no** form to restore the default.

Syntax

```
switchport ingress-filtering
no switchport ingress-filtering
```

Default Setting

Disabled

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- If ingress filtering is enabled, incoming frames for VLANs which do not include this ingress port in their member set will be discarded at the ingress port.
- Ingress filtering does not affect VLAN independent BPDU frames, such as GVRP or STA. However, they do affect VLAN dependent BPDU frames, such as GMRP.

Example

The following example shows how to set the interface to port 1 and then enable ingress filtering:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport ingress-filtering
Console(config-if)#
```

switchport native vlan

Use this command to configure the PVID (i.e., default VLAN ID) for a port. Use the **no** form to restore the default.

Syntax

switchport native vlan *vlan-id*
no switchport native vlan

vlan-id - Default VLAN ID for a port. (Range: 1-4094, no leading zeroes)

Default Setting

VLAN 1

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- If the switchport mode is set to **trunk**, the PVID will be inserted into all untagged frames sent from a tagged port.
- If ingress filtering is disabled, all untagged frames received on this port will be assigned to the VLAN indicated by the PVID.

Example

The following example shows how to set the PVID for port 1 to VLAN 3:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport native vlan 3
Console(config-if)#
```

switchport allowed vlan

Use this command to configure VLAN groups on the selected interface.
Use the **no** form to restore the default.

Syntax

switchport allowed vlan {**add** *vlan-list* [**tagged** | **untagged**] |
remove *vlan-list*}
no switchport allowed vlan

- **add** *vlan-list* - List of VLAN identifiers to add.
- **remove** *vlan-list* - List of VLAN identifiers to remove.
Separate nonconsecutive VLAN identifiers with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeros. (Range: 1-4094)

Default Setting

All ports are assigned to VLAN 1 by default.
The default frame type is untagged.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

You must enter the switchport mode command before the switchport allowed vlan command can take effect.

Example

The following example shows how to add VLANs 1, 2, 5 and 6 to the allowed list as tagged VLANs for port 1:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport allowed vlan add 1,2,5,6 tagged
Console(config-if)#
```

switchport forbidden vlan

Use this command to configure forbidden VLANs. Use the **no** form to remove the list of forbidden VLANs.

Syntax

switchport forbidden vlan {**add** *vlan-list* | **remove** *vlan-list*}
no switchport forbidden vlan

- **add** *vlan-list* - List of VLAN IDs to add.
 - **remove** *vlan-list* - List of VLAN IDs to remove.
- Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs. Do not enter leading zeroes. (Range: 1-4094)

Default Setting

No VLANs are included in the forbidden list.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

This command prevents a VLAN from being automatically added to the specified interface via GVRP.

Example

The following example shows how to prevent port 1 from being added to VLAN 3:

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport forbidden vlan add 3
Console(config-if)#
```

show vlan

Use this command to show VLAN information.

Syntax

```
show vlan [id vlan-id | name vlan-name]
```

- **id** - Keyword to be followed by the VLAN ID.
 - *vlan-id* - ID of the configured VLAN. (Range: 1-4094, no leading zeroes)
- **name** - Keyword to be followed by the VLAN name.
 - *vlan-name* - ASCII string from 1 to 32 characters.

Default Setting

Shows all VLANs.

Command Mode

Normal Exec, Privileged Exec

Example

The following example shows how to display information for VLAN 1:

```
Console#show vlan id 1
VLAN Type      Name           Status  Ports/Channel groups
-----
  1  Static      DefaultVlan    Active  Eth1/ 1 Eth1/ 2 Eth1/ 3 Eth1/ 4 Eth1/ 5
                                   Eth1/ 6 Eth1/ 7 Eth1/ 8 Eth1/ 9 Eth1/10
                                   Eth1/11 Eth1/12 Eth1/13 Eth1/14 Eth1/15
                                   Eth1/16 Eth1/17 Eth1/18 Eth1/19 Eth1/20
                                   Eth1/21 Eth1/22 Eth1/23 Eth1/24
Console#
```

GVRP and Bridge Extension Commands

GARP VLAN Registration Protocol defines a way for switches to exchange VLAN information in order to automatically register VLAN members on interfaces across the network. This section describes how to enable GVRP for individual interfaces and globally for the switch, as well as how to display default configuration settings for the Bridge Extension MIB.

| Command | Function | Mode | Page |
|---------------------------|--|--------|-------|
| <i>Interface Commands</i> | | | |
| switchport gvrp | Enables GVRP for an interface | IC | 3-105 |
| switchport forbidden vlan | Configures forbidden VLANs for an interface | IC | 3-103 |
| show gvrp configuration | Displays GVRP configuration for selected interface | NE, PE | 3-106 |
| garp timer | Sets the GARP timer for the selected function | IC | 3-107 |
| show garp timer | Shows the GARP timer for the selected function | NE, PE | 3-108 |
| <i>Global Commands</i> | | | |
| bridge-ext gvrp | Enables GVRP globally for the switch | GC | 3-109 |
| show bridge-ext | Shows bridge extension configuration | PE | 3-109 |

switchport gvrp

Use this command to enable GVRP for a port. Use the **no** form to disable it.

Syntax

```
switchport gvrp
no switchport gvrp
```

Default Setting

Disabled

Command Mode

Interface Configuration (Ethernet, Port Channel)

Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#switchport gvrp
Console(config-if)#
```

show gvrp configuration

Use this command to show if GVRP is enabled.

Syntax

show gvrp configuration [*interface*]

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

Shows both global and interface-specific configuration.

Command Mode

Normal Exec, Privileged Exec

Example

```
Console#show gvrp configuration ethernet 1/7
Eth 1/ 7:
  Gvrp configuration: Disabled
Console#
```


garp timer

Use this command to set the values for the join, leave and leaveall timers.
Use the **no** form to restore the timers' default values.

Syntax

```
garp timer {join | leave | leaveall} timer_value  
no garp timer {join | leave | leaveall}
```

- {**join** | **leave** | **leaveall**} - Which timer to set.
- *timer_value* - Value of timer.
Ranges:
join: 20-1000 centiseconds
leave: 60-3000 centiseconds
leaveall: 500-18000 centiseconds

Default Setting

- join: 20 centiseconds
- leave: 60 centiseconds
- leaveall: 1000 centiseconds

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- Group Address Registration Protocol is used by GVRP and GMRP to register or deregister client attributes for client services within a bridged LAN. The default values for the GARP timers are independent of the media access method or data rate. These values should not be changed unless you are experiencing difficulties with GMRP or GVRP registration/deregistration.
- Timer values are applied to GVRP for all the ports on all VLANs.
- Timer values must meet the following restrictions:
leave >= (3 x join)
leaveall > leave

Note: Set GVRP timers on all Layer 2 devices connected in the same network to the same values. Otherwise, GVRP will not operate successfully.

Example

```
Console(config)#interface ethernet 1/1
Console(config-if)#garp timer join 100
Console(config-if)#
```

Related Commands

show garp timer

show garp timer

Use this command to show the GARP timers for the selected interface.

Syntax

show garp timer [*interface*]

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

Shows all GARP timers.

Command Mode

Normal Exec, Privileged Exec

Example

```
Console#show garp timer ethernet 1/1
Eth 1/ 1 GARP timer status:
Join timer: 20 centiseconds
Leave timer: 60 centiseconds
Leaveall timer: 1000 centiseconds
Console#
```

Related Commands

garp timer

bridge-ext gvrp

Use this command to enable GVRP. Use the **no** form to disable it.

Syntax

bridge-ext gvrp
no bridge-ext gvrp

Default Setting

Disabled

Command Mode

Global Configuration

Command Usage

GVRP defines a way for switches to exchange VLAN information in order to register VLAN members on ports across the network. This function should be enabled to permit automatic VLAN registration, and to support VLANs which extend beyond the local switch.

Example

```
Console(config)#bridge-ext gvrp
Console(config)#
```

show bridge-ext

Use this command to show the configuration for bridge extension commands.

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show bridge-ext
Max support vlan numbers: 255
Max support vlan ID: 4094
Extended multicast filtering services: No
Static entry individual port: Yes
VLAN learning: IVL
Configurable PVID tagging: Yes
Local VLAN capable: No
Traffic classes: Enabled
Global GVRP status: Disabled
GMRP: Disabled
Console#
```

IGMP Snooping Commands

This switch uses IGMP (Internet Group Management Protocol) to query for any attached hosts that want to receive a specific multicast service. It identifies the ports containing hosts requesting a service and sends data out to those ports only. It then propagates the service request up to any neighboring multicast switch/router to ensure that it will continue to receive the multicast service.

| Command | Function | Mode | Page |
|------------------------------|--|------|-------|
| <i>Basic IGMP Commands</i> | | | |
| ip igmp snooping | Enables IGMP snooping | GC | 3-111 |
| ip igmp snooping vlan static | Adds an interface as a member of a multicast group | GC | 3-112 |
| ip igmp snooping version | Configures the IGMP version for snooping | GC | 3-113 |
| show ip igmp snooping | Shows the IGMP snooping configuration | PE | 3-113 |
| show bridge multicast | Shows the IGMP snooping MAC multicast list | PE | 3-114 |
| <i>IGMP Querier Commands</i> | | | |
| ip igmp snooping querier | Allows this device to act as the querier for IGMP snooping | GC | 3-115 |
| ip igmp snooping query-count | Configures the query count | GC | 3-116 |

| Command | Function | Mode | Page |
|--|---------------------------------------|------|-------|
| ip igmp snooping query-interval | Configures the query interval | GC | 3-116 |
| ip igmp snooping query-max-response-time | Configures the report delay | GC | 3-117 |
| ip igmp snooping query-time-out | Configures the query timeout | GC | 3-118 |
| show ip igmp snooping | Shows the IGMP snooping configuration | PE | 3-113 |
| <i>Multicast Router Commands</i> | | | |
| ip igmp snooping vlan mrouter | Adds a multicast router port | GC | 3-119 |
| show ip igmp snooping mrouter | Shows multicast router ports | PE | 3-120 |

ip igmp snooping

Use this command to enable IGMP snooping on this switch. Use the **no** form to disable it.

Syntax

ip igmp snooping
no ip igmp snooping

Default Setting

Enabled

Command Mode

Global Configuration

Example

The following example enables IGMP snooping.

```
Console(config)#ip igmp snooping
Console(config)#
```

ip igmp snooping vlan static

Use this command to add a port to a multicast group. Use the no form to remove the port.

Syntax

ip igmp snooping vlan *vlan-id* static *ip-address* *interface*
no ip igmp snooping vlan *vlan-id* static *ip-address* *interface*

- *vlan-id* - VLAN ID (Range: 1-4094)
- *ip-address* - IP address for multicast group
- *interface*
 - **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
 - **port-channel** *channel-id* (Range: 1-6)

Default Setting

None

Command Mode

Global Configuration

Example

The following shows how to statically configure a multicast group on a port:

```
Console(config)#ip igmp snooping vlan 1 static 224.0.0.12 ethernet  
1/5  
Console(config)#
```

ip igmp snooping version

Use this command to configure the IGMP snooping version. Use the **no** form to restore the default.

Syntax

ip igmp snooping version {1 | 2}

no ip igmp snooping version

- 1 - IGMP Version 1
- 2 - IGMP Version 2

Default Setting

IGMP Version 2

Command Mode

Global Configuration

Command Usage

- All systems on the subnet must support the same version. If there are legacy devices in your network that only support Version 1, you will also have to configure this switch to use Version 1.
- Some commands are only enabled for IGMPv2, including **ip igmp query-max-response-time** and **ip igmp query-timeout**.

Example

The following configures the switch to use IGMP Version 1:

```
Console(config)#ip igmp snooping version 1
Console(config)#
```

show ip igmp snooping

Use this command to show the IGMP snooping configuration.

Default Setting

None

Command Mode

Privileged Exec

Example

The following shows the current IGMP snooping configuration:

```
Console#show ip igmp snooping
Service status: Enabled
Querier status: Enabled
Query count: 2
Query interval: 125 sec
Query max response time: 10 sec
Query time-out: 300 sec
IGMP snooping version: Version 2
Console#
```

show bridge multicast

Use this command to show known multicast addresses.

Syntax

show bridge *bridge-group* **multicast** [**vlan** *vlan-id*]
[**user** | **igmp-snooping**]

- *bridge-group* - Bridge group index.
- *vlan-id* - VLAN ID (1 to 4094)
- **user** - Display only the user-configured multicast entries.
- **igmp-snooping** - Display only entries learned through IGMP snooping.

Default Setting

None

Command Mode

Privileged Exec

Example

The following shows the multicast entries learned through IGMP snooping for bridge group 1, VLAN 1:

```
Console#show bridge 1 multicast vlan 1 igmp-snooping
VLAN M'cast IP addr. Member ports Type
-----
1      224.1.2.3      Eth1/11      IGMP
Console#
```

ip igmp snooping querier

Use this command to enable the switch as an IGMP snooping querier. Use the **no** form to disable it.

Syntax

```
ip igmp snooping querier
no ip igmp snooping querier
```

Default Setting

Enabled

Command Mode

Global Configuration

Command Usage

If enabled, the switch will serve as querier if elected. The querier is responsible for asking hosts if they want to receive multicast traffic.

Example

```
Console(config)#ip igmp snooping querier
Console(config)#
```

ip igmp snooping query-count

Use this command to configure the query count. Use the **no** form to restore the default.

Syntax

ip igmp snooping query-count *count*
no ip igmp snooping query-count

count - The maximum number of queries issued for which there has been no response before the switch takes action to solicit reports. (Range: 2-10)

Default Setting

2 times

Command Mode

Global Configuration

Example

The following shows how to configure the query count to 10:

```
Console(config)#ip igmp snooping query-count 10
Console(config)#
```

ip igmp snooping query-interval

Use this command to configure the snooping query interval. Use the **no** form to restore the default.

Syntax

ip igmp snooping query-interval *seconds*
no ip igmp snooping query-interval

seconds - The frequency at which the switch sends IGMP host-query messages. (Range: 60-125)

Default Setting

125 seconds

Command Mode

Global Configuration

Example

The following shows how to configure the query interval to 100 seconds:

```
Console(config)#ip igmp snooping query-interval 100
Console(config)#
```

ip igmp snooping query-max-response-time

Use this command to configure the snooping report delay. Use the **no** form of this command to restore the default.

Syntax

ip igmp snooping query-max-response-time *seconds*

no ip igmp snooping query-max-response-time

seconds - The report delay advertised in IGMP queries. (Range: 5-30)

Default Setting

10 seconds

Command Mode

Global Configuration

Command Usage

- The switch must be using IGMPv2 for this command to take effect.
- The command sets the time the switch waits after receiving an IGMP report (for an IP multicast address) on a port before it sends an IGMP Query out that port and then removes the entry from its list.

Example

The following shows how to configure the maximum response time to 20 seconds:

```
Console(config)#ip igmp snooping query-max-response-time 20
Console(config)#
```

Related Commands

ip igmp snooping version

ip igmp snooping query-time-out

Use this command to configure the snooping query-timeout. Use the no form of this command to restore the default.

Syntax

ip igmp snooping query-time-out *seconds*
no ip igmp snooping query-time-out

seconds - The time the switch waits after the previous querier has stopped querying before it takes over as the querier. (Range: 300-500)

Default Setting

300 seconds

Command Mode

Global Configuration

Command Usage

The switch must be using IGMPv2 for this command to take effect.

Example

The following shows how to configure the default timeout to 300 seconds:

```
Console(config)#ip igmp snooping query-time-out 300
Console(config)#
```

Related Commands

ip igmp snooping version

ip igmp snooping vlan mrouter

Use this command to statically configure a multicast router port. Use the **no** form to remove the configuration.

Syntax

ip igmp snooping vlan *vlan-id* **mrouter** *interface*
no ip igmp snooping vlan *vlan-id* **mrouter** *interface*

- *vlan-id* - VLAN ID (Range: 1-4094)
- *interface*
 - **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
 - **port-channel** *channel-id* (Range: 1-6)

Default Setting

No static multicast router ports are configured.

Command Mode

Global Configuration

Command Usage

Depending on your network connections, IGMP snooping may not always be able to locate the IGMP querier. Therefore, if the IGMP querier is a known multicast router/switch connected over the network to an interface (port or trunk) on your switch, you can manually configure that interface to join all the current multicast groups.

Example

The following shows how to configure port 11 as a multicast router port within VLAN 1:

```
Console(config)#ip igmp snooping vlan 1 mrouter ethernet 1/11
Console(config)#
```

show ip igmp snooping mrouter

Use this command to display information on statically configured and dynamically learned multicast router ports.

Syntax

show ip igmp snooping mrouter [**vlan** *vlan-id*]

vlan-id - VLAN ID (Range: 1-4094)

Default Setting

Displays multicast router ports for all configured VLANs.

Command Mode

Privileged Exec

Example

The following shows the port in VLAN 1 that is attached to a multicast router:

```
Console#show ip igmp snooping mrouter vlan 1
VLAN M'cast Router Ports Type
-----
    1                Eth 1/11  Static
Console#
```

Priority Commands

The commands described in this section allow you to specify which data packets have greater precedence when traffic is buffered in the switch due to congestion. This switch supports CoS with four priority queues for each port. Data packets in a port's high-priority queue will be transmitted before those in the lower-priority queues. You can set the default priority for each interface, the relative weight of each queue, and the mapping of frame priority tags to the switch's priority queues.

| Command | Function | Mode | Page |
|--|--|------|-------|
| <i>Layer 2 Priority Commands</i> | | | |
| switchport priority default | Sets a port priority for incoming untagged frames | IC | 3-122 |
| queue bandwidth | Assigns round-robin weights to the priority queues | GC | 3-123 |
| queue cos map | Assigns class of service values to the priority queues | IC | 3-124 |
| show queue bandwidth | Shows round-robin weights assigned to the priority queues | PE | 3-125 |
| show queue cos-map | Shows the class of service map | PE | 3-126 |
| show interfaces switchport | Displays the administrative and operational status of an interface | PE | 3-78 |
| <i>Layer 3 and 4 Priority Commands</i> | | | |
| map ip precedence | Enables IP precedence class of service mapping | GC | 3-127 |
| map ip precedence | Maps IP precedence value to a class of service | IC | 3-127 |
| map ip dscp | Enables IP DSCP class of service mapping | GC | 3-129 |
| map ip dscp | Maps IP DSCP value to a class of service | IC | 3-129 |
| show map ip precedence | Shows the IP precedence map | PE | 3-131 |
| show map ip dscp | Shows the IP DSCP map | PE | 3-132 |

switchport priority default

Use this command to set a priority for incoming untagged frames, or the priority of frames received by the device connected to the specified interface. Use the **no** form to restore the default value.

Syntax

switchport priority default *default-priority-id*

no switchport priority default

default-priority-id - The priority number for untagged ingress traffic. The priority is a number from 0 to 7. Seven is the highest priority.

Default Setting

The priority is not set, and the default value for untagged frames received on the interface is zero. The switch is not instructed what to do with the priority.

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- The precedence for priority mapping is IP Precedence or IP DSCP, and default switchport priority.
- The default port priority applies if the incoming frame is an untagged frame received from a VLAN trunk or a static-access port. This priority does not apply to IEEE 802.1Q VLAN tagged frames. If the incoming frame is an IEEE 802.1Q VLAN tagged frame, the IEEE 802.1p User Priority bits will be used.
- This switch provides four priority queues for each port. It is configured to use Weighted Round Robin, which can viewed with the **queue bandwidth** command. Inbound frames that do not have VLAN tags are tagged with the input port's default ingress user priority, and then placed in the appropriate priority queue at the output port. The default priority for all ingress ports is zero. Therefore, any inbound frames that do not have priority tags will be placed in queue 0 of the output port. (Note that if the output port is an untagged member of the associated

VLAN, these frames are stripped of all VLAN tags prior to transmission.)

Example

The following example shows how to set a default priority on port 3 to 5:

```
Console(config)#interface ethernet 1/3
Console(config-if)#switchport priority default 5
```

queue bandwidth

Use this command to assign Weighted Round-Robin (WRR) weights to the four class of service (CoS) priority queues. Use the **no** form to restore the default weights.

Syntax

queue bandwidth *weight1...weight4*
no queue bandwidth

weight1...weight4 - The ratio of weights for queues 0 - 3 determines the weights used by the WRR scheduler. (Range: 1 - 255)

Default Setting

Weights 16, 64, 128 and 240 are assigned to queue 0, 1, 2 and 3 respectively.

Command Mode

Global Configuration

Command Usage

WRR allows bandwidth sharing at the egress port by defining scheduling weights.

Example

The following example shows how to assign WRR weights of 1, 3, 5 and 7 to the CoS priority queues 0, 1, 2 and 3:

```
Console(config)#queue bandwidth 1 3 5 7
Console(config)#
```

Related Commands

show queue bandwith

queue cos-map

Use this command to assign class of service (CoS) values to the CoS priority queues. Use the **no** form set the CoS map to the default values.

Syntax

queue cos-map *queue_id* [*cos1* ... *cosn*]
no queue cos-map

- *queue_id* - The queue id of the CoS priority queue.
 - Ranges are 0 to 3, where 3 is the highest CoS priority queue.
- *cos1* .. *cosn* - The CoS values that are mapped to the queue id. It is a space-separated list of numbers. The CoS value is a number from 0 to 7, where 7 is the highest priority.

Default Setting

This switch supports Class of Service by using four priority queues, with Weighted Round Robin for each port. Eight separate traffic classes are defined in IEEE 802.1p. The default priority levels are assigned according to recommendations in the IEEE 802.1p standard as shown in the following table.

| | Queue | | | |
|----------|-------|---|---|---|
| | 1 | 2 | 3 | 4 |
| Priority | | 0 | | |
| | 1 | | | |
| | 2 | | | |
| | | 3 | | |
| | | | 4 | |
| | | | 5 | |
| | | | | 6 |
| | | | | 7 |

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

CoS assigned at the ingress port is used to select a CoS priority at the egress port.

Example

The following example shows how to map CoS values 0, 1 and 2 to CoS priority queue 0, value 3 to CoS priority queue 1, values 4 and 5 to CoS priority queue 2, and values 6 and 7 to CoS priority queue 3:

```
Console(config)#interface ethernet 1/1
Console(config-if)#queue cos-map 0 0 1 2
Console(config-if)#queue cos-map 1 3
Console(config-if)#queue cos-map 2 4 5
Console(config-if)#queue cos-map 3 6 7
Console(config-if)#
```

Related Commands

show queue cos-map

show queue bandwidth

Use this command to display the Weighted Round-Robin (WRR) bandwidth allocation for the four class of service (CoS) priority queues.

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show queue bandwidth
Queue ID Weight
-----
      0      1
      1      4
      2     16
      3     64
Console#
```

show queue cos-map

Use this command to show the class of service priority map.

Syntax

show queue cos-map [*interface*]

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show queue cos-map ethernet 1/11
Information of Eth 1/11
Queue ID Traffic class
-----
      0      1 2
      1      0 3
      2      4 5
      3      6 7
Console#
```

map ip precedence (Global Configuration)

Use this command to enable IP precedence mapping (i.e., IP Type of Service). Use the **no** form to disable IP precedence mapping.

Syntax

```
map ip precedence
no map ip precedence
```

Default Setting

Disabled

Command Mode

Global Configuration

Command Usage

- The precedence for priority mapping is IP Precedence or IP DSCP, and default switchport priority.
- IP Precedence and IP DSCP cannot both be enabled. Enabling one of these priority types will automatically disable the other type.

Example

The following example shows how to enable IP precedence mapping globally:

```
Console(config)#map ip precedence
Console(config)#
```

map ip precedence (Interface Configuration)

Use this command to set IP precedence priority (i.e., IP Type of Service priority). Use the **no** form to restore the default table.

Syntax

```
map ip precedence ip-precedence-value cos cos-value
no map ip precedence
```

- *precedence-value* - 3-bit precedence value. (Range: 0-7)

- *cos-value* - Class-of-Service value (Range: 0-7)

Default Setting

The list below shows the default priority mapping.

| IP Precedence Value | CoS Value |
|---------------------|-----------|
| 0 | 0 |
| 1 | 1 |
| 2 | 2 |
| 3 | 3 |
| 4 | 4 |
| 5 | 5 |
| 6 | 6 |
| 7 | 7 |

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- The precedence for priority mapping is IP Precedence or IP DSCP, and default switchport priority.
- IP Precedence values are mapped to default Class of Service values on a one-to-one basis according to recommendations in the IEEE 802.1p standard, and then mapped to the queue defaults.
- This command sets the IP Precedence for all interfaces.

Example

The following example shows how to map IP precedence value 1 to CoS value 0:

```
Console(config)#interface ethernet 1/5
Console(config-if)#map ip precedence 1 cos 0
Console(config-if)#
```

map ip dscp (Global Configuration)

Use this command to enable IP DSCP mapping (i.e., Differentiated Services Code Point mapping). Use the **no** form to disable IP DSCP mapping.

Syntax

```
map ip dscp
no map ip dscp
```

Default Setting

Enabled

Command Mode

Global Configuration

Command Usage

- The precedence for priority mapping is IP Precedence or IP DSCP, and default switchport priority.
- IP Precedence and IP DSCP cannot both be enabled. Enabling one of these priority types will automatically disable the other type.

Example

The following example shows how to enable IP DSCP mapping globally:

```
Console(config)#map ip dscp
Console(config)#
```

map ip dscp (Interface Configuration)

Use this command to set IP DSCP priority (i.e., Differentiated Services Code Point priority). Use the **no** form to restore the default table.

Syntax

```
map ip dscp dscp-value cos cos-value
no map ip dscp
```

- *dscp-value* - 8-bit DSCP value. (Range: 0-255)

- *cos-value* - Class-of-Service value (Range: 0-7)

Default Setting

The list below shows the default priority mapping. Note that all the DSCP values that are not specified are mapped to CoS value 0.

| IP DSCP Value | CoS Value |
|------------------------|-----------|
| 0 | 0 |
| 8 | 1 |
| 10, 12, 14, 16 | 2 |
| 18, 20, 22, 24 | 3 |
| 26, 28, 30, 32, 34, 36 | 4 |
| 38, 40, 42 | 5 |
| 48 | 6 |
| 46, 56 | 7 |

Command Mode

Interface Configuration (Ethernet, Port Channel)

Command Usage

- The precedence for priority mapping is IP Port, IP Precedence or IP DSCP, and default switchport priority.
- DSCP priority values are mapped to default Class of Service values according to recommendations in the IEEE 802.1p standard, and then mapped to the queue defaults.
- This command sets the DSCP Priority for all interfaces.

Example

The following example shows how to map IP DSCP value 1 to CoS value 0:

```
Console(config)#interface ethernet 1/5
Console(config-if)#map ip dscp 1 cos 0
Console(config-if)#
```


show map ip precedence

Use this command to show the IP precedence priority map.

Syntax

show map ip precedence [*interface*]

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show map ip precedence ethernet 1/5
Precedence mapping status: disabled
```

| Port | Precedence | COS |
|----------|------------|-----|
| Eth 1/ 5 | 0 | 0 |
| Eth 1/ 5 | 1 | 1 |
| Eth 1/ 5 | 2 | 2 |
| Eth 1/ 5 | 3 | 3 |
| Eth 1/ 5 | 4 | 4 |
| Eth 1/ 5 | 5 | 5 |
| Eth 1/ 5 | 6 | 6 |
| Eth 1/ 5 | 7 | 7 |

```
Console#
```

Related Commands

map ip precedence - Maps CoS values to IP precedence values.

show map ip dscp

Use this command to show the IP DSCP priority map.

Syntax

show map ip dscp [*interface*]

interface

- **ethernet** *unit/port*
 - *unit* - This is device 1.
 - *port* - Port number.
- **port-channel** *channel-id* (Range: 1-6)

Default Setting

None

Command Mode

Privileged Exec

Example

```
Console#show map ip dscp ethernet 1/1
DSCP mapping status: disabled

Port          DSCP COS
-----
Eth 1/ 1      0    0
Eth 1/ 1      1    0
Eth 1/ 1      2    0
Eth 1/ 1      3    0
.
.
.
Eth 1/ 1      62   0
Eth 1/ 1      63   0
Console#
```

Related Commands

map ip dscp - Maps CoS values to IP DSCP values.

Mirror Port Commands

This section describes how to configure port mirror sessions.

| Command | Function | Mode | Page |
|-------------------|---|------|-------|
| port monitor | Configures a mirror session | IC | 3-133 |
| show port monitor | Shows the configuration for a mirror port | PE | 3-134 |

port monitor

Use this command to configure a mirror session. Use the **no** form to clear a mirror session.

Syntax

port monitor *interface* [**rx** | **tx** | **both**]

no port monitor *interface*

- *interface* - **ethernet** *unit/port* (source port)
 - *unit* - Switch (unit 1).
 - *port* - Port number.
- **rx** - Mirror received packets.
- **tx** - Mirror transmitted packets.
- **both** - Mirror both received and transmitted packets.

Default Setting

No mirror session is defined. When enabled, the default mirroring is for both received and transmitted packets.

Command Mode

Interface Configuration (Ethernet, destination port)

Command Usage

- You can mirror traffic from any source port to a destination port for real-time analysis. You can then attach a logic analyzer or RMON probe to the destination port and study the traffic crossing the source port in a completely unobtrusive manner.

- The destination port is set by specifying an Ethernet interface.
- You can create only one port mirror session.
- The source and destination ports have to be either both in the port range 1-12 or both in the port range 13-24.

Example

The following example configures the switch to mirror all packets from port 6 to port 11:

```
Console(config)#interface ethernet 1/11
Console(config-if)#port monitor ethernet 1/6 both
Console(config-if)#
```

Related Commands

show port monitor

show port monitor

Use this command to display mirror information.

Syntax

show port monitor [*interface*]

interface - **ethernet** *unit/port* (source port)

- *unit* - Switch (unit 1).
- *port* - Port number.

Default Setting

Shows all sessions.

Command Mode

Privileged Exec

Example

The following shows mirroring configured from port 6 to port 11:

```
Console(config)#interface ethernet 1/11
Console(config-if)#port monitor ethernet 1/6
Console(config-if)#end
Console#show port monitor
Port Mirroring
-----
Destination port(listen port):Eth1/1
Source port(monitored port) :Eth1/6
Mode                        :RX/TX
Console#
```

Related Commands

port monitor

Port Trunking Commands

Ports can be statically grouped into an aggregate link to increase the bandwidth of a network connection or to ensure fault recovery. Or you can use the Link Aggregation Control Protocol (LACP) to automatically negotiate a trunk link between this switch and another network device. You can configure trunks between switches of the same type. This switch supports up to six trunks. For example, a trunk consisting of two 1000 Mbps ports can support an aggregate bandwidth of 4 Gbps when operating at full duplex.

| Command | Function | Mode | Page |
|--------------------------------------|--|------|-------|
| <i>Manual Configuration Commands</i> | | | |
| interface port-channel | Configures a trunk and enters interface configuration mode for the trunk | GC | 3-69 |
| channel-group | Adds a port to a trunk | IC | 3-136 |
| <i>Dynamic Configuration Command</i> | | | |
| lacp | Configures LACP for the current interface | IC | 3-137 |

| Command | Function | Mode | Page |
|--|-------------------------|-----------|------|
| <i>Trunk Status Display Command</i> | | | |
| show interfaces status port-channel | Shows trunk information | NE, PE | 3-76 |

channel-group

Use this command to add a port to a trunk. Use the **no** form to remove a port from a trunk.

Syntax

channel-group *channel-id*
no channel-group

channel-id - Trunk index (Range: 1-6)

Default Setting

A new trunk contains no ports.

Command Mode

Interface Configuration (Ethernet)

Command Usage

- The maximum number of ports that can be combined as a static trunk is four 10/100 Mbps ports, and two 1000 Mbps ports.
- All links in a trunk must operate at the same data rate and duplex mode.

Example

The following example creates trunk 1 and then adds port 11:

```
Console(config)#interface port-channel 1
Console(config-if)#exit
Console(config)#interface ethernet 1/11
Console(config-if)#channel-group 1
Console(config-if)#
```

lacp

Use this command to enable 802.3ad Link Aggregation Control Protocol (LACP) for the current interface. Use the **no** form to disable it.

Syntax

lacp
no lacp

Default Setting

Disabled

Command Mode

Interface Configuration (Ethernet)

Command Usage

- Finish configuring a port trunk before you connect the corresponding network cables between switches.
- You can configure up to six trunks, containing up to four ports as a dynamic LACP trunk.
- All ports in the same trunk must consist of the same media type (i.e., twisted-pair or fiber).
- The ports on both ends of trunk must be configured the same for speed and flow control.
- The ports on both ends of trunk must also be configured for full duplex, either by forced mode or auto-negotiation.
- If the target switch has also enabled LACP on the connected ports, the trunk will be activated.
- If more than four ports attached to the same target switch have LACP enabled, the additional ports will be placed in standby mode, and will only be enabled if one of the active links fails.
- STP, VLAN and IGMP settings can only be made for the entire trunk via the specified port-channel.
- A trunk formed with another switch using LACP will automatically be assigned the next available port-channel id.

Example

The following shows LACP enabled on ports 11-13. Because LACP has also been enabled on the ports at the other end of the links, the show interfaces status port-channel 1 command shows that Trunk1 has been established.

```
Console(config)#interface ethernet 1/11
Console(config-if)#lacp
Console(config-if)#exit
Console(config)#interface ethernet 1/12
Console(config-if)#lacp
Console(config-if)#exit
Console(config)#interface ethernet 1/13
Console(config-if)#lacp
Console(config-if)#exit
Console(config)#exit
Console#show interfaces status port-channel 1
Information of Trunk 1
Basic information:
  Port type: 1000t
  Mac address: 00-00-e8-00-00-0b
Configuration:
  Name:
  Port admin status: Up
  Speed-duplex: Auto
  Capabilities: 10half, 10full, 100half, 100full, 1000full,
  Flow control status: Disabled
Current status:
  Created by: lacp
  Link status: Up
  Operation speed-duplex: 1000full
  Flow control type: None
  Member Ports: Eth1/11, Eth1/12, Eth1/13,
Console#
```


APPENDIX A

TROUBLESHOOTING

Troubleshooting Chart

| Troubleshooting Chart | |
|---|--|
| Symptom | Action |
| Cannot connect using Telnet, Web browser, or SNMP software | <ul style="list-style-type: none">• Be sure to have configured the agent with a valid IP address, subnet mask and default gateway.• Be sure that your management station has management VLAN access to the switch (default is VLAN 1).• Check that you have a valid network connection to the switch and that the port you are using has not been disabled.• Check network cabling between the management station and the switch.• If you cannot connect using Telnet, you may have exceeded the maximum number of concurrent Telnet sessions permitted. Try connecting again at a later time. |
| Cannot access the on-board configuration program via a serial port connection | <ul style="list-style-type: none">• Be sure to have set the terminal emulator program to VT100 compatible, 8 data bits, 1 stop bit, no parity and 9600 bps.• Check that the null-modem serial cable conforms to the pin-out connections provided in Appendix B. |
| Forgot or lost the password | <ul style="list-style-type: none">• Reinstall the switch defaults or runtime code. Make a direct connection to the switch's console port and power cycle the switch. During the POST diagnostics, access the firmware-download menu and select the appropriate options. See "Upgrading Firmware via the Serial Port" on page A-2 for more details. |

Upgrading Firmware via the Serial Port

The switch contains two firmware components that can be upgraded; the diagnostics (or Boot-ROM) code and runtime operation code. The runtime code can be upgraded via the switch's RS-232 serial console port, via a network connection to a TFTP server, or using SNMP management software. The diagnostics code can be upgraded only via the switch's RS-232 serial console port.

Note: You can use the switch's web interface to download runtime code via TFTP. Downloading large runtime code files via TFTP is normally much faster than downloading via the switch's serial port.

You can upgrade switch firmware by connecting a PC directly to the serial Console port on the switch's front panel and using VT100 terminal emulation software that supports the XModem protocol. (See "Required Connections" on page 1-3.)

1. Connect a PC to the switch's Console port using a null-modem or crossover RS-232 cable with a female DB-9 connector.
2. Configure the terminal emulation software's communication parameters to 9600 baud, 8 data bits, 1 stop bit, no parity, and set flow control to *none*.
3. Power cycle the switch.
4. When the switch initialization screen appears, enter firmware-download mode by pressing <Ctrl><f> immediately after the diagnostic test results. Screen text similar to that shown below displays:

| File Name | S/Up Type Size | | Create Time |
|-----------------------------|----------------|--------------------|------------------|
| ----- | | | |
| \$logfile_1 | 0 | 3 | 64 00:00:07 |
| \$logfile_2 | 0 | 3 | 64 00:00:12 |
| diag_0070 | 0 | 1 | 96500 00:06:37 |
| diag_0074 | 1 | 1 | 97780 00:00:05 |
| run_03024 | 0 | 2 | 1121956 00:21:41 |
| run_10020 | 1 | 2 | 1124416 00:00:10 |
| ----- | | | |
| [X]modem Download | [D]elete File | [S]et Startup File | |
| [R]eturn to Factory Default | | [C]hange Baudrate | [Q]uit |
| Select> | | | |

5. Press <c> to change the baud rate of the switch's serial connection.
6. Press to select the option for 115200 baud.

There are two baud rate settings available, 9600 and 115200. Using the higher baud rate minimizes the time required to download firmware code files.

7. Set your PC's terminal emulation software to match the 115200 baud rate. Press <Enter> to reset communications with the switch.

```
Select>
Change baudrate [A]9600 [B]115200
Baudrate set to 115200
```

8. Check that the switch has sufficient flash memory space for the new code file before starting the download.

You can store a maximum of only two runtime and two diagnostic code files in the switch's flash memory. Use the **[D]elete File** command to remove a runtime or diagnostic file that is not set as the startup file (the **S/Up** setting for the file is "0").

9. Press <x> to start to download the new code file.

If using Windows HyperTerminal, click the “Transfer” button, and then click “Send File...” Select the XModem Protocol and then use the “Browse” button to select the required firmware code file from your PC system. The “Xmodem file send” window displays the progress of the download procedure.

Note: The download file must be a SMC8624T binary software file from SMC.

10. After the file has been downloaded, you are prompted with “Update Image File:” to specify the type of code file. Press <r> for runtime code, or <d> for diagnostic code.
11. Specify a name for the downloaded code file. Filenames can be up to 32 characters, are case-sensitive, and cannot contain spaces.

For example, the following screen text shows the download procedure for a runtime code file:

```
Select>x
Xmodem Receiving Start ::
      [R]untime
      [D]iagnostic
Update Image File:r
Runtime Image Filename : run_10030
Updating file system.
File system updated.
[Press any key to continue]
```

12. To set the new downloaded file as the startup file, use the **[S]et Startup File** menu option.
13. When you have finished downloading code files, use the **[C]hange Baudrate** menu option to change the baud rate of the switch’s serial connection back to 9600 baud.
14. Set your PC’s terminal emulation software baud rate back to 9600 baud. Press <Enter> to reset communications with the switch.

15. Press <q> to quit the firmware-download mode and boot the switch.

APPENDIX B

PIN ASSIGNMENTS

Console Port Pin Assignments

The DB-9 serial port on the switch's front panel is used to connect to the switch for out-of-band console configuration. The onboard menu-driven configuration program can be accessed from a terminal, or a PC running a terminal emulation program. The pin assignments used to connect to the serial port are provided in the following tables.




Figure B-1. DB-9 Console Port Pin Numbers

DB-9 Port Pin Assignments

| EIA Circuit | CCITT Signal | Description | Switch's DB9 DTE Pin # | PC DB9 DTE Pin # |
|-------------|--------------|-------------------------------|------------------------|------------------|
| BB | 104 | RxD (Received Data) | 2 | 2 |
| BA | 103 | TxD (Transmitted Data) | 3 | 3 |
| AB | 102 | SGND (Signal Ground) | 5 | 5 |

No other pins are used.

Console Port to 9-Pin DTE Port on PC

| Switch's 9-Pin Serial Port | Null Modem | PC's 9-Pin DTE Port |
|----------------------------|-----------------|---------------------|
| 2 RXD | <-----TXD ----- | 3 TXD |
| 3 TXD | -----RXD -----> | 2 RXD |
| 5 SGND | -----SGND ----- | 5 SGND |

No other pins are used.

Console Port to 25-Pin DTE Port on PC

| Switch's 9-Pin Serial Port | Null Modem | PC's 25-Pin DTE Port |
|----------------------------|-----------------|----------------------|
| 2 RXD | <-----TXD ----- | 2 TXD |
| 3 TXD | -----RXD -----> | 3 RXD |
| 5 SGND | -----SGND ----- | 7 SGND |

No other pins are used.

GLOSSARY

10BASE-T

IEEE 802.3 specification for 10 Mbps Ethernet over two pairs of Category 3, 4, or 5 UTP cable.

100BASE-TX

IEEE 802.3u specification for 100 Mbps Fast Ethernet over two pairs of Category 5 UTP cable.

1000BASE-T

IEEE 802.3ab specification for Gigabit Ethernet over two pairs of Category 5, 5e 100-ohm UTP cable.

1000BASE-X

IEEE 802.3 shorthand term for any 1000 Mbps Gigabit Ethernet based on 8B/10B signaling.

Auto-negotiation

Signalling method allowing each node to select its optimum operational mode (e.g., 10 Mbps or 100 Mbps and half or full duplex) based on the capabilities of the node to which it is connected.

Bandwidth

The difference between the highest and lowest frequencies available for network signals. Also synonymous with wire speed, the actual speed of the data transmission along the cable.

BOOTP

Boot protocol used to load the operating system for devices connected to the network.

Collision

A condition in which packets transmitted over the cable interfere with each other. Their interference makes both signals unintelligible.

Collision Domain

Single CSMA/CD LAN segment.

CSMA/CD

Carrier Sense Multiple Access/Collision Detect is the communication method employed by Ethernet and Fast Ethernet.

Dynamic Host Control Protocol (DHCP)

Provides a framework for passing configuration information to hosts on a TCP/IP network. DHCP is based on the Bootstrap Protocol (BOOTP), adding the capability of automatic allocation of reusable network addresses and additional configuration options.

End Station

A workstation, server, or other device that does not act as a network interconnection.

Ethernet

A network communication system developed and standardized by DEC, Intel, and Xerox, using baseband transmission, CSMA/CD access, logical bus topology, and coaxial cable. The successor IEEE 802.3 standard provides for integration into the OSI model and extends the physical layer and media with repeaters and implementations that operate on fiber, thin coax and twisted-pair cable.

Fast Ethernet

A 100 Mbps network communication system based on Ethernet and the CSMA/CD access method.

Full Duplex

Transmission method that allows switch and network card to transmit and receive concurrently, effectively doubling the bandwidth of that link.

GARP VLAN Registration Protocol (GVRP)

Defines a way for switches to exchange VLAN information in order to register necessary VLAN members on ports along the Spanning Tree so

that VLANs defined in each switch can work automatically over a Spanning Tree network.

Generic Attribute Registration Protocol (GARP)

GARP is a protocol that can be used by endstations and switches to register and propagate multicast group membership information in a switched environment so that multicast data frames are propagated only to those parts of a switched LAN containing registered endstations. Formerly called Group Address Registration Protocol.

Generic Multicast Registration Protocol (GMRP)

GMRP allows network devices to register endstations with multicast groups. GMRP requires that any participating network devices or endstations comply with the IEEE 802.1p standard.

Gigabit Ethernet

A 1000 Mbps network communication system based on Ethernet and the CSMA/CD access method.

Group Attribute Registration Protocol

See Generic Attribute Registration Protocol.

IEEE 802.1D

Specifies a general method for the operation of MAC bridges, including the Spanning Tree Protocol.

IEEE 802.1Q

VLAN Tagging—Defines Ethernet frame tags which carry VLAN information. It allows switches to assign endstations to different virtual LANs, and defines a standard way for VLANs to communicate across switched networks.

IEEE 802.1p

An IEEE standard for providing quality of service (QoS) in Ethernet networks. The standard uses packet tags that define up to eight traffic classes and allows switches to transmit packets based on the tagged priority value.

IEEE 802.3

Defines carrier sense multiple access with collision detection (CSMA/CD) access method and physical layer specifications.

IEEE 802.3ab

Defines CSMA/CD access method and physical layer specifications for 1000BASE-T Fast Ethernet.

IEEE 802.3ac

Defines frame extensions for VLAN tagging.

IEEE 802.3u

Defines CSMA/CD access method and physical layer specifications for 100BASE-TX Fast Ethernet.

IEEE 802.3x

Defines Ethernet frame start/stop requests and timers used for flow control on full-duplex links.

IEEE 802.3z

Defines CSMA/CD access method and physical layer specifications for 1000BASE Gigabit Ethernet.

IGMP Snooping

Listening to IGMP Query and IGMP Report packets transferred between IP Multicast Routers and IP Multicast host groups to identify IP Multicast group members.

Internet Control Message Protocol (ICMP)

Commonly used to send echo messages (i.e., Ping) for monitoring purposes.

Internet Group Management Protocol (IGMP)

A protocol through which hosts can register with their local router for multicast services. If there is more than one multicast router on a given

subnetwork, one of the routers is made the “querier” and assumes responsibility for keeping track of group membership.

In-Band Management

Management of the network from a station attached directly to the network.

IP Multicast Filtering

A process whereby this switch can pass multicast traffic along to participating hosts.

Layer 2

Data Link layer in the ISO 7-Layer Data Communications Protocol. This is related directly to the hardware interface for network devices and passes on traffic based on MAC addresses.

Layer 3

Network layer in the ISO 7-Layer Data Communications Protocol. This layer handles the routing functions for data moving from one open system to another.

Link Aggregation

See Port Trunk.

Link Aggregation Control Protocol (LACP)

Allows ports to automatically negotiate a trunked link with LACP-configured ports on another device.

Media Access Control (MAC)

A portion of the networking protocol that governs access to the transmission medium, facilitating the exchange of data between network nodes.

Management Information Base (MIB)

An acronym for Management Information Base. It is a set of database objects that contains information about a specific device.

Multicast Switching

A process whereby the switch filters incoming multicast frames for services for which no attached host has registered, or forwards them to all ports contained within the designated multicast VLAN group.

Out-of-Band Management

Management of the network from a station not attached to the network.

Port Mirroring

A method whereby data on a target port is mirrored to a monitor port for troubleshooting with a logic analyzer or RMON probe. This allows data on the target port to be studied unobstructively.

Port Trunk

Defines a network link aggregation and trunking method which specifies how to create a single high-speed logical link that combines several lower-speed physical links.

Remote Monitoring (RMON)

RMON provides comprehensive network monitoring capabilities. It eliminates the polling required in standard SNMP, and can set alarms on a variety of traffic conditions, including specific error types.

Simple Network Management Protocol (SNMP)

The application protocol in the Internet suite of protocols which offers network management services.

Spanning Tree Protocol (STP)

A technology that checks your network for any loops. A loop can often occur in complicated or backup linked network systems. Spanning Tree detects and directs data along the shortest available path, maximizing the performance and efficiency of the network.

Telnet

Defines a remote communication facility for interfacing to a terminal device over TCP/IP.

Transmission Control Protocol/Internet Protocol (TCP/IP)

Protocol suite that includes TCP as the primary transport protocol, and IP as the network layer protocol.

Trivial File Transfer Protocol (TFTP)

A TCP/IP protocol commonly used for software downloads.

Virtual LAN (VLAN)

A Virtual LAN is a collection of network nodes that share the same collision domain regardless of their physical location or connection point in the network. A VLAN serves as a logical workgroup with no physical barriers, and allows users to share information and resources as though located on the same LAN.

XModem

A protocol used to transfer files between devices. Data is grouped in 128-byte blocks and error-corrected.

GLOSSARY

INDEX

A

address table 2-30

B

BOOTP 2-11

broadcast storm, threshold 2-28

C

Class of Service

 configuring 2-53

 queue mapping 2-53

community string 2-67

configuration settings, saving or
 restoring 2-18

console port

 pin assignments B-1

D

default priority, ingress port 2-54

default settings 1-13

DHCP 2-11

downloading software 2-16, A-2

F

firmware

 upgrades A-2

firmware version, displaying 2-22

firmware, upgrading 2-16

H

hardware version, displaying 2-22

I

IGMP, configuring 2-69

IP address

 BOOTP/DHCP service 2-11

 setting 2-10

L

log-in

 Web interface 2-2

login authentication

 RADIUS server 2-14

M

main menu 2-5

mirror port, configuring 2-29

multicast

 configuring 2-69

 router 2-72, 3-119

P

passwords

 administrator setting 2-13

pin assignments

 25-pin DTE port B-2

 9-pin DTE port B-2

 console port B-1

port priority

 configuring 2-53

 default ingress 2-54

ports

 configuring 2-24

priority, default port ingress 2-54

problems, troubleshooting A-1

R

RADIUS, logon authentication 2-14

S

serial port

 configuring 3-57

 XModem downloads A-2

SNMP

 community string 2-67

 enabling traps 2-68

 trap manager 2-68

software downloads 2-16, A-2

software version, displaying 2-22

Spanning Tree Protocol 2-33

startup files

 displaying 2-16

 setting 2-16

statistics, switch 2-77

system software

 downloading from server 2-16

T

trap manager 2-68

troubleshooting A-1

trunk

 configuration 2-64

 LACP 2-65

 static 2-66

U

upgrading software 2-16, A-2

user password 2-13

V

VLANs

Index-2

 configuring 2-41

W

Web interface

 access requirements 2-1

 configuration buttons 2-3

 home page 2-2

 menu list 2-5

 panel display 2-4

X

XModem downloads A-2

FOR TECHNICAL SUPPORT, CALL:

From U.S.A. and Canada (24 hours a day, 7 days a week)

(800) SMC-4-YOU; (949) 679-8000; Fax: (949) 679-1481

From Europe (8:00 AM - 5:30 PM UK Time)

44 (0) 118 974 8700; Fax: 44 (0) 118 974 8701

INTERNET

E-mail addresses:

techsupport@smc.com

european.techsupport@smc-europe.com

Driver updates:

http://www.smc.com/index.cfm?action=tech_support_drivers_downloads

World Wide Web:

<http://www.smc.com/>

<http://www.smc-europe.com/>

FOR LITERATURE OR ADVERTISING RESPONSE, CALL:

| | | |
|----------------------|----------------------|-------------------------|
| U.S.A. and Canada: | (800) SMC-4-YOU; | Fax (949) 679-1481 |
| Spain: | 34-93-477-4935; | Fax 34-93-477-3774 |
| UK: | 44 (0) 118 974 8700; | Fax 44 (0) 118 974 8701 |
| France: | 33 (0) 41 38 32 32; | Fax 33 (0) 41 38 01 58 |
| Italy: | 39 02 739 12 33; | Fax 39 02 739 14 17 |
| Benelux: | 31 33 455 72 88; | Fax 31 33 455 73 30 |
| Central Europe: | 49 (0) 89 92861-0; | Fax 49 (0) 89 92861-230 |
| Switzerland: | 41 (0) 1 9409971; | Fax 41 (0) 1 9409972 |
| Nordic: | 46 (0) 868 70700; | Fax 46 (0) 887 62 62 |
| Northern Europe: | 44 (0) 118 974 8700; | Fax 44 (0) 118 974 8701 |
| Eastern Europe: | 34 -93-477-4920; | Fax 34 93 477 3774 |
| Sub Saharian Africa: | 27-11 314 1133; | Fax 27-11 314 9133 |
| North Africa: | 34 93 477 4920; | Fax 34 93 477 3774 |
| Russia: | 7 (095) 290 29 96; | Fax 7 (095) 290 29 96 |
| PRC: | 86-10-6235-4958; | Fax 86-10-6235-4962 |
| Taiwan: | 886-2-2659-9669; | Fax 886-2-2659-9666 |
| Asia Pacific: | (65) 238 6556; | Fax (65) 238 6466 |
| Korea: | 82-2-553-0860; | Fax 82-2-553-7202 |
| Japan: | 81-45-224-2332; | Fax 81-45-224-2331 |
| Australia: | 61-2-9416-0437; | Fax 61-2-9416-0474 |
| India: | 91-22-8204437; | Fax 91-22-8204443 |

If you are looking for further contact information, please visit www.smc.com or www.smc-europe.com.

SMC[®]
Networks

38 Tesla

Irvine, CA 92618

Phone: (949) 679-8000

Model Number: SMC8624T

Publication Number: 150200016900A

Revision Number: E062002-R01