



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
1	OS INF File	OSINFFileDriver_v9.3.0.1019_191_192_W764_ss11122.exe	c:\util2\drivers\intelinf	pininstall.bat execution. Run as administrator.		9.3.0.1019	8/9/12	Mandatory	No	Please install OS INF file before installing all drivers and all applications.
2	Intel Management Engine Software	MeIntelDriver_v8.0.3.1427_191_192_W764_ss11092.exe	c:\util2\drivers\lme	pininstall.bat execution. Run as administrator.	.NET Framework 3.5 or above	8.0.3.1427	8/9/12	Mandatory	No	
3	Intel(R) Rapid Storage Technology	RapidStorageTechnologyDriver_v1.1.0.1006_191_192_W764_ss11109.exe	c:\util2\drivers\lrst	pininstall.bat execution. Run as administrator.		11.1.0.1006	8/9/12	Mandatory	No	
4	Video Driver	VideoDriver_v8.15.10.2696_191_192_W764_ss11116.exe	c:\util2\drivers\video	pininstall.bat execution. Run as administrator.		8.15.10.2696	8/9/12	Mandatory	Yes	The setting of the video is carried out when reboot pininstall.bat after practice. Run "c:\util2\drivers\video\VGAUp.bat" Please reboot again to reflect setting.
5	Port replicator LAN Driver	PortReplicatorLANDriver_v1.0.0.14_191_192_W764_ss11125.exe	c:\util2\drivers\lex-lan\moschip	Run "c:\util2\drivers\lex-lan\moschip\AMD64\setup.exe".		1.0.0.14	8/9/12	Mandatory	Yes	Please install it after it connects it with Port replicator. After it installs it, it is necessary to reboot a system.
6	Common Components for Panasonic PC	PanasonicCommonComponents_v3.00113_191_192_W764_ss11107.exe	c:\util2\pcommon	pininstall.bat execution. Run as administrator.		V3.00L13 M00	8/9/12	Mandatory	No	Install "Panasonic Misc Driver" and "Common Components for Panasonic PC" before installing "Relating driver and application".
7	Panasonic Misc Driver	PanasonicMiscDriver_v1.3.1100.100_191_192_W764_ss11079.exe	c:\util2\drivers\newmisc	pininstall.bat execution. Run as administrator.		1.3.1100.100	8/9/12	Mandatory	No	Install "Panasonic Misc Driver" and "Common Components for Panasonic PC" before installing "Relating driver and application". Two or more "[Other devices]-[Unknown device]" might exist. "Panasonic Misc Driver" is displayed with "ACPI\MAT0021" by "Device Instance Id" of "[Unknown device]->[Details]".



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
8	Common Components for Panasonic PC (x64)	PanasonicCommonComponents64bit_v3.00i13_191_192_W764_ss1108.exe	c:\util2\pcomn64	pininstall.bat execution. Run as administrator.		V3.00L13 M00	8/9/12	Mandatory	No	Install "Panasonic Misc Driver" and "Common Components for Panasonic PC" before installing "Relating driver and application".
9	2nd LAN Driver	2ndLANDriver_v2.4.8.0_191_192_W764_ss11112.exe	c:\util2\drivers\ex-lan\smc	Run [Other devices]->[LAN9500]->[Update driver]. Select "c:\util2\drivers\ex-lan\smc\64\Driver".		v2.4.8.0	8/9/12	Mandatory	No	
10	Bluetooth Stack	BluetoothStackDriver_ver9.00.03(p)_191_192_W764_ss11078.exe	c:\util2\drivers\bluet	pininstall.bat execution. Run as administrator.	Wireless Switch Utility	Ver9.00.03(P)	8/9/12	Mandatory	No	Can only be installed on models with Bluetooth hardware. The application cannot install while the Wireless Switch is OFF. Turn ON Wireless Switch before installing."
11	Modem Driver	ModemDriver_v7.80.4.0_191_192_W764_ss11126.exe	c:\util2\drivers\modem	pininstall.bat execution. Run as administrator.		7.80.4.0	8/9/12	Mandatory	Yes	
12	Power Plan Extension Utility	PanasonicPowerPlanExtensionUtil_v1.09i12_191_192_W764_ss11083.exe	c:\util2\pplanex	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64)	V1.09L12 M00	8/9/12	Recommend	Yes	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously.
13	Battery Recalibration	BatteryRecalibrationUtil_v3.00i10_191_192_W764_ss11077.exe	c:\util2\breca	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64)	V3.00L10 M01	8/9/12	Recommend	Yes	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously.
14	Hand Writing Utility	PanasonicHandWritingApp_v5.05i10_191_192_W764_ss11089.exe	c:\util2\writing	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64)	V5.05L10 M00	8/9/12	Recommend	No	



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
15	Hotkey Driver	HotkeyDriver_v11.2.1100.0_191_192_W764_ss11120.exe	c:\util2\drivers\hotkey	pininstall.bat execution. Run as administrator.		11.2.1100.0	8/9/12	Mandatory	No	Two or more "[Other devices]-[Unknown device]" might exist. "Hotkey Driver" is displayed with "ACPI\MAT0019\..." by "Device Instance Id" of "[Unknown device]->[Details]".
16	Hotkey Settings	HotkeySettingUtil_v3.00111_191_192_W764_ss11119.exe	c:\util2\hkeyset	pininstall.bat execution. Run as administrator.	System Interface Manager, Hotkey Driver	V3.00L11 M00	8/9/12	Recommend	Yes	Install "System Interface Manager" and "Hotkey Driver" first.
17	Dual Touch Driver	DualTouchDriver_v1.00110_191_192_W764_ss11102.exe	c:\util2\drivers\dtouch	Run "c:\util2\drivers\dtouch\calibdat.reg".		V1.00L10M00	8/9/12	Mandatory	Yes	
18	Panasonic Notification	PanasonicNotificationUtil_v1.04112_191_192_W764_ss11082.exe	c:\util2\pnnotif	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64)	V1.04L12 M00	8/9/12	Recommend	No	
19	PC Information Viewer	PCInfoViewerApp_v7.07110_191_192_W764_ss11081.exe	c:\util2\pcinfo	pininstall.bat execution. Run as administrator.	Common Components for Panasonic PC, Common Components for Panasonic PC (x64), Panasonic Misc Driver	V7.07L10 M00	8/9/12	Recommend	Yes	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously.
20	System Interface Manager	SystemInterfaceMgrApp_v11.01111_191_192_W764_ss11114.exe	c:\util2\sysifman	pininstall.bat execution. Run as administrator.	Hotkey Driver, Panasonic Notification	V11.01L11 M00	8/9/12	Mandatory	Yes	Install "Hotkey Driver" first.
21	USB Selective Suspend Manager	USBSelectiveSuspendMgrApp_v2.02110_191_192_W764_ss11110.exe	c:\util2\selsussv	pininstall.bat execution. Run as administrator.		V2.02L10 M01	8/9/12	Recommend	Yes	



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
22	Wireless Connection Disable Utility	WirelessConnDisableUtil_v1.0711_191_192_W764_ss11086.exe	c:\util2\wdisable	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Wireless Switch Utility	V1.07L11 M00	8/9/12	Optional	Yes	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously. Install "Wireless Switch Utility". (However, execute "Panasonic Misc Driver" and "Common Components for Panasonic PC".) Utility is not pre-installed on factory Panasonic image. The installer is only provided in "c:\util2\wdisable".
23	Wireless Switch Utility [This file can be installed only to WLAN model]	WirelessSwitchUtil_v4.11112_191_192_W764_ss11068.exe	c:\util2\wswitch	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64), Wireless LAN Driver, System Interface Manager, Hotkey Driver, Bluetooth Stack	V4.11L12 M00	8/9/12	Recommend	Yes	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously. Install "System Interface Manager" and "Hotkey Driver". (However, execute "Panasonic Misc Driver" and "Common Components for Panasonic PC".) Please uninstall it first when there is Wireless LAN Switch or Bluetooth Switch.
24	Wireless LAN Driver (Atheros Wireless LAN model) [This file can be installed only to WLAN model]	WirelessLANDriver_win7_9.2.0.489_191_192_W764_ss11087.exe	c:\util2\drivers\wlan_a	Executing "setup.exe"		Win7_9.2.0.489	8/9/12	Mandatory	Yes	Can only be installed on models with Atheros WLAN module.
25	Touchscreen Driver	TouchscreenDriver_v1.0.0.9_191_192_W764_ss11104.exe	c:\util2\drivers\tscreen	1. Run "c:\util2\drivers\tscreen\TPSetUp.exe" 2. Run "[start]-[Control Panel]-[Hardware and Sound]-[Tablet Calibration]" 3. Please do calibration.		1.0.0.9	8/9/12	Mandatory	Yes	
26	USB 3.0 Driver	USB30(Renesas)Driver_v1.0.4.225_191_192_W764_ss11140.exe	c:\util2\drivers\usb30	pininstall.bat execution. Run as administrator.		1.0.4.225	8/9/12	Mandatory	No	
27	Wireless LAN Driver (Intel Wireless LAN model) [This file can be installed only to WLAN model]	WirelessLANDriver_muroc15.1.1.0_wifi_pv_ticthwfw0927g_191_192_W764_ss11088.exe	c:\util2\drivers\wlan	pininstall.bat execution. Run as administrator.		Muroc 15.1.1.0_WiFi_P V_TICTHWFW0927G	8/9/12	Mandatory	No	Can only be installed on models with Intel WLAN module.
28	Software Keyboard	SwKeyboard_v7.0711_191_192_W764_ss11101.exe	c:\util2\meiskb	pininstall.bat execution. Run as administrator.		V7.07L11 M00	8/9/12	Optional	No	

CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
29	SD Driver	SDDriver_v6.10.10.28_53J_191_192_W764_ss11127.exe	c:\util2\drivers\sd_ri	pininstall.bat execution. Run as administrator. Copy "c:\util2\drivers\sd_ri\sdpcbus.dll" in "C:\Windows\System32\sdca".		6.10.10.28	8/9/12	Mandatory	Yes	
30	GPS Registry Patch	GPSRegistryPatch_v2.0012_191_192_W764_ss11117.exe	c:\util2\drivers\gps	1. Set GPS to Disabled in BIOS Setup. 2. Reboot PC and execute "c:\util2\drivers\gps\GPS.reg". 3. Set GPS to Auto in BIOS Setup. 4. Reboot PC		V2.00L12M00	8/9/12	Mandatory	No	Can only be installed on models with GPS module.
31	Tablet Buttons Driver	TabletButtonDriver_v2.2.1000.0_191_192_W764_ss11103.exe	c:\util2\drivers\meitbtr	pininstall.bat execution. Run as administrator. Carry out the batch file in the route of the Stock folder in administrator rights Run "c:\util2\drivers\meitbtr\standard_19.bat.		2.2.1000.0	8/9/12	Mandatory	Yes	
32	Fingerprint Driver	FingerprintDriver_v2011build7080_191_192_W764_ss11067.exe	c:\util2\drivers\fngrprnt	pininstall.bat execution. Run as administrator. *application is not installed [When install application] Run "c:\util2\drivers\fngrprnt\install\32-bit\Setup.exe".(32bit) Run "c:\util2\drivers\fngrprnt\install\64-bit\Setup.exe".(64bit)		2011 build7080	8/9/12	Mandatory	No	Can only be installed on models with Fingerprint Reader.
33	Tablet Button Manager	TabletButtonMgrApp_v2.03110_191_192_W764_ss11074.exe	c:\util2\meitbman	pininstall.bat execution. Run as administrator.	Tablet Buttons Driver, Panasonic Notification, Common Components for Panasonic PC, Common Components for Panasonic PC (x64), Panasonic Misc Driver	V2.03L10 M00	8/9/12	Recommend	No	
34	Intel(R) Dynamic Platform and Thermal Framework 6.0	DynamicPowerPerfMgmtDriver_v6.0.2.1071(hotfix2pv)_191_192_W764_ss11106.exe	c:\util2\drivers\letm	Executing "setup.exe"		6.0.2.1071 (HotFix2 PV)	8/9/12	Mandatory	Yes	
35	LAN Driver	LanDriver_v11.15.16.0_191_192_W764_ss11123.exe	c:\util2\drivers\lan	pininstall.bat execution. Run as administrator.		11.15.16.0	8/9/12	Mandatory	No	



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
36	Camera Utility	PanasonicCameraUtil_v3.0511_191_192_W764_ss11080.exe	c:\util2\pcam	Executing "setup.exe"	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64)	V3.05L11 M00	8/9/12	Recommend	Yes	Install Camera Driver before installing this software. (For Camera model.) Install "Camera Light Switch Utility" before installing "Relating application". (For Camera Light model.)
37	Display Selector	DisplaySelectorUtil_v1.0012_191_192_W764_ss11105.exe	c:\util2\dispse	Executing "setup.exe"	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64) PC, Information Viewer	V1.00L12 M00	8/9/12	Recommend	Yes	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously. Install "PC Information Viewer". (However, execute "Panasonic Misc Driver" and "Common Components for Panasonic PC".) Manual (README.pdf) cannot be referred to if Adobe Reader is not installed.
38	Touch Pad Driver	TouchPadDriver_v2.0.0_191_192_W764_ss11138.exe	c:\util2\drivers\mouse_i	Executing "setup.exe"		2.0.0	8/9/12	Mandatory	Yes	
39	Calibration Utility	CalibrationUtil_v1.0412_191_192_W764_ss11069.exe	c:\util2\calibutl	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver	V1.04L12 M00	8/9/12	Recommend	Yes	
40	DevUp Service	PanasonicDevUpService_v1.1011_191_192_W764_ss11071.exe	c:\util2\devup	Executing "setup.exe"	Panasonic Misc Driver	V1.10L11 M00	8/9/12	Mandatory	No	
41	WWAN Driver (F5521gw) Package	F5521gw(Ericsson)WWANDriver_v1.07110_191_192_W764_ss11090.exe	c:\util2\drivers\wwan	pininstall.bat execution. Run as administrator.		V1.07L10M00	8/9/12	Mandatory	No	Only Ericsson WWAN model can develop. Please apply following KB. KB2615592 http://support.microsoft.com/kb/2615592 [Win7 nonSP] Please apply following KB. KB975496, KB975777, KB975851, KB976972, KB978258, KB981214, KB981351, KB981382



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
42	Camera Light Switch Utility	CameraLightSwitchUtil_v1.05111_191_192_W764_ss11073.exe	c:\util2\lightsw	Executing "setup.exe"	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64), Panasonic Camera Utility	V1.05L11 M01	8/9/12	Recommend	No	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously.
43	GPS Viewer	GPSViewerApp_v1.02111_191_192_W764_ss11091.exe	c:\util2\GPSState	Executing "setup.exe"		V1.02L11M00	8/9/12	Recommend	Yes	
44	Quick Boot Manager	QuickBootMgmtApp_v3.01110_191_192_W764_ss11084.exe	c:\util2\qbmgr	pininstall.bat execution. Run as administrator.	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64), PC Information Viewer	V3.01L10 M00	8/9/12	Recommend	No	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously.
45	Dashboard for Panasonic PC	PanasonicDashboardApp_v2.05110b_191_192_W764_ss11070.exe	c:\util2\dashboard19	Executing "setup.exe"	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64) System Interface Manager GPS Viewer(Only GPS Model)	V2.05L10B M00	8/9/12	Recommend	No	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously. Install "System Interface Manager" first.(Confirmation of "Battery Recalibration" is not possible.)
46	Sound Driver	SoundDriver_v6.0.1.6591_191_192_W764_ss11113.exe	c:\util2\drivers\sound	pininstall.bat execution. Run as administrator. It is necessary to reboot after having carried out pininstall.bat.		6.0.1.6591	8/9/12	Mandatory	No	
47	Smart Card Driver	SmartCardDriver_v4.49.0.0_191_192_W764_ss11111.exe	c:\util2\drivers\smartc	pininstall.bat execution. Run as administrator.		V4.49.0.0	8/9/12	Mandatory	No	Can only be installed on models with SmartCard module.
48	Display Rotation Tool	DisplayRotationTool_v7.09112_191_192_W764_ss11072.exe	c:\util2\disprot	Executing "setup.exe"	Panasonic Misc Driver, Common Components for Panasonic PC, Common Components for Panasonic PC (x64)	V7.09L12 M00	8/9/12	Recommend	No	"Panasonic Misc Driver" and "Common Components for Panasonic PC" are installed previously. Install "TouchPad Driver".(A rotary function of "TouchPad" is not available.)

CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
49	Wireless WAN Manager	WirelessWANManagerUtil_v7.1.0.2_191_192_W764_ss11118.exe	c:\util2\wwanm	pinstall.bat execution. Run as administrator.		V7.1.0.2	8/9/12	Recommend	Yes	
50	TPM Driver	TPMDriver_v3.7rtm_191_192_W764_ss11085.exe	c:\util2\drivers\tpm	Because the driver of InBox is used, the installation is unnecessary.		V3.7RTM	8/9/12	Mandatory	Yes	Please see the manual(C:\util2\drivers\tpm\README.PDF) concerning TPM about detailed use. However, the manual cannot be referred to if Acrobat Reader is not installed. Please read and change the description of "C:\util" of the manual into customer's development folder(C:\util2). The application program is not installed in the state of the factory shipment. Please install from "C:\util2\drivers\tpm\inf\neon\setup.exe" and use it when you use the application program.
51	Asset Tag Entry	AssetTagEntryUtil_v4.00110_191_192_W764_ss11076.exe	c:\util2\assettag	The installation is unnecessary. Only the execution of exe.	Panasonic Misc Driver	V4.00L10 M00	8/9/12	Optional	Yes	Please finish installing all applications before using this utility.
52	Wireless WAN Antenna Switch Utility	WirelessWANAntennaSwitchUtil_v3.00111_191_192_W764_ss11098.exe	c:\util2\wwanasw	Executing "setup.exe"		V3.00L11 M00	8/9/12	Optional	Yes	
53	Wireless Manager for Panasonic Projector			http://panasonic.net/avc/projector/software/			8/9/12			Utility is not pre-installed on factory Panasonic image. The installer is only provided in "c:\util\wpjct".
-	Hotkey Driver with apps.	HotkeysCollectiveSettingApp_v11.2.1100.0_v11.01111_v3.00111_191_192_W764_ss11121.exe	c:\util2\drivers\hotkeyw	Executing [Update driver..] in the device manager		11.2.1100.0/V11.01L11 M00/V3.00L11 M00	8/9/12	Optional	No	Hotkey Driver with apps. is the INF style installer to install Hotkey Driver, System Interface Manager and Hotkey Settings. You can use this installer if you are inevitable to install these softwares by INF. Two or more "[Other devices]-[Unknown device]" might exist. "Hotkey Driver" is displayed with "ACPI\MAT0019\..." by "Device Instance Id" of "[Unknown device]->[Details]".



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))
Installation Instructions for All CF-19 Drivers and Utilities

This document shows the correct order of installing all CF-19 drivers and applications

9-Aug-12
H-2012-0085

Order	Driver Type	File Name	Unpacked Directory	Installation Procedure	Dependencies	Version	Release Date	Required	Microsoft Signed	Comments
-------	-------------	-----------	--------------------	------------------------	--------------	---------	--------------	----------	------------------	----------



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

MS Updates Installation Instructions

* Please download these MS Updates from Microsoft Download Center (<http://www.microsoft.com/downloads/>).

9-Aug-12
H-2012-0085

* Please download these MS Updates from Microsoft Download Center (<http://www.microsoft.com/downloads/>).

	* Update #	Version	Release Date	Optional	Required
1	.net framework V4.0		08/09/2012	Optional	
2	Silverlight 4		08/09/2012	Optional	
3	VirtualXP (64bit)		08/09/2012	Optional	
4	Windows Live Essentials 2011 (Mail) english		08/09/2012	Optional	
5	xpmode		08/09/2012	Optional	
6	Internet Explorer 9 for Win7 64bit		08/09/2012	Recommend	
7	Microsoft Update Module (Q2393802)		08/09/2012	Mandatory	
8	Microsoft Update Module (Q2425227)		08/09/2012	Mandatory	
9	Microsoft Update Module (Q2459268)		08/09/2012	Mandatory	
10	Microsoft Update Module (Q2479943)		08/09/2012	Mandatory	
11	Microsoft Update Module (Q2484033)		08/09/2012	Mandatory	
12	Microsoft Update Module (Q2488113)		08/09/2012	Mandatory	
13	Microsoft Update Module (Q2489036)		08/09/2012	Mandatory	
14	Microsoft Update Module (Q2491683)		08/09/2012	Mandatory	
15	Microsoft Update Module (Q2492386)		08/09/2012	Mandatory	
16	Microsoft Update Module (Q2496898)		08/09/2012	Mandatory	
17	Microsoft Update Module (Q2503658)		08/09/2012	Mandatory	
18	Microsoft Update Module (Q2505438)		08/09/2012	Mandatory	
19	Microsoft Update Module (Q2505454)		08/09/2012	Mandatory	
20	Microsoft Update Module (Q2506014)		08/09/2012	Mandatory	
21	Microsoft Update Module (Q2506212)		08/09/2012	Mandatory	
22	Microsoft Update Module (Q2506928)		08/09/2012	Mandatory	
23	Microsoft Update Module (Q2507618)		08/09/2012	Mandatory	
24	Microsoft Update Module (Q2509553)		08/09/2012	Mandatory	
25	Microsoft Update Module (Q2510636)		08/09/2012	Mandatory	
26	Microsoft Update Module (Q2511250)		08/09/2012	Mandatory	
27	Microsoft Update Module (Q2515325)		08/09/2012	Mandatory	
28	Microsoft Update Module (Q2518869)		08/09/2012	Mandatory	
29	Microsoft Update Module (Q2528984)		08/09/2012	Mandatory	
30	Microsoft Update Module (Q2529073)		08/09/2012	Mandatory	
31	Microsoft Update Module (Q2532531)		08/09/2012	Mandatory	
32	Microsoft Update Module (Q2534111)		08/09/2012	Mandatory	
33	Microsoft Update Module (Q2536275)		08/09/2012	Mandatory	
34	Microsoft Update Module (Q2536276-V2)		08/09/2012	Mandatory	
35	Microsoft Update Module (Q2541014)		08/09/2012	Mandatory	
36	Microsoft Update Module (Q2544893)		08/09/2012	Mandatory	
37	Microsoft Update Module (Q2545698)		08/09/2012	Mandatory	
38	Microsoft Update Module (Q2547666)		08/09/2012	Mandatory	
39	Microsoft Update Module (Q2552343)		08/09/2012	Mandatory	
40	Microsoft Update Module (Q2556532)		08/09/2012	Mandatory	
41	Microsoft Update Module (Q2560656)		08/09/2012	Mandatory	
42	Microsoft Update Module (Q2563227)		08/09/2012	Mandatory	
43	Microsoft Update Module (Q2564958)		08/09/2012	Mandatory	
44	Microsoft Update Module (Q2567680)		08/09/2012	Mandatory	
45	Microsoft Update Module (Q2570947)		08/09/2012	Mandatory	
46	Microsoft Update Module (Q2572077)		08/09/2012	Mandatory	
47	Microsoft Update Module (Q2579686)		08/09/2012	Mandatory	
48	Microsoft Update Module (Q2584146)		08/09/2012	Mandatory	
49	Microsoft Update Module (Q2585542)		08/09/2012	Mandatory	
50	Microsoft Update Module (Q2588516)		08/09/2012	Mandatory	
51	Microsoft Update Module (Q2607576)		08/09/2012	Mandatory	
52	Microsoft Update Module (Q2615592)		08/09/2012	Mandatory	



CF-19[1/2] (Windows 7 Professional SP1 64bit for English(North America))

MS Updates Installation Instructions

* Please download these MS Updates from Microsoft Download Center (<http://www.microsoft.com/downloads/>).

9-Aug-12
H-2012-0085

* Please download these MS Updates from Microsoft Download Center (<http://www.microsoft.com/downloads/>).

	* Update #	Version	Release Date	Required
53	Microsoft Update Module (Q2618451)		08/09/2012	Mandatory
54	Microsoft Update Module (Q2619339)		08/09/2012	Mandatory
55	Microsoft Update Module (Q2620712)		08/09/2012	Mandatory
56	Microsoft Update Module (Q2621440)		08/09/2012	Mandatory
57	Microsoft Update Module (Q2631813)		08/09/2012	Mandatory
58	Microsoft Update Module (Q2633873)		08/09/2012	Mandatory
59	Microsoft Update Module (Q2633952)		08/09/2012	Mandatory
60	Microsoft Update Module (Q2639308)		08/09/2012	Mandatory
61	Microsoft Update Module (Q2640148)		08/09/2012	Mandatory
62	Microsoft Update Module (Q2641653)		08/09/2012	Mandatory
63	Microsoft Update Module (Q2641690)		08/09/2012	Mandatory
64	Microsoft Update Module (Q2644615)		08/09/2012	Mandatory
65	Microsoft Update Module (Q2645640)		08/09/2012	Mandatory
66	Microsoft Update Module (Q2647516)		08/09/2012	Mandatory
67	Microsoft Update Module (Q2647518)		08/09/2012	Mandatory
68	Microsoft Update Module (Q2654428)		08/09/2012	Mandatory
69	Microsoft Update Module (Q2656356)		08/09/2012	Mandatory
70	Microsoft Update Module (Q2660075)		08/09/2012	Mandatory
71	Microsoft Update Module (Q2661796)		08/09/2012	Mandatory
72	Microsoft Update Module (Q2665364)		08/09/2012	Mandatory
73	Microsoft Update Module (Q2667402)		08/09/2012	Mandatory
74	Microsoft Update Module (Q982018)		08/09/2012	Mandatory



The history of CF-19[1/2] Windows 7 Professional SP1 64bit for English(North America) Installation Instructions

14-Sep-12
H-2012-0085

	Histories	Version	Release Date	Required
1	Initial Release		08/09/2012	Mandatory
2	The order of "Hotkey Driver with apps." was changed.		08/30/2012	Optional
3	Description of the comment was corrected.		09/14/2012	Mandatory

